



VOLVO PARTS  
1 040 10437

Sida Page	Grupp Group	Växellåda BW35, GV	Gearbox BW35, GV	Illustration 10437 1979-11	0950						
78	4										
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	254 677	254 679	254 680	254 708							
1	1	-	-	-	254677-8	Växellåda.....	Gearbox.....		8	B20E. 145 B20F. ERS AV 1ST 254784-2, 2ST 235851-3, 1ST 381106-4, 1ST 235985-9.	1010 1011 1012 1013 1014
	-	1	-	-	254679-4	Växellåda.....	Gearbox.....			B20B,D.	1020
	-	-	1	-	254680-2	Växellåda.....	Gearbox.....		8	B20A. ERS AV 1ST 254782-6, 2ST 235851-3, 1ST 381106-4, 1ST 235985-9.	1030 1031 1032 1033 1034
	-	-	-	1	254708-1	Växellåda.....	Gearbox.....		8	B20F. EXCL 145 B20F. ERS AV 1ST 254760-2, 1ST 235877-8, 1ST 235985-9.	1050 1051 1052
x x 2	1	-	-	1	1220608-2	•Momentomvandlare.....	•Converter.....			(235879)	1060
	-	1	1	-	1220586-0	•Momentomvandlare.....	•Converter.....			(1220505)	1070
3	1	1	1	1	235736-6	•Momentomvandlarkåpa...	•Converter housing.....				1080
4	2	2	2	2	235814-1	•Skyddsnet.....	•Stone guard.....				1090
5	6	6	6	6	940135-7	•Skruv.....	•Screw.....				1100
6	6	6	6	6	955921-2	•Fjäderbricka.....	•Spring washer.....				1110
7	1	1	1	1		•Hus med planetväxel.....	•Planet cover.....			SE SIDA 86, 2-115	1120
8	1	1	1	1	235922-2	•Bakre gavel.....	•Extension housing.....				1130
9	1	1	1	1	235728-3	•Tätningring.....	•Oil seal.....		S		1140
10	1	1	1	1		•Packning.....	•Gasket.....		S		1150
11	4	4	4	4	235918-0	•Skruv.....	•Screw.....				1160
12	4	4	4	4	940110-0	•Fjäderbricka.....	•Spring washer.....				1170
13	1	1	-	1	235983-4	•Kontrollsystem.....	•Valve bodies.....				1180
	-	-	1	-	235970-1	•Kontrollsystem.....	•Valve bodies.....				1190
	-	-	-	-		•Det se sida 96, 2-J01.....	•Comps page 96, 2-J01.....				1200
14	1	1	1	1	940117-5	•Skruv.....	•Screw.....			L31,75	1210
15	1	1	1	1	955920-4	•Fjäderbricka.....	•Spring washer.....				1220
16	2	2	2	2	955516-0	•Skruv.....	•Screw.....			L50,8	1230
17	2	2	2	2	955920-4	•Fjäderbricka.....	•Spring washer.....				1240
18	1	1	1	1	235705-1	•Inloppsrör, främre pump...	•Tube, front pump.....				1250
19	1	1	1	1	235527-9	•O-ring.....	•O-ring.....		S		1260
20	1	1	1	1	235704-4	•Utloppsrör, främre pump...	•Tube, front pump.....				1270
21	1	1	1	1	235706-9	•Inloppsrör, konverter.....	•Tube, converter.....				1280
22	1	1	1	1	235848-9	•Utloppsrör, konverter.....	•Tube, converter.....				1290
23	1	1	1	1	235701-0	•Rör, främre servo.....	•Tube, front servo.....				1300
24	-	1	1	-	235702-8	•Rör, främre servo.....	•Tube, front servo.....				1310
	1	-	-	1	235853-9	•Rör, främre servo.....	•Tube, front servo.....				1320
25	1	1	1	1	235703-6	•Rör, bakre koppling.....	•Tube, rear clutch.....				1330
26	1	1	1	1	235707-7	•Rör, bakre servo.....	•Tube, rear servo.....				1340
27	1	1	1	1	235985-9	•Reglagewire.....	•Cable.....				1350
27a	1	1	1	1	1220513-4	•Kabelstopp.....	•Cable stop.....				1360
28	1	1	1	1	235812-5	•Packning.....	•Packing.....				1370
29	1	1	1	1		•Kam.....	•Cam.....			SE SIDA 96, 2-J01	1380
30	1	1	1	1	1220558-9	•Startspärr och back- ljuskontakt,6-stift.....	•Inhibitor and back- lamp switch,6-pin.....		8	ERS AV 1220509-2.	1390
	1	1	1	1	1220509-2	•Startspärr-och back- ljuskontakt,4-stift.....	•Inhibitor-and back- lamp switch, 4-pin.....				1392
31	1	1	1	1	941442-6	•Mutter.....	•Nut.....			TID UTF	1400
31a	1	1	1	1	235812-5	•Packning.....	•Packing.....			SEN UTF	1405
32	1	1	1	1	235907-3	•Axel.....	•Shaft.....				1410
33	1	1	1	1	235979-2	•Hävarm.....	•Lever.....				1420
34	1	1	1	1	235845-5	•Pinne.....	•Pin.....				1430
35	1	1	1	1	235927-1	•Låspinne.....	•Lock pin.....				1440
36	1	1	1	1	235928-9	•Låsring.....	•Snap ring.....				1450
37	1	1	1	1	235783-8	•Hattplugg.....	•Plug.....				1460
38	1	1	1	1		•Tätningring.....	•Seal ring.....			SE SIDA 86, 2-115	1470
39	1	1	1	1	60309-2	•Kula.....	•Ball.....				1480
40	1	1	1	1	235714-3	•Fjäder.....	•Spring.....				1490

Sida Page	Grupp Group	Växellåda BW35, GV	Gearbox BW35, GV	Illustration 10437 1979-11	0950						
80	4										
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	254 677	254 679	254 680	254 708							
41	1	1	1	1	235972-7	•Dragstång .....	•Linkage rod .....				1500
42	1	1	1	1	235826-5	•Hävarm .....	•Torsion lever .....				1510
43	1	1	1	1	235652-5	•Fjäder .....	•Toggle lever spring .....				1520
44	1	1	1	1		•Lagertapp .....	•Pivot pin .....			SESIDA 86, 2-115	1530
45	1	1	1	1	41561-2	•Bricka .....	•Washer .....				1540
46	1	1	1	1	235654-1	•Låsfjäder .....	•Retaining spring .....				1550
47	1	1	1	1	235651-7	•Hävarm .....	•Toggle lift lever .....				1560
48	1	1	1	1	235641-8	•Hänke .....	•Toggle link .....				1570
49	1	1	1	1	235640-0	•Hävarm .....	•Pawl .....				1580
50	1	1	1	1	235642-6	•Tapp .....	•Pin .....				1590
51	1	1	1	1	235643-4	•Hävarm .....	•Toggle lever .....				1600
52	1	1	1	1	235792-9	•Tapp .....	•Pin .....				1610
53	1	1	1	1	235793-7	•Fjäder .....	•Release spring .....				2020
54	1	1	1	1	235648-3	•Lagertapp .....	•Toggle pin .....				2030
55	1	1	1	1	235649-1	•O-ring .....	•O-ring .....	S			2040
56	1	1	1	1	235650-9	•Pinne .....	•Anchor pin .....				2050
57	1	1	1	1	951956-2	•Låspinne .....	•Slotted spring pin .....				2060
58	1	1	1	1	235857-0	•Oljesump .....	•Oilpan .....				2070
59	1	1	1	1	235739-0	•Magnet .....	•Magnet .....				2080
60	1	1	1	1		•Packning .....	•Gasket .....	S			2090
61	15	15	15	15	955523-6	•Skruv .....	•Screw .....				2100
62	15	15	15	15	955921-2	•Fjäderbricka .....	•Spring washer .....				2110
63	1	1	1	1	235859-6	•Avtappningspropp .....	•Drain plug .....				2120
64	1	1	1	1	235858-8	•Packning .....	•Packing .....				2130
	1	1	1	1	276501-4	Gummi- och tätningssats .....	Rubber- and seal ring .....				2140
						Ringsats .....	Kit .....				2150
	1	1	1	1	273221-2	Packningssats .....	Gasket kit .....				2160