



VOLVO PARTS
1040 10836

Sida Page	Grupp Group	Växellåda BW35, RV	Gearbox BW35, RV	Illustration 10836 1979-11	0850					
70	4									
Pos. Fig.	Antal/Quantity			Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	254 525	254 586								
1	1	-	-	254525-9	Växellåda.....	Gearbox.....		8		1010
				254586-1	Växellåda.....	Gearbox.....				1020
x 2	1	1	-	1220601-7	•Momentomvandlare.....	•Converter.....			(235503)	1030
3	1	1	-	235736-6	•Momentomvandlarkåpa.....	•Converter housing.....				1040
4	2	2	-	235814-1	•Skyddsnät.....	•Stone guard.....				1050
4a	4	-	-	235768-9	•Skruv.....	•Screw.....			TID UTF.	1070
5	6	6	-	940135-7	•Skruv.....	•Screw.....				1080
6	6	6	-	955921-2	•Fjäderbricka.....	•Spring washer.....				1090
7	1	1	-		•Hus med planetväxel.....	•Planet cover.....			SE SIDA 86, 2-115	1100
8	1	1	-	235727-5	•Bakre gavel.....	•Extension housing.....				1110
9	1	1	-	235728-3	•Tätningssystem.....	•Oil seal.....		S		1120
10	1	1	-		•Packning.....	•Gasket.....		S		1130
11	4	4	-	955525-1	•Skruv.....	•Bolt.....				1140
12	4	4	-	955921-2	•Fjäderbricka.....	•Spring washer.....				1150
13	1	1	-	235842-2	•Kontrollsystem.....	•Valve bodies.....				1160
					•Det se sida 96, 2-J01.....	•Comps page 96, 2-J01.....				1170
14	1	1	-	940117-5	•Skruv.....	•Bolt.....			L 11/4 TUM	1180
15	1	1	-	955920-4	•Fjäderbricka.....	•Spring washer.....				1200
16	2	2	-	955516-0	•Skruv.....	•Bolt.....			L 2 TUM	1210
17	2	2	-	955920-4	•Fjäderbricka.....	•Spring washer.....				1220
18	1	1	-	235705-1	•Inloppsrör, främre pump.....	•Tube, front pump.....				1230
19	1	1	-	235527-9	•O-ring.....	•O-ring.....		S		1240
20	1	1	-	235704-4	•Utloppsrör, främre pump.....	•Tube, front pump.....				1250
21	1	1	-	235706-9	•Inloppsrör, konverter.....	•Tube, converter.....				1260
22	1	-	-	235706-9	•Utloppsrör, konverter.....	•Tube, converter.....				1270
				235848-9	•Utloppsrör, konverter.....	•Tube, converter.....				1280
23	1	1	-	235701-0	•Rör, främre servo.....	•Tube, front servo.....				1290
24	1	1	-	235702-8	•Rör, främre servo.....	•Tube, front servo.....				1300
25	1	1	-	235703-6	•Rör, bakre koppling.....	•Tube, rear clutch.....				1310
26	1	1	-	235707-7	•Rör, bakre servo.....	•Tube, rear servo.....				1320
27	1	1	-	235985-9	•Reglagevajer.....	•Control wire.....				1330
27a	1	1	-	1220513-4	•Kabelstopp.....	•Cable stop.....				1340
28	1	1	-	235812-5	•Packning.....	•Packing.....				1350
29	1	1	-		•Kam.....	•Cam.....			SE SIDA 96, 2-J01 (1220508)	1360
30	1	1	-	1220509-2	•Startspärr och back- ljuskontakt, 4-stift.....	•Inhibitor and back- lamp switch, 4-pin.....				1370
31	1	1	-	941442-6	•Mutter.....	•Nut.....			TID UTF	1380
31a	1	1	-	235812-5	•Packning.....	•Packing.....			SEN UTF	1390
32	1	-	-	235709-3	•Axel.....	•Shaft.....			BW35-EN 12560 ERS AV 273111 BW35 EN 12561-	1400
				235808-3	•Axel.....	•Manual valve lever shaft.....		S		1410
33	1	1	-	235711-9	•Fjäder.....	•Spring.....				1420
34	1	-	-	235708-5	•Hävarm.....	•Manual valve lever.....			BW35-EN 12560 ERS AV 273111	1430
				235836-4	•Hävarm.....	•Manual valve lever.....		S	BW35 EN 12561- (235735)	1450
35	1	1	-	235710-1	•Låspinne.....	•Slotted spring pin.....		S		1460
36	1	1	-	235712-7	•Ring.....	•Collar.....				1470
37	1	1	-	235713-5	•Låspinne.....	•Slotted spring pin.....				1480
38	2	2	-		•Tätningssystem.....	•Seal ring.....			SE SIDA 86, 2-115	1490
39	1	1	-	60309-2	•Kula.....	•Ball.....				1500
40	1	1	-	235714-3	•Fjäder.....	•Spring.....				1510
41	1	-	-	235655-8	•Dragstång.....	•Linkage rod.....			BW35-EN 26869	1520
				235827-3	•Dragstång.....	•Linkage rod.....		8	BW35 EN 26870-	1530
41a	2	-	-	235656-6	•Låsfjäder.....	•Retaining spring.....				1540
42	1	1	-	235826-5	•Hävarm.....	•Torsion lever.....			(235653)	1560
43	1	1	-	235652-5	•Fjäder.....	•Toggle lever spring.....				1570
44	1	1	-		•Lagertapp.....	•Pivot pin.....			SE SIDA 86, 2-115	1580
45	1	1	-	41561-2	•Bricka.....	•Washer.....				1590
46	1	1	-	235654-1	•Låsfjäder.....	•Retaining spring.....				1600
47	1	1	-	235651-7	•Hävarm.....	•Toggle lift lever.....				2010
48	1	1	-	235641-8	•Hänke.....	•Toggle link.....				2020
49	1	1	-	235640-0	•Hävarm.....	•Pawl.....				2030
50	1	1	-	235642-6	•Tapp.....	•Pin.....				

Sida Page	Grupp Group	Växellåda BW35, RV	Gearbox BW35, RV	Illustration 10836 1979-11	0850						
72	4										
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	254 525	254 586									
51	1	1	-	-	235643-4	•Hävarm	•Toggle lever				2040
52	1	1	-	-	235792-9	•Tapp	•Pin				2050
53	1	1	-	-	235793-7	•Fjäder	•Release spring				2060
54	1	1	-	-	235648-3	•Lagertapp	•Toggle pin				2070
55	1	1	-	-	235649-1	•O-ring	•O-ring	S			2080
56	1	1	-	-	235650-9	•Pinne	•Anchor pin				2090
57	1	1	-	-	951956-2	•Låspinne	•Slotted spring pin				2100
58	1	1	-	-	235715-0	•Oljesump	•Oil pan	8	TID UTFERS AV 1ST 235857-0, 1 ST 235859-6, 1 ST 235858-8. SEN UTF.		2110 2120 2130 2140
	1	1	-	-	235857-0	•Oljesump	•Oil pan				2150
59	1	1	-	-	235739-0	•Magnet	•Magnet				2160
60	1	1	-	-		•Packning	•Gasket	8			2170
61	15	15	-	-	955523-6	•Skruv	•Screw				2180
62	15	15	-	-	955921-2	•Fjäderbricka	•Spring washer				2190
63	1	1	-	-	952075-0	•Avtappningspropp	•Drain plug		21)		2200
64	1	1	-	-	235859-6	•Avtappningspropp	•Drain plug		22)		2210
65	1	1	-	-	235858-8	•Packning	•Packing		22)		2220
	1	1	-	-	276501-4	Gummi- och tätningssats ringsats	Rubber and seal ring kit				2230
	1	1	-	-	276502-2	Packningssats	Gasket kit				2240
	1	-	-	-	273111-5	Reparationssats, spärr- arm	Manuel valve detent lever kit				2250 2260

21. För oljesump 235715. For oil sump 235715. Pour carter d'huile 235715. Für Ölwanne 235715. Para cárter de aceite 235715.
22. För oljesump 235857. For oil sump 235857. Pour carter d'huile 235857. Für Ölwanne 235857. Para cárter de aceite 235857.