



Sida Page	Grupp Group	Förgasare	Carburetter	Illustration	0800						
72	2c			10898							
				1979-11							
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	237 548	237 549	237 552	237 553							
45	1	1	-	-	237528-5	•Packning.....	•Packning.....	S			1280
46	1	1	-	-	237525-1	•Spårring.....	•Circlip.....	S		TID UTF	1300
47	1	1	-	-	237524-4	•Bricka.....	•Washer.....	S		TID UTF	1320
48	1	1	-	-	237580-6	•Bricka.....	•Washer.....	8		SEN UTF	1340
	1	1	-	-		•Ventilspindel.....	•Valve spindle.....	8		TID UTF. ERS AV	1360
49	1	1	-	-	237595-4	•Ventilspindel.....	•Valve spindle.....	S		1ST 237595-4,	1380
	1	1	-	-	237527-7	•O-ring.....	•O-ring.....	S		1ST 237596-2,	1400
50	1	1	-	-	237581-4	•Ventilhylsa.....	•Valve sleeve.....	8		1ST 237597-0,	1420
										1ST 419568-1.	1440
51	1	1	-	-	237596-2	•Ventilhylsa.....	•Valve sleeve.....	S		SEN UTF	1460
	1	1	-	-	237529-3	•Tätningring.....	•Seal ring.....	S		TID UTF	1480
51a	1	1	-	-	419568-1	•Tätningring.....	•Seal ring.....	S		(237510) SEN UTF.	1520
	1	1	-	-	237597-0	•Styrning.....	•Guide.....	S		SEN UTF	1540
52	1	-	1	-	237530-1	•Hållare.....	•Retainer.....	8			1560
53	-	1	-	1	237582-2	•Hållare.....	•Retainer.....	8			1580
	2	2	2	2	237531-9	•Skruv.....	•Screw.....	8			1600
54	1	-	1	-	237628-3	•Returfjäder.....	•Return spring.....			(237532)	1620
	-	1	-	1	237629-1	•Returfjäder.....	•Return spring.....			(237583)	1640
55	1	-	1	-	237584-8	•Hävarm.....	•Lever.....				1660
	-	1	-	1	237585-5	•Hävarm.....	•Lever.....				1680
55a	1	1	1	1	955225-8	•Skruv.....	•Screw.....	S			1700
56	1	1	1	1	237467-6	•Låsbricka.....	•Lock washer.....	S			1720
57	1	1	1	1	237468-4	•Mutter.....	•Nut.....	S			1740
58	1	-	1	-	237534-3	•Ventilationshus.....	•Ventilator housing.....				1760
	-	1	-	1	237535-0	•Ventilationshus.....	•Ventilator housing.....				1780
58a	1	1	-	-	237604-4	•Gummitätning.....	•Rubber seal.....				1800
58b	1	1	-	-	955894-1	•Bricka.....	•Washer.....				1820
59	1	-	1	-	237539-2	•Packning.....	•Packing.....	S			1840
	-	1	-	1	237540-0	•Packning.....	•Packing.....	S			1860
60	2	2	2	2	955918-8	•Fjäderbricka.....	•Spring washer.....	S			1880
61	2	2	2	2	237541-8	•Skruv.....	•Screw.....	S			1900
62	1	1	1	1	237404-9	•Vakuumpkammare.....	•Vacuum chamber.....				1920
63	1	1	1	1		•Kolv.....	•Piston.....	8			1940
64	1	1	1	1	237575-6	•Skruv.....	•Screw.....	S		ERS AV 1ST 237614-3,	1960
										1ST 237615-0.	2080
65	1	1	1	1	71816-3	•Fjäder.....	•Spring.....				2100
66	1	1	-	-	237550-9	•Bränslenål.....	•Jet needle.....				2120
	-	-	1	1	237620-0	•Bränslenål.....	•Jet needle.....			(237551)	2140
67	1	1	1	1	237405-6	•Fjäder.....	•Spring.....				2160
68	1	1	1	1	237576-4	•Styrning.....	•Guide.....	8		ERS AV 1ST 237614-3,	2180
										1ST 237615-0.	2200
69	1	1	1	1	237144-1	•Dämpare.....	•Damper.....				2220
70	1	1	1	1	190349-1	•Packning.....	•Packing.....				2240
71	1	1	1	1	237084-9	•Skruv.....	•Screw.....	S			2260
	-	-	-	-	276302-7	Reparationssats.....	Repair kit.....	S		(27)	2280
											2300

Sida Page		Grupp Group				Förgasare		Carburetter		Illustration		0850
74		2c								10899		
										1979-11		
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes		
	237 570	237 571										
1	1	-	-	-	237570-7	Förgasare, främre	Carburetter, forward	8		ERS AV 1ST 237623-4, 1ST 237626-7, 1ST 237586-3, 1ST 418646-6.	0020	
	-	1	-	-	237571-5	Förgasare, bakre	Carburetter, rear	8		ERS AV 1ST 237624-2, 1ST 237625-9, 1ST 237586-3.	0040 0060 0080 0100 0120 0140 0160	
2	1	1	-	-		•Hus	•Housing	8			0180	
2a	1	-	-	-	237568-1	•Propp	•Plug				0200	
3	1	1	-	-	237184-7	•Kil	•Key				220	
4	1	1	-	-	237185-4	•Skruv	•Screw				J240	
5	1	1	-	-		•Pinne	•Pin	8			0260	
6	1	1	-	-	237042-7	•Fjäder	•Spring	8			0280	
7	1	1	-	-		•Spärryttare	•Circlip	8			0300	
8	1	1	-	-	237490-8	•Lagerhylsa	•Bearing				0320	
9	1	1	-	-	237491-6	•Packning	•Packing	S			340	
10	1	1	-	-	237492-4	•Skruv	•Screw				360	
11	1	-	-	-	237499-9	•Munstycke	•Jet			ERS AV 1 ST 237592-1, 1 ST 237594-7.	0380	
	-	1	-	-	237499-9	•Munstycke	•Jet			ERS AV 1 ST 237593-9, 1 ST 237594-7.	0400 0420 0440 0460 0480 0500 0520 0540 0560 0580 0600 0620 0640 0660 0680 0700 0720 0740 760 780 0800 0820 0840 0860 0880 900 0920 0940 0960 0980 1000 1020 1040 1060 1080 1100 1120 1140 1160 1180 1200 1220 1240 1260	
12	1	1	-	-	237500-4	•Bimetallfjäder	•Bimetal, assy					
13	1	1	-	-	237501-2	•Fjäder	•Spring					
14	1	1	-	-	237502-0	•Skruv	•Screw					
15	1	1	-	-	237504-6	•O-ring	•O-ring	S				
16	1	1	-	-	237503-8	•Justerskruv	•Adjuster screw					
17	1	1	-	-		•Säte	•Seat	8				
18	1	1	-	-		•Nålventil	•Needle valve	8				
18a	1	1	-	-	237569-9	•Nålventil med säte	•Needle valve with seat	S				
x	1	-	-	-	237692-9	•Flottör	•Float			(237495)	0600	
x	-	1	-	-	237693-7	•Flottör	•Float			(237496)	0620	
20	1	1	-	-	237498-1	•Bricka	•Washer	S			0640	
21	1	1	-	-	237497-3	•Flottöraxel	•Spindle				0660	
22	1	1	-	-	237594-7	•Lock	•Cover				0680	
23	1	1	-	-	237506-1	•Gummiring	•Rubber ring	S			0700	
24	4	4	-	-	955918-8	•Fjäderbricka	•Spring washer	S			0720	
25	4	4	-	-	237507-9	•Skruv	•Screw	S			0740	
26	1	1	-	-	237508-7	•Spjällaxel	•Spindle				760	
27	1	1	-	-	237586-3	•Spjällskiva	•Throttle disc				780	
x	2	2	-	-	943781-5	•Skruv	•Screw	S		(71849)	0800	
29	2	2	-	-	419568-1	•Tätningring	•Seal ring	S		(237510)	0820	
30	1	-	-	-	237511-1	•Hävarm	•Lever				0840	
	-	1	-	-	237578-0	•Hävarm	•Lever				0860	
31	1	1	-	-	237513-7	•Justerskruv	•Adjuster screw				0880	
	1	1	-	-	237085-6	•Justerskruv	•Adjuster screw				900	
31a	1	1	-	-	71856-9	•Fjäder	•Spring				0920	
32	1	1	-	-	237514-5	•Distanshylsa	•Spacer sleeve				0940	
33	1	-	-	-	237602-8	•Returfjäder	•Spring			(237515)	0960	
	-	1	-	-	237603-6	•Returfjäder	•Return spring			(237516)	0980	
x	1	-	-	-	237464-3	•Hävarm	•Lever				1000	
	-	1	-	-	237517-8	•Hävarm	•Lever				1020	
35	1	1	-	-	237466-8	•Hävarm	•Lever				1040	
36	1	1	-	-	237465-0	•Bussning	•Bushing				1060	
37	1	1	-	-	237467-6	•Låsbricka	•Lock washer	S			1080	
38	1	1	-	-	237468-4	•Mutter	•Nut				1100	
39	1	1	-	-	237579-8	•Distansbricka	•Spacer washer	8			1120	
40	1	-	-	-	237519-4	•Hävarm	•Lever				1140	
	-	1	-	-	237520-2	•Hävarm	•Lever				1160	
41	1	1	-	-	237521-0	•Justerskruv	•Adjuster screw				1180	
42	1	1	-	-	237522-8	•Låsmutter	•Lock nut				1200	
43	1	1	-	-	237467-6	•Låsbricka	•Lock washer				1220	
44	1	1	-	-	237468-4	•Mutter	•Nut				1240	
45	1	1	-	-	237528-5	•Packning	•Packning	S			1260	