



VOLVO PARTS
1 021 10336



Sida	Grupp	Cylinderlock	Cylinder head	Illustration 10336	0250					
20	2a									
Page	Group			1975-01						
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	-	-	-	460902-0	Cylinderlock	Cylinder head		1) B20A. ERS AV 1 ST 462696-6, 1 ST 462743-6, 1 ST 955534-3, 1 ST 460322-1, 1 ST 418657-3, 1 ST 418655-7.	1010 1011 1012 1013 1014 1015 1016
	1	-	-	-	460801-4	Cylinderlock	Cylinder head		13) B20A. ERS AV 1 ST 462696-6, 1 ST 462743-6, 1 ST 955534-3. 14) B20A.	1017 1018 1019 1020
	1	-	-	-	462696-6	Cylinderlock	Cylinder head		B20B(498256-498259, 498065).	1022 1023
	1	-	-	-	460914-5	Cylinderlock	Cylinder head		B20B(498034-498037, 498051)	1025 1026
	1	-	-	-	462700-6	Cylinderlock	Cylinder head		B20E(498268-498271, 498288, 498289, 498066)	1030
	1	-	-	-	460805-5	Cylinderlock	Cylinder head		B20E(498038-498041, 498056, 498057, 498052)	1036
	1	-	-	-	460906-1	Cylinderlock	Cylinder head		B20F(498058, 498059, 498062, 498063, 498284, 498285, 498067)	1040 1042 1044
	1	-	-	-	460807-1	Cylinderlock	Cylinder head		B20F(498048, 498049, 498060, 498061, 498053)	1046 1048
	-	-	-	-	460908-7	Cylinderlock	Cylinder head			1050
2	4	-	-	-	419652-3	•Ventilstyrning, insugn	•Valve guide, intake	1		1060
	4	-	-	-	419653-1	•Ventilstyrning, utblåsn	•Valve guide, exhaust	1		1070
3	1	-	-	-	418466-9	•Vattenfördelningsrör	•Water distributor pipe			1080
4	2	-	-	-	418717-5	•Expansionsplugg	•Expander plug	1	D 35	1090
5	1	-	-	-	418718-3	•Expansionsplugg	•Expander plug	1	D 45	1100
6	3	-	-	-	950586-8	Styrpinne	Guide pin	0	B20E-F	1110
7	1	-	-	-	418213-5	Tätningssläns	Seal flange	3	B20A-B	1120
8	1	-	-	-	418214-3	Packning	Gasket	S	B20A-B	1130
9	2	-	-	-	955512-9	Skruv	Screw	0	B20A-B	1140
10	2	-	-	-	941906-0	Fjädrande bricka	Resilient washer	0		1150
11	4	-	-	-	419766-1	Insugningsventil	Inlet valve	1		1160
12	4	-	-	-	419640-8	Avgasventil	Exhaust valve	1	B20A-B	1170
	4	-	-	-	419735-6	Avgasventil	Exhaust valve	1	B20E-F	1180
13	8	-	-	-	418737-3	Ventilfjäder	Valve spring	1		1190
14	8	-	-	-	419644-0	Bricka	Washer	1		1200
15	16	-	-	-	419643-2	Lås	Lock	1		1210
16	8	-	-	-	419702-6	Ventiltätning	Valve seal	S		1220
17	4	-	-	-	418206-9	Lagerbock	Bearing bracket			1230
18	4	-	-	-	191689-9	Skruv	Screw	0		1240
19	1	-	-	-	418305-9	Vipparmsaxel	Rocker arm shaft	4		1250
20	2	-	-	-	955083-1	•Hattplugg	•Plug			1260
21	4	-	-	-	418301-8	Vipparm	Rocker arm	3	NR 1,3,5,7	1270
22	4	-	-	-	418298-6	Vipparm	Rocker arm	3	NR 2,4,6,8	1280
23	8	-	-	-	418297-8	•Bussning	•Bushing	1		1290
24	8	-	-	-	418286-1	•Kulbult	•Ball stud	3		1300
25	8	-	-	-	921781-1	•Mutter	•Nut	0		1310
26	3	-	-	-	418426-3	Fjäder	Spring	4		1320
27	2	-	-	-	411140-7	Fjäder	Spring	4		1330
28	2	-	-	-	914456-9	Låsring	Circlip	S		

1. B20A (498250) MO-101587. B20A (498251) MO-10626. B20A (498252) MO-10689. B20A (498253) MO -7000 B20A (498064) MO-210.
13. B20A(498250) MO 101588-. B20A(498251) MO 10627-. B20A(498252) MO 10690-. B20A(498253) MO 7001-. B20A(498064) MO 211-.
14. B20A(498030-498033, 498050).