



VOLVO PARTS
 1 040 10436

Sida	Grupp	Växellåda	Gearbox	Illustration 10436	0900				
56	4	BW35, RV	BW35, RV						
Page	Group			1975-12					
Pos. Fig.	Antal/Quantity			Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	254 535	254 636	254 658						
1	1	-	-	254535-8	Växellåda	Gearbox	4		1010
	-	1	-	254636-4	Växellåda	Gearbox	4		1020
	-	-	1	254658-8	Växellåda	Gearbox	4		1030
2	1	-	-	235872-9	•Konverter	•Converter	4	(235809)	1040
	-	1	1	235880-2	•Konverter	•Converter	4		1050
3	1	1	1	235813-3	•Konverterkåpa	•Converter housing			1060
4	1	1	1	235814-1	•Skyddsnet	•Stone guard			1070
5	6	6	6	940135-7	•Skruv	•Screw	0		1080
6	6	6	6	955921-2	•Fjäderbricka	•Spring washer	0		1090
7	1	1	1		•Hus med planetväxel	•Planet cover			1100
	-	-	-		••Det sida 64 , 2-C19	••Comps. page 64 , 2-C19			1105
8	1	-	-	235727-5	•Bakre gavel	•Extension housing	4		1110
	-	1	1	235922-2	•Bakre gavel	•Extension housing	4		1120
9	1	1	1	235728-3	••Tätningring	••Seal ring	S		1130
10	1	-	-		•Packning	•Gasket	8		1140
	-	1	1		•Packning	•Gasket	8		1150
11	4	-	-	955525-1	•Skruv	•Screw	0		1160
	-	4	4	235918-0	•Skruv	•Screw	0		1170
12	4	-	-	955921-2	•Fjäderbricka	•Spring washer	0		1180
	-	4	4	940110-0	•Fjäderbricka	•Spring washer	0		1190
13	1	-	-	235828-1	•Kontrollsystem	•Valve bodies	4	MÄRKT 90.ERS AV	1200
	1	-	1	235854-7	•Kontrollsystem	•Valve bodies	4	1 ST 235854-7	1210
	-	1	-	235935-4	•Kontrollsystem	•Valve bodies	4	MÄRKT 112	1220
	-	-	-		••Det sida 80 , 2-D11	••Comps. page 80 , 2-D11			1230
14	1	1	1	940117-5	•Skruv	•Screw	0	L 1 1/4 TUM	1240
15	1	1	1	955920-4	•Fjäderbricka	•Spring washer	0		1250
16	2	2	2	955516-0	•Skruv	•Screw	0	L 2 TUM	1260
17	2	2	2	955920-4	•Fjäderbricka	•Spring washer	0		1270
18	1	1	1	235705-1	•Inloppsrör, främre pump	•Tube, front pump	3		1280
19	1	1	1	235527-9	•O-ring	•O-ring	S		1290
20	1	1	1	235704-4	•Utloppsrör, främre pump	•Tube, front pump	3		1300
21	1	1	1	235706-9	•Inloppsrör, konverter	•Tube, converter	3		1310
22	1	1	1	235848-9	•Utloppsrör, konverter	•Tube, converter	3		1320
23	1	1	1	235701-0	•Rör, främre servo	•Tube, front servo	3		1330
24	1	1	-	235702-8	•Rör, främre servo	•Tube, front servo	3	VXL 254535, -5EN 1828	1340
	1	-	1	235853-9	•Rör, främre servo	•Tube, front servo	3	VXL 254535, 5EN 1829-	1350
25	1	1	1	235703-6	•Rör, bakre koppling	•Tube, rear clutch	3		1360
26	1	1	1	235707-7	•Rör, bakre servo	•Tube, rear servo	3		1370
27	1	1	1	682295-1	•Reglagewire	•Cable	2		1380
27a	1	1	1	1220513-4	•Kabelstopp	•Cable stop			1395
28	1	1	1	235812-5	•Packning	•Packing	1		1400
29	1	-	-		•Kam	•Cam		SE SIDA 80, 2-D11	1410
30	1	1	1	1220509-2	•Startspärr- och backljuskontakt	•Inhibitor- and backlamp switch		(235512)	1420
31	1	1	1	941442-6	•Mutter	•Nut	0	TID. UTF.	1425
31a	1	1	1	235812-5	•Packning	•Packing		SEN. UTF.	1430
32	1	-	1	235808-3	•Axel	•Manual valve lever shaft	4		1445
	-	1	-	235907-3	•Axel	•Manual valve lever shaft	4		1450
33	1	-	1	235711-9	•Fjäder	•Spring	3		1460
34	1	1	1	235836-4	•Hävarm	•Manual valve lever	4		1470
35	1	-	-	235710-1	•Fjädrande rörpinne	•Resilient tubular pin	3		1480
	-	1	1	235845-5	•Cylindrisk pinne	•Straight pin	3		1490
36	1	-	1	235712-7	•Ring	•Collar			1500
37	1	-	1	235713-5	•Låspinne	•Slotted spring pin	3		1510
37a	-	1	-	235927-1	•Låspinne	•Lock pin	3		1520
37b	-	1	-	235928-9	•Låsring	•Snap ring	3		1530
37c	-	1	-	235783-8	•Hattplugg	•Plug	3		1540
38	-	-	-		•Tätningring	•Seal ring		SE SIDA 64, 2-C19	1550
39	1	1	1	60309-2	•Kula	•Ball	3		1560
40	1	1	1	235714-3	•Fjäder	•Spring	3		1570
41	1	1	1	235827-3	•Dragstång	•Linkage rod	4		1580
42	1	1	1	235826-5	•Hävarm	•Torsion lever	4		1590



Sida		Grupp		Växellåda		Gearbox		Illustration 10436		0900
58		4		BW35, RV		BW35, RV				
Page		Group						1975-12		
Pos. Fig.	Antal/Quantity			Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes		
	254 535	254 636	254 658							
43	1	1	1	235652-5	•Fjäder	•Toggle lever spring	3		2010	
44	-	-	-		•Lagertapp	•Pivot pin		SE SIDA 64, 2-C19	2020	
45	1	1	1	41561-2	•Bricka	•Washer			2030	
46	1	1	1	235654-1	•Låsfjäder	•Retaining spring	3		2040	
47	1	1	1	235651-7	•Hävarm	•Toggle lift lever	4		2050	
48	1	1	1	235641-8	•Hänke	•Toggle link	3		2060	
49	1	1	1	235640-0	•Hävarm	•Pawl	4		2070	
50	1	1	1	235642-6	•Tapp	•Pin	3		2080	
51	1	1	1	235643-4	•Hävarm	•Toggle lever	4		2090	
52	1	1	1	235792-9	•Tapp	•Pin	3		2100	
53	1	1	1	235793-7	•Fjäder	•Release spring	3		2110	
54	1	1	1	235648-3	•Lagertapp	•Toggle pin	4		2120	
55	1	1	1	235649-1	•O-ring	•O-ring	S		2130	
56	1	1	1	235650-9	•Pinne	•Anchor pin	4		2140	
57	1	1	1	951956-2	•Låspinne	•Slotted spring pin	0		2150	
58	1	-	-	235715-0	•Oljesump	•Oil pan	4	TID UTFERS AV 1 ST 235857-0, 1 ST 235859-6, 1 ST 235858-8	2160	
	1	-	-	235857-0	•Oljesump	•Oil pan	4	SE UTF	2170	
	-	1	1	235857-0	•Oljesump	•Oil pan	4		2180	
59	1	1	1	235739-0	•Magnet	•Magnet	S	(235716)	2190	
60	1	1	1	276502-2	•Packning	•Gasket	0		2200	
61	15	15	15	955523-6	•Skruv	•Screw	0		2210	
62	15	15	15	955921-2	•Fjäderbricka	•Spring washer	0		2220	
63	1	-	-	952075-0	•Avtappningspropp	•Drain plug	0	5)	2230	
64	1	-	-	235859-6	•Avtappningspropp	•Drain plug	1	6)	2240	
	-	1	1	235859-6	•Avtappningspropp	•Drain plug	1		2250	
65	1	-	-	235858-8	•Packning	•Packing	1	6)	2260	
	-	1	1	235858-8	•Packning	•Packing	1		2270	
	1	-	-	276501-4	Gummi- och tätningssats	Rubber and seal ring kit	2		2280	
	-	1	-	273291-5	Gummi- och tätningssats	Rubber and seal ring kit	1		2290	
	1	-	-	276502-2	Packningssats	Gasket kit	1		2300	
	-	1	1	273221-2	Packningssats	Gasket kit	1		2310	
	-	1	1	273221-2	Packningssats	Gasket kit	1		2312	
	-	1	1	273221-2	Packningssats	Gasket kit	1		2315	
	-	1	1	273221-2	Packningssats	Gasket kit	1		2320	
	-	1	1	273221-2	Packningssats	Gasket kit	1		2330	

5. För oljesump 235715. For oil sump 235715. Pour carter d'huile 235715. Für Ölwanne 235715. Para carter de aceite 235715.
6. För oljesump 235857. For oil sump 235857. Pour carter d'huile 235857. Für Ölwanne 235857. Para carter de aceite 235857.