



VOLVO PARTS  
 1040 14023  
 (10961)

Sida	Grupp	Koppling, kopplingsmanövrering			Clutch, clutch linkage		Illustration 14023	0150		
Page	6	4			M400, M410	M400, M410				
		Group			HST	RHD	1975-12			
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	-	-	-	430123-0	Koppling .....	Clutch .....	2		1010
2	1	-	-	-	430124-8	Lamell .....	Plate .....		B30A ERS AV 1 ST	1015
	1	-	-	-	461134-9	Lamell .....	Plate .....		461134-9	1016
	1	-	-	-	461314-7	Lamell .....	Plate .....		B30A	1020
2a	1	-	-	-	275919-9	•Lamellbeläggsats för .....	•Clutch facing kit for .....		B30E,F	1030
	1	-	-	-	430124		430124		B30A	1040
	1	-	-	-	275930-6	•Lamellbeläggsats för .....	•Clutch facing kit for .....		B30A	1045
	1	-	-	-	461134		461134			1048
	1	-	-	-	275931-4	•Lamellbeläggsats .....	•Clutch facing kit .....		B30E,F	1050
3	2	-	-	-		••Belägg .....	••Facing .....	S		1055
4	36	-	-	-		••Nit .....	••Rivet .....	S		1060
5	6	-	-	-	940135-7	Skruv .....	Screw .....		5/16 UNC-22 CH-105845,	1070
	6	-	-	-	955296-9	Skruv .....	Screw .....		EXCL 103274-104323, 104420-105815.	1081
	6	-	-	-	955296-9	Skruv .....	Screw .....		M8-22 CH 105846- INCL 103274-104323, 104420-105815.	1082
6	1	-	-	-	679149-5	Kopplingspedal .....	Clutch pedal .....			1083
7	2	-	-	-	675555-7	Bussning .....	Bushing .....	3		1084
8	1	-	-	-	676526-7	Axel .....	Shaft .....			1085
9	1	-	-	-	940156-3	Skruv .....	Bolt .....	0		1100
10	1	-	-	-	950364-0	Mutter .....	Nut .....	0		1110
11	1	-	-	-	675529-2	Returfjäder .....	Return spring .....	3		1120
12	1	-	-	-	679925-8	Konsol .....	Bracket .....			1130
13	1	-	-	-	677198-4	Pedalstopp .....	Pedal stop .....	3		1140
14	1	-	-	-	942624-8	Flänsskruv .....	Flanged screw .....		(955523)	1150
15	1	-	-	-	955894-1	Bricka .....	Washer .....		TID UTF	1160
16	1	-	-	-	941907-8	Fjädrande bricka .....	Resilient washer .....		TID UTF	1170
17	1	-	-	-	955826-3	Mutter .....	Nut .....	0		1180
18	1	-	-	-	666176-3	Gummiskoning .....	Rubber pad .....	2		1190
19	1	-	-	-		Pedalkåpa .....	Pedal casing .....		SE GRUPP 5	1200
20	1	-	-	-	679154-5	Huvudcylinder .....	Master cylinder .....		CH-28593	1210
20a	1	-	-	-	687465-5	Huvudcylinder .....	Master cylinder .....		ERS AV 687465-5	1220
	2	-	-	-		•Det sida 10, 2-A13 .....	•Comps. page 10, 2-A13 .....		CH 28594-	1230
21	2	-	-	-	940135-7	Skruv .....	Screw .....	0		1240
22	2	-	-	-	941907-8	Fjädrande bricka .....	Resilient washer .....	0		1250
23	1	-	-	-		Tryckstång .....	Push rod .....		SE SIDA 10, 2-A13	1260
24	1	-	-	-	955847-9	Mutter .....	Nut .....	0	CH-28593	1270
25	1	-	-	-	913128-5	Saxpinnebult .....	Clevis pin .....	0	CH-63406 ERS AV	1280
	1	-	-	-	907824-7	Saxpinne .....	Split pin .....	0	1 ST 943546 1 ST 950363	1290
26a	1	-	-	-	943456-4	Skruv .....	Skruv .....		CH-63406	1300
26b	1	-	-	-	950363-2	Mutter .....	Nut .....		CH 63407-	1304
27	1	-	-	-	663418-2	Behållare .....	Container .....	3	CH 63407-	1310
28	1	-	-	-	663417-4	Klammer .....	Clamp .....		CH-28593	1315
29	1	-	-	-	950038-0	Skruv .....	Bolt .....	0	CH-28593	1320
30	1	-	-	-	940145-6	Mutter .....	Nut .....	0	CH-28593	1330
31	2	-	-	-	955138-3	Skruv .....	Screw .....	0	CH-28593	1340
32	1	-	-	-	679867-2	Konsol .....	Bracket .....		CH-28593	1350
33	4	-	-	-	955138-3	Skruv .....	Screw .....	0	CH-28593	1360
34	70MM	-	-	-	952956-1	Gummislang .....	Rubber hose .....	2	CH-28593	1370
35	1	-	-	-	190784-9	Förskruvning .....	Screw union .....	0		1380
36	1	-	-	-	18651-0	Packning .....	Packing .....	0		1390
37	1510	-	-	-	954314-1	Bundyrör .....	Bundypiping .....	0		1400
38	1	-	-	-	80940-0	Förskruvningsmutter .....	Union nut .....	0		1410
39	1	-	-	-	954321-6	Överfallsmutter .....	Cap nut .....	0		1420
40	3	-	-	-	951188-2	Klammer .....	Clamp .....	0		1430
41	3	-	-	-	955140-9	Skruv .....	Screw .....	0		1440
42	1	-	-	-	681084-0	Konsol .....	Bracket .....			1450
43	1	-	-	-	665254-9	Gummislang .....	Rubber hose .....	1		1460
44	1	-	-	-	940147-2	Låsbricka .....	Lock washer .....	0		1470