



VOLVO PARTS
1 023 15009

Sida	Grupp	Bränslesystem			Fuel system		Illustration 15009	0150		
10	2c	insprutningsmotor			fuel injection engine					
Page	Group						1975-12			
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	-	-	-		Bensintank	Fuel tank	CH - 102949		0020
2	-	-	-	-		Bränslepump, bränsle- filter med monterings- detaljer	Fuel pump, fuel filter with installation components	SE SIDA 22, 1-E05 CH - 102949		0040 0060
3	-	-	-	-		Avdunstningskontroll	Gas evaporite	SE SIDA 18, 1-E01		0080 0100
4	1	-	-	-		Bränslerör	Fuel pipe	CH - 102949		0120
	-	-	-	-		BRÄNSLERÖR MED MONTERINGSDETALJER	FUEL PIPE WITH IN- STALLATION COMPONENTS	SE SIDA 22, 1-E05 CH - 79525 SE SIDA 18, 1-E01		0140 0160 0180
5	2570	-	-	-	941354-3	•Bundyrör	•Bundy piping	CH - 102949		0200
	1840	-	-	-	941354-3	•Bundyrör	•Bundy piping	CH - 74449		0240
6	110	-	-	-	947831-4	•Bränsleslang	•Fuel hose	CH 74450-		0280
7	4	-	-	-	945652-6	•Slangklammer	•Hose clamp			0280
8	1250	-	-	-	941354-3	•Bundyrör	•Bundy piping			0300
9	1550	-	-	-	941354-3	•Bundyrör	•Bundy piping			0320
10	110	-	-	-	947831-4	•Bränsleslang	•Fuel hose			0340
11	2100	-	-	-	941354-3	•Bundyrör	•Bundy piping			0360
12	1	-	-	-	954322-4	•Överfallsmutter	•Cap nut			0380
13	1	-	-	-	954343-0	•Vinkelnippel	•Elbow nipple			0400
14	1	-	-	-		Bensintank	Fuel tank	CH 102950-		0420
15	-	-	-	-		Bränslepump, bränsle- filter med monterings- detaljer	Fuel pump, fuel filter with installation components	SE SIDA 26, 1-E09 CH 102950-		0440 0460
16	-	-	-	-		Avdunstningskontroll	Gas evaporite	SE SIDA 20, 1-E03		0480 0500
	-	-	-	-		BRÄNSLERÖR MED MONTERINGSDETALJER	FUEL PIPE WITH IN- STALLATION COMPONENTS	CH 102950-		0520
17	360	-	-	-	947831-4	•Bränsleslang	•Fuel hose	CH 102950-122560		0540 0560 0580
	205	-	-	-	947831-4	•Bränsleslang	•Fuel hose			0620
18	1660	-	-	-	941354-3	•Bundyrör	•Bundy piping	CH - 112881		0640
19	110	-	-	-	947831-4	•Bränsleslang	•Fuel hose	CH 112882-		0660
20	4	-	-	-	945652-6	•Slangklammer	•Hose clamp			0680
21	1250	-	-	-	941354-3	•Bundyrör	•Bundy piping			0700
22	1550	-	-	-	941354-3	•Bundyrör	•Bundy piping			0720
23	110	-	-	-	947831-4	•Bränsleslang	•Fuel hose			0740
24	1660	-	-	-	941354-3	•Bundyrör	•Bundy piping			0760
25	350	-	-	-	947831-4	•Bränsleslang	•Fuel hose			0780
26	ERF	-	-	-	945652-6	•Slangklammer	•Hose clamp			0800
	-	-	-	-		BRÄNSLERÖR MED MONTERINGSDETALJER	FUEL PIPE WITH IN- STALLATION COMPONENTS	CH 122561-		0820
27	205	-	-	-	947831-4	•Bränsleslang	•Fuel hose	CH - 132566		0840
	130	-	-	-	947831-4	•Bränsleslang	•Fuel hose	CH 132567-		0880
28	2840	-	-	-	941354-3	•Bundyrör	•Bundy piping	CH - 132566		0900
	2850	-	-	-	946234-2	•Plaströr	•Plastic piping	CH 132567-		0920
28a	2	-	-	-	947441-2	•Nippel	•Nipple	CH 132567-		0940
29	1550	-	-	-	941354-3	•Bundyrör	•Bundy piping	CH - 132566		0960
30	110	-	-	-	947831-4	•Bränsleslang	•Fuel hose	CH - 132566		0980
31	2	-	-	-	945652-6	•Slangklammer	•Hose clamp	CH - 132566		1000
32	1660	-	-	-	941354-3	•Bundyrör	•Bundy piping	CH - 132566		1020
33	3100	-	-	-	946234-2	•Plaströr	•Plastic piping	CH 132567-		1040
33a	2	-	-	-	947441-2	•Nippel	•Nipple	CH 132567-		1060
34	350	-	-	-	947831-4	•Bränsleslang	•Fuel hose	CH - 132566		1080
	400	-	-	-	947831-4	•Bränsleslang	•Fuel hose	CH 132567-		1100
35	ERF	-	-	-	945652-6	•Slangklammer	•Hose clamp			1200
36	ERF	-	-	-	952624-5	Klammer	Clamp			1220
37	ERF	-	-	-	677980-5	Klammer	Clamp			1240
38	ERF	-	-	-	1221990-3	Klammer	Clamp	D8 X D6,4		1260
	ERF	-	-	-	1221991-1	Klammer	Clamp	D8 X D8		1280
39	ERF	-	-	-	960862-1	Skruv	Screw	L 9,5		1300
	ERF	-	-	-	190665-0	Skruv	Screw	L 13		



Sida	Grupp	Bränslesystem	Fuel system	Illustration 15009	0150					
12	2c	insprutningsmotor	fuel injection engine							
Page	Group			1975-12						
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
40	ERF	-	-	-	960863-9	Skruv	Screw	L 22		1320
	ERF	-	-	-	940090-4	Fjäderbricka	Spring washer			1340
41	770	-	-	-	947831-4	Bränsleslang	Fuel hose	CH-132566		1360
	635	-	-	-	947831-4	Bränsleslang	Fuel hose	CH 132567-		1380
42	1065	-	-	-	947831-4	Bränsleslang	Fuel hose	CH-132566		1400
	910	-	-	-	947831-4	Bränsleslang	Fuel hose	CH 132567-		1420
43	4	-	-	-	945652-6	Slangklammer	Hose clamp			1440
44	1	-	-	-	460498-9	Konsol	Bracket	CH-132566		1460
45	2	-	-	-	461621-5	Konsol	Bracket			1480
46	2	-	-	-	460500-2	Klammer	Clamp			1500
47	1	-	-	-	243129-4	Tryckregulator	Pressure regulator	11)		1520
	1	-	-	-	461395-6	Tryckregulator	Pressure regulator	12)		1540
48	96MM	-	-	-	947831-4	Bränsleslang	Fuel hose	2 STL 48		1560
49	4	-	-	-	945652-6	Slangklammer	Hose clamp			1580
50	1	-	-	-	461052-3	Bränslerör	Fuel pipe			1600
51	6	-	-	-	419755-4	Hållare	Retainer			1620
52	6	-	-	-	956570-6	Skruv	Screw			1640
53	6	-	-	-	941907-8	Fjädrande bricka	Resilient washer			1660
54	6	-	-	-	960218-6	O-ring (utan fiber- bricka. se pos 55)	O-ring (without fibre washer. see fig 55)	TID UTF. ERS AV 1 ST 960168-3, 2 ST 962658-1. SEN UTF		1680
	6	-	-	-	960168-3	O-ring (med fiber- bricka. se pos 55)	O-ring (with fibre washer. see fig 55)			1700
55	12	-	-	-	962658-1	Fiberbricka	Fibre washer	SEN UTF		1720
56	6	-	-	-	241720-2	Insprutningsventil	Fuel injector	18) ERS AV 1 ST 461585-2, 1 ST 945651-8, 1 ST 461611-6. 19) ERS AV 1 ST 461585-2, 1 ST 461611-6. 20) (461585)		1740
	6	-	-	-	462645-3	Insprutningsventil	Fuel injector	18) ERS AV 1 ST 461585-2, 1 ST 461611-6. 19) ERS AV 1 ST 461585-2, 1 ST 461611-6. 20) (461585)		1760
x 58	6	-	-	-	461674-4	Insprutningsventil	Fuel injector	18, 19) DI 7,6 MM		1780
59	6	-	-	-	419785-1	Tätningring för 241720 och 462645	Seal ring for 241720 and 462645	20) DI 8,6 MM		1800
	6	-	-	-	461611-6	Tätningring för 461585	Seal ring for 461585			1820
60	6	-	-	-	419784-4	Tätningring	Seal ring	S		1840
61	6	-	-	-	419795-0	Bricka	Washer			1860
62	6	-	-	-	419783-6	Låsring	Lock ring			1880
63	6	-	-	-	945650-0	Slangklammer för 241720	Hose clamp for 241720	18) M-12		1900
	6	-	-	-	945651-8	Slangklammer för 462645 och 461585	Hose clamp for 462645 and 461585	19, 20) M-13		1920
63a	3	-	-	-	1218622-7	Servicesats	Service kit			2000
63b	6	-	-	-		•Slang	•Hose	S		2020
63c	12	-	-	-	948061-7	•Slangklammer	•Hose clamp	S		2040
64	1	-	-	-		Insugningsrör	Induction manifold	SE GRUPP 2A		2060
65	1	-	-	-	461190-1	Spjällhus	Throttle housing	CH-74449		2080
	1	-	-	-	461354-3	Spjällhus	Throttle housing	CH 74450-		2100
66	2	-	-	-	943912-6	•Bussning	•Bushing			2120
67	3	-	-	-	953465-2	Pinnskruv	Stud			2140
68	1	-	-	-	461055-6	Packning	Packing	S		2160
69	3	-	-	-	941907-8	Fjädrande bricka	Resilient washer			2180
70	3	-	-	-	955826-3	Mutter	Nut			2200
71	1	-	-	-	945435-6	O-ring	O-ring	S		2220
72	1	-	-	-	461191-9	Spjällaxel	Throttle shaft			2240

11. B30E(498102) Mo -3755. B30E(498103) Mo -4799. B30F(498100) Mo -4373. B30F(498101) Mo -10789.
 12. B30E (498102) MO 3756-. B30E (498103) MO 4800-. B30E (498166, 498167). B30F (498100) MO 4374-. B30F (498101) MO 10790-. B30F (498164, 498165).
 18. B30E(498102) MO -4573, B30E(498103) MO -6805, B30E(498110) MO -292, B30E(498111) MO -197, B30F(498100) MO -5573, B30F(498101) MO -16146.
 19. B30E(498102) MO 4574-, B30E(498103) MO 6806-, B30E(498110) MO 293-, B30E(498111) MO 198-, B30E(498166) MO -784, B30E(498167) MO -1833. B30F(498100) MO 5574-, B30F(498101) MO 16147-, B30F(498164) MO -629, B30F(498165) MO -4238.
 20. B30E(498166) MO 785-, B30E(498167) MO 1834-, B30E(498169, 498173, 498174), B30F(498164) MO 630-, B30F(498165) MO 4239-, B30F(498170, 498245, 498246, 498247, 498248).



Sida	Grupp	Bränslesystem	Fuel system	Illustration 15009	0150					
14	2c	insprutningsmotor	fuel injection engine							
Page	Group			1975-12						
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
73	1	-	-	-	461192-7	Spjällskiva	Throttle disc		B30E CH - 94817. B30F	2420
	1	-	-	-	461410-3	Spjällskiva	Throttle disc		B30E CH 94818 -	2440
74	2	-	-	-	71849-4	Skruv	Screw		(943781)	2460
75	1	-	-	-	18696-5	Mellanlägg	Spacer			2480
76	1	-	-	-	951669-1	Spärryttare	Circlip			2500
77	1	-	-	-	944208-8	Filtring	Felt ring	S		2520
78	1	-	-	-	461560-5	Spjällkontakt	Throttle valve switch		(243366)	2540
79	2	-	-	-	956059-0	Skruv	Screw			2560
80	2	-	-	-	955891-7	Bricka	Washer			2580
81	1	-	-	-	461629-8	Kallstartventil	Cold start valve		(243363)	2600
82	1	-	-	-	419831-3	Packning	Packing			2620
83	2	-	-	-	950032-3	Skruv	Screw			2640
84	3	-	-	-	461189-3	Klammer	Clamp			2660
85	3	-	-	-	940100-1	Skruv	Screw			2680
86	3	-	-	-	960140-2	Bricka	Washer			2700
87	510	-	-	-	947831-4	Bränsleslang	Fuel hose			2720
88	2	-	-	-	945652-6	Slangklammer	Hose clamp			2740
89	1	-	-	-	946405-8	Klammer	Clamp			2760
90	1	-	-	-	944560-2	Nippel	Nipple		CH - 132566	2780
	1	-	-	-	948489-0	Nippel	Nipple		CH 132567 -	2790
91	270	-	-	-	947831-4	Bränsleslang	Fuel hose			2800
92	2	-	-	-	945652-6	Slangklammer	Hose clamp			2820
93	1	-	-	-	243183-1	Tryckgivare	Pressure sensor		B30E CH - 132566.	2840
	1	-	-	-	243316-7	Tryckgivare	Pressure sensor		B30F URA CH - 132566.	2860
	1	-	-	-	460835-2	Tryckgivare	Pressure sensor		B30F MRA CH - 102949.	2880
	1	-	-	-	460835-2	Tryckgivare	Pressure sensor		B30F MRA CH 102950 -	2900
	1	-	-	-					132566. EXCL CALIF.	2920
	1	-	-	-	462567-9	Tryckgivare	Pressure sensor		B30F MRA CALIF CH	2940
	1	-	-	-	461583-7	Tryckgivare	Pressure sensor		102950 - 132566.	2960
	-	-	-	-	243316-7	Tryckgivare	Pressure sensor		USA, CAN VXL BW35	2980
	-	-	-	-					CH 132567 -	2981
	-	-	-	-	461666-0	Tryckgivare	Pressure sensor		JAPAN VXL BW35	2982
	-	-	-	-					CH 132567 -	2983
	-	-	-	-	461666-0	Tryckgivare	Pressure sensor		VXL M410 CH 132567 -	2984
94	3	-	-	-	955138-3	Skruv	Screw			3000
95	1	-	-	-	461559-7	Tillsatsluftslid	Auxiliary air slide		CH - 132566.	3020
96	1	-	-	-	419894-1	Packning	Gasket		CH - 132566.	3040
97	2	-	-	-	956554-0	Skruv	Screw		CH - 132566.	3060
98	2	-	-	-	941906-0	Fjädrande bricka	Resilient washer		CH - 132566.	3080
99	1	-	-	-	461234-7	Gummislang	Rubber hose		CH - 132566.	3100
100	1	-	-	-	461234-7	Gummislang	Rubber hose		CH - 132566.	3120
101	2	-	-	-	943473-9	Slangklammer	Hose clamp		CH - 132566.	3140
102	1	-	-	-	461214-9	Ventilhus	Valve housing		CH - 132566.	3160
103	1	-	-	-	461223-0	Fjäder	Spring		CH - 132566.	3180
104	1	-	-	-	461222-2	Skruv	Screw		CH - 132566.	3200
105	1	-	-	-	237568-1	Plugg	Plug		UAC. CH - 132566.	3220
106	330	-	-	-	192358-0	Gummislang	Rubber hose		URA CH - 132566.	3240
107	1	-	-	-	943473-9	Slangklammer	Hose clip		URA CH - 132566	3260
108	4	-	-	-	943473-9	Slangklammer	Hose clip		MRA CH - 102949.	3280
109	130	-	-	-	192358-0	Gummislang	Rubber hose		MRA CH - 102949.2X65	3300
110	1	-	-	-		Anslutningsrör	Union manifold		MRA CH - 102949.	3320
									SE SIDA 44, 1-F03	3340
111	1	-	-	-		Anslutningsrör	Union manifold		MRA CH 102950 - 132566.	3360
									SE SIDA 48, 1-F07	3380
112	1	-	-	-	461445-9	Tätningring	Seal ring		MRA CH 102950 - 132566.	3400
113	130	-	-	-	192358-0	Gummislang	Rubber hose		MRA CH 102950 -	3420
114	2	-	-	-	943473-9	Slangklammer	Hose clip		MRA CH 102950 -	3440
115	340	-	-	-	192055-2	Slang	Hose		MRA	3460
116	1	-	-	-	418646-6	Plugg	Plug		URA	3480
117	1	-	-	-	461233-9	Gummislang	Rubber hose		CH - 132566	3500
118	1	-	-	-	241810-1	Temperaturgivare	Temperature sender			3520
119	1	-	-	-	955782-8	Mutter	Nut			3540
120	1	-	-	-	241726-9	Temperaturgivare	Temperature sender			3560



Sida	Grupp	Bränslesystem	Fuel system	Illustration 15009	0150					
16	2c	insprutningsmotor	fuel injection engine							
Page	Group				1975-12					
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
121	1	-	-	-	957173-8	Packning	Packing	S		3580
122	1	-	-	-	243126-0	Styrenhet	Control unit		CH - 102949	3600
	1	-	-	-	243126-0	Styrenhet	Control unit		CH 102950 - 132566	3620
	1	-	-	-	462568-7	Styrenhet	Control unit		EXCL B30F BW35 CALIF.	3640
	1	-	-	-	461503-5	Styrenhet	Control unit		B30F BW35 CALIF CH	3660
	1	-	-	-	243126-0	Styrenhet	Control unit		102950 - 132566.	3680
	1	-	-	-	461503-5	Styrenhet	Control unit		CH 132567 - EXCL JAPAN	3700
122a	2	-	-	-	190665-0	Skruv	Screw		JAPAN CH 132567 -	3710
122b	2	-	-	-	192292-1	Bricka	Washer			3715
122c	2	-	-	-	191391-2	Fjädermutter	Spring nut			3716
123	1	-	-	-	688955-4	Skyddsplåt	Backing plate		CH - 102949	3717
	1	-	-	-	1207723-6	Skyddsplåt	Backing plate		CH 102950 - 132567	3720
	1	-	-	-	1203466-6	Konsol	Bracket		USA,CAN	3760
124	6	-	-	-	190666-8	Skruv	Screw		CH - 132566	3780
	4	-	-	-	955137-5	Skruv	Screw		USA,CAN	3800
125	6	-	-	-	955893-3	Bricka	Washer			3820
126	-	-	-	-		Reläer	Relays		SE GRUPP 3	3840
127	1	-	-	-	686224-7	Luftfilter	Air filter			3860
128	1	-	-	-	461177-8	•Filterinsats	•Filter insert			3900
129	1	-	-	-	686240-3	Slang	Hose			3920
130	1	-	-	-	673647-4	Luftintag	Air intake			3940
131	1	-	-	-	951798-8	Slangklammer	Hose clamp			3960
132	1	-	-	-	243130-2	Termostidgivare	Thermal - time sensor			3980
133	1	-	-	-	957178-7	Packning	Packing			4000
134	1	-	-	-	461627-2	Tillsatsluftslid	Auxiliary air slide		CH 132567 -	4020
135	2	-	-	-	950046-3	Skruv	Screw		CH 132567 - 135452. L 16	4030
	2	-	-	-	950048-9	Skruv	Screw		CH 135453 - . L 22	4040
136	2	-	-	-	941906-0	Fjädrande bricka	Resilient washer		CH 132567 -	4060
137	1	-	-	-	461497-0	Gummislang	Rubber hose		CH 132567 -	4080
138	1	-	-	-	461496-2	T - stycke	T - union		CH 132567 -	4100
139	1	-	-	-	461497-0	Gummislang	Rubber hose		CH 132567 -	4120
140	110	-	-	-	942390-6	Gummislang	Rubber hose		CH 132567 -	4140
141	1	-	-	-	461497-0	Gummislang	Rubber hose		CH 132567 -	4160
142	1	-	-	-	461495-4	Ventilhus	Valve housing		CH 132567 -	4180
143	1	-	-	-	461223-0	Fjäder	Spring		CH 132567 -	4200
144	1	-	-	-	461222-2	Skruv	Screw		CH 132567 -	4220
145	1	-	-	-	237568-1	Plugg	Plug		UAC CH 132567 -	4240
146	50MM	-	-	-	192358-0	Gummislang	Rubber hose		MRA CH 132567 -	4280
	108	-	-	-	192358-0	Gummislang	Rubber hose		URA CH 132567 -	4300
147	5	-	-	-	943473-9	Slangklamma	Hose clamp		CH 132567 -	4320
148	1	-	-	-		Anslutningsrör	Union manifold		MRA CH 132567 -	4360
		-	-	-					SE SIDA 50, 1-F09	4380
149	1	-	-	-	461445-9	Tätningring	Seal ring		MRA CH 132567 -	4300
150	1	-	-	-	461659-5	Slangstyrning	Hose guide		CH 132567 -	4320
151	1	-	-	-	461665-2	Strålningskydd	Heat shield		CH 132567 -	4360
152	1	-	-	-	944025-6	Klammer	Clamp		CH 132567 -	4380
153	2	-	-	-	955894-1	Bricka	Washer		CH 132567 -	4380