



VOLVO PARTS  
1 060 10495

Sida	Grupp	Pump, oljebhållare, servostyrning			Hydraulic pump, oil reservoir, servo steering	Illustration 10495	0350			
Page	22	Group 6				1975-03				
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	VST	HST								
1	1	1	-	-	679688-2	Pump .....	Hydraulic pump .....	VST CH-132566	0020	
	1	-	-	-	1221733-7	Pump .....	Hydraulic pump .....	VST CH 132567-	0040	
	-	-	-	-		•Det sida 24, 2-K03 .....	•Comps. page 24, 2-K03 .....		0060	
2	1	1	-	-	461059-8	Konsol .....	Bracket .....		0080	
3	1	1	-	-	461322-0	Konsol .....	Bracket .....	(430249)	0100	
	1	-	-	-	461613-2	Konsol .....	Bracket .....	VST CH-132566	0120	
4	1	1	-	-	461323-8	Konsol .....	Bracket .....	VST CH 132567-	0140	
5	ERF	ERF	-	-	955294-4	Skruv .....	Screw .....	(430239)	0160	
	ERF	ERF	-	-	940114-2	Skruv .....	Screw .....	L 16	0180	
	ERF	ERF	-	-	955561-6	Skruv .....	Screw .....	L 22	0200	
6	ERF	ERF	-	-	955827-1	Mutter .....	Nut .....	L 32	0220	
7	ERF	ERF	-	-	942336-9	Fjädrande bricka .....	Resilient washer .....	3/8-16	0240	
	ERF	ERF	-	-	940280-1	Fjädrande bricka .....	Resilient washer .....	D1 10	0260	
8	1	1	-	-	430241-0	Spännjärn .....	Tensioner rod .....	D1 13,5	0280	
9	1	1	-	-	955530-1	Skruv .....	Screw .....		0300	
10	1	1	-	-	430242-8	Distanshylsa .....	Spacer sleeve .....		0320	
11	1	1	-	-	955297-7	Skruv .....	Screw .....		0340	
12	1	1	-	-	191172-6	Bricka .....	Washer .....		0360	
13	1	1	-	-	460956-6	Remskiva .....	Pulley .....	(430243)	0400	
14	1	1	-	-	461455-8	Remskiva .....	Pulley .....	(461333)	0420	
15	6	6	-	-	955524-4	Skruv .....	Screw .....	ALT 1 L 19	0440	
	6	6	-	-	956570-6	Skruv .....	Screw .....	ALT 2 L 25	0460	
16	1	1	-	-	958484-8	Drivrem .....	Drive belt .....		0480	
17	1	1	-	-	679689-0	Oljebhållare .....	Oil reservoir .....		0520	
	-	-	-	-		•Det sida 24, 2-K03 .....	•Comps. page 24, 2-K03 .....		0540	
18	1	1	-	-	680659-0	Klammer .....	Clamp .....		0560	
19	2	2	-	-	955524-4	Skruv .....	Screw .....	CH-74729 L 19	0580	
	2	2	-	-	955523-6	Skruv .....	Screw .....	CH 74730- L 16	0600	
20	2	2	-	-	950353-3	Mutter .....	Nut .....	CH-74729	0620	
21	1	1	-	-	679690-8	Slang, sugledning .....	Suction hose .....	VST CH-132566	0640	
	1	-	-	-	1221759-2	Slang, sugledning .....	Suction hose .....	VST CH 132567-	0660	
22	1	1	-	-	190714-6	Hålskruv .....	Inlet fitting screw .....		0680	
23	2	2	-	-	11998-2	Packning .....	Packing .....		0700	
24	1	1	-	-	943472-1	Klammer .....	Clamp .....		0720	
25a	1	-	-	-	682334-8	Slang, tryckledning .....	High-pressure hose .....	CH-74449	0740	
25b	1	-	-	-	1206758-3	Slang, tryckledning .....	High-pressure hose .....	CH 74450-132566	0760	
	1	-	-	-	1221758-4	Slang, tryckledning .....	High-pressure hose .....	CH 132567-	0780	
	-	1	-	-	682451-0	Slang, tryckledning .....	High-pressure hose .....		0800	
26	1	-	-	-	952633-6	Klammer .....	Clamp .....	CH-74449	0820	
27	1	-	-	-	958236-2	Skruv .....	Screw .....	CH-74449	0840	
28	1	1	-	-	1206773-2	Rör .....	Piping .....	VST CH-74449	0860	
29	1	1	-	-	943178-4	Nippel .....	Nipple .....		0880	
29a	1	-	-	-	943178-4	Nippel .....	Nipple .....	VST CH 74450-132566	0900	
30	1	1	-	-	25167-8	Hålskruv .....	Inlet fitting screw .....	VST EXCL CH 74450-132566	0920	
31	ERF	ERF	-	-	18671-8	Packning .....	Packing .....		0960	
32	1	-	-	-	1206211-3	Slang, sugledning .....	Return hose .....		0980	
	-	1	-	-	681455-2	Slang, sugledning .....	Return hose .....	CH-52789	1000	
	-	1	-	-	1210396-6	Slang, sugledning .....	Return hose .....	CH 52790-	1020	
33	1	1	-	-	941686-8	Hålskruv .....	Inlet fitting screw .....		1040	
34	2	2	-	-	11996-6	Packning .....	Packing .....		1060	
35	1	1	-	-	943472-1	Klammer .....	Clamp .....		1080	
36	-	ERF	-	-	681920-5	Klammer .....	Clamp .....	CH-52789	1100	
37	-	ERF	-	-	362281-8	Klammer .....	Clamp .....	CH-25342	1120	
	-	ERF	-	-	714529-5	Klammer .....	Clamp .....	CH 25343-	1140	
38	-	ERF	-	-	945301-0	Klammer .....	Clamp .....	CH 52790-	1160	
39	-	ERF	-	-	955547-5	Skruv .....	Screw .....		1180	