



VOLVO PARTS  
 1 040 31984  
 (105:3)

Sida Page	Grupp Group	Växellåda AW71 1208378	Gearbox AW71 1208378	Illustration 31984 1984-12	0878					
140	4									
Pos. Fig.	Antal/Quantity			Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	1208 378									
x 1	1	-	-	1208378-8	Växellåda	Gearbox		5	VXL MARKED 1208378	0020
2	1	-	-	1239882-2	.Konverter	.Converter		4		0045
x 3	1	-	-	1239977-0	.Konverterkåpa	.Converter housing		5		0060
4	2	-	-	1233328-2	.Skyddsnet	.Guard net		5		0080
5	4	-	-	1239691-7	.Skruv	.Screw		3	M10 X 118	0100
	2	-	-	1239690-9	.Skruv	.Screw		3	M12 X 98	0120
6	4	-	-	941908-6	.Bricka	.Washer		2	D1 10.5 MM	0140
	2	-	-	940280-1	.Fjädrande bricka	.Resilient washer		2	D1 13.5 MM	0160
7	-	-	-		.Växellådshus, kmpl	.Gearbox housing, cpl		8		0180
	-	-	-		..Pumphus-	..Pump housing-			SE SIDA 144, 4-G01	0200
	-	-	-		främre planetväxel-, kopplingshus	overdrive gearing-, clutch housing				0220
	-	-	-		..Mellangavel-, planetväxel-, utgående axel	..Centre section-, planetary gearing-, output shaft			SE SIDA 110, 4-E15	0240
7a	1	-	-	1239689-1	.Tätningring	.Seal ring		3		0246
8	1	-	-	1233374-6	.Bakre hus	.Rear housing		8	ERS AV 1 ST 1239637-0, 1 ST 1239883-0, 1 ST 1239848-8	0250 0250
9	1	-	-		..Bussning	..Bushing		8		0270
10	1	-	-	235728-3	.Tätningring	.Sealing ring		S 3		0280
11	1	-	-		.Packning	.Gasket		S		0300
12	4	-	-	1239883-0	.Skruv	.Screw		S 4		0320
	2	-	-	1239884-8	.Skruv	.Screw		S 4		0340
13	4	-	-	1239139-7	.Låsbricka	.Lock washer		2		0350
14	1	-	-	1239971-3	.Kontrollsystem	.Valve bodies, cpl		4		0380
	-	-	-		..Det se sida 168, 4-H01	..Comps page 168, 4-H01				0416
15	2	-	-	955272-0	.Skruv	.Screw		2	M6 X 20	0420
	2	-	-	955274-6	.Skruv	.Screw		2	M6 X 25	0440
	5	-	-	955275-3	.Skruv	.Screw		2	M6 X 30	0460
	3	-	-	955276-1	.Skruv	.Screw		2	M6 X 35	0480
	1	-	-	940101-9	.Skruv	.Screw		2	M6 X 40	0500
	1	-	-	1239826-9	.Skruv	.Screw		3	M6 X 47	0510
	3	-	-	955279-5	.Skruv	.Screw		2	M6 X 55	0515
15a	17	-	-	941906-0	.Fjädrande bricka	.Resilient washer		2		0517
16	1	-	-	1239827-7	.Mellandel	.Spacer, oil strainer		5		0520
16a	1	-	-	1239828-5	.Packning	.Gasket		S 2		0540
17	1	-	-	1239829-3	.Oljesil	.Oil strainer		5		0560
18	5	-	-	955248-0	.Skruv	.Screw		2		0560
19	5	-	-	941905-2	.Fjädrande bricka	.Resilient washer		2		0570
20	1	-	-	1239930-9	.Reglagewire	.Control wire		4		0620
21	1	-	-	1220513-4	.Kabelstopp	.Cable stop		4		0655
22	1	-	-	1233141-9	.O-ring	.O-ring		S 3		0660
23	1	-	-		.Kam	.Cam			SE SIDA 166, 4-G23	0680
24	1	-	-	1239744-4	.Växelväljaraxel	.Gear selector shaft		4		0700
25	1	-	-	1239936-6	.Växelväljarkam	.Gear selector cam		3		
25a	1	-	-	1233098-1	..Låsring	..Locking ring		3		0830
26	1	-	-	1239832-7	.Låspinne	.Lock pin		3		0835
27	2	-	-	1233064-3	.Tätningring	.Seal ring		3		0840
	1	-	-	1239658-6	.Hylsa	.Sleeve		4		0880
28	1	-	-		.Spärrfjäder med rulle	.Spring catch w.roller			SE SIDA 162, 4-G19	0890
29	1	-	-	1239880-6	.Parkerings spärr	.P-position catch		3		0920
30	1	-	-	1233116-1	.Lagertapp	.Bearing bolt		3		0940
31	1	-	-	1233117-9	.Låsring	.Locking ring		3		0960
32	1	-	-	1239750-1	.Vridfjäder	.Torsion spring		3		0980
33	1	-	-	1239662-8	.Tryckstång, kmpl	.Thrust rod, cpl		4		1000
	1	-	-		..Tryckstång	..Thrust rod		8		1020
34	1	-	-	1233121-1	..Fjäder	..Spring		4		1021
35	1	-	-		..Tryckhylsa	..Thrust sleeve		8		1040
36	1	-	-		..Stoppkrage	..Stop ring		8		1060
37	1	-	-	1239885-5	.Låsplåt	.Lock plate		4		1080
38	2	-	-	955271-2	.Skruv	.Screw		2		1100
39	2	-	-	941906-0	.Fjädrande bricka	.Resilient washer		2		1120

