



Sida Page	Grupp Group	Växellåda BW55 Pumphus-kopplingshus	Gearbox BW55 Pump housing-clutch housing	Illustration 23428 1984-12	0800					
122	4									
Pos. Fig.	Antal/Quantity			Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
1	1	-	-	1233233-4	Kopplingshus, C2	Clutch housing, C2		5		0020
2	1	-	-	1233303-5	Kolv, bakre	Piston, rear		4		0040
3	2	-	-		.Kulventil	.Ball valve		8		0060
4	1	-	-	1233301-9	Hållare med fjädrar	Retainer with springs		4		0080
	1	-	-		.Hållare	.Retainer		8		0100
	18	-	-		.Returfjäder	.Return spring		8		0120
5	1	-	-	1233302-7	Fjädersäte	Spring seat		4		0140
6	1	-	-	1233028-8	Låsring	Circlip		3		0160
	1	-	-	273415-0	Lamellsats, C2	Direct clutch kit, C2		3		0180
7	1	-	-		.Stållamell	.Steel disc	S			0200
8	2	-	-		.Stållamell	.Steel disc	S			0
9	3	-	-		.Friktionslamell	.Friction disc	S			0240
10	1	-	-		.Tryckplatta	.Thrust plate	S			0260
11	2	-	-	1233024-7	.O-ring	.O-ring	S	3		0280
12	1	-	-	1233041-1	.O-ring	.O-ring	S	3		0300
13	1	-	-	1233025-4	.O-ring	.O-ring	S	3		0320
14	1	-	-	1233232-6	.Låsring	.Circlip	S	3		0
15	1	-	-	1233231-8	Kopplingsnav, C2	Clutch hub, C2		4		0300
16	1	-	-	1233035-3	Lagerbricka	Bearing washer	S	3		0380
17	1	-	-	1233036-1	Axialnållager	Needle thrust bearing	S	3		0400
18	1	-	-	1233037-9	Lagerbricka	Bearing washer	S	3		0420
19	1	-	-	1233327-4	Kopplingsnav, C1	Clutch hub, C1		4	(1233249)	0440
	1	-	-	273414-3	Lamellsats, C1	Forward clutch kit, C1		3	B23, B27, B28.	0460
	1	-	-	273649-4	Lamellsats, C1	Forward clutch kit, C1		3	B17, B19, B21, D20, D24.	0480
20	4	-	-		.Stållamell	.Steel disc	S	8	B23, B27, B28.	0500
	3	-	-		.Stållamell	.Steel disc	S	8	B17, B19, B21, D20, D24.	0520
21	4	-	-		.Friktionslamell	.Friction disc	S	8	B23, B27, B28.	0540
	3	-	-		.Friktionslamell	.Friction disc	S	8	B17, B19, B21, D20, D24.	0560
22	1	-	-	1233024-7	.O-ring, inre	.O-ring, inner	S	3		0580
23	1	-	-	1233025-4	.O-ring, yttre	.O-ring, outer	S	3		0600
24	1	-	-	1233232-6	.Låsring	.Circlip	S	3		0620
25	1	-	-	1233028-8	.Låsring	.Circlip	S	3	B17, B19, B21.	0640
	1	-	-	1233028-8	Låsring	Circlip		3	B23, B27, B28.	0660
26	1	-	-	1233248-2	Axel med kopplingshus C1	Shaft with clutch housing, C1		4		0680
27	1	-	-	1233021-3	Kolv, främre	Piston, forward		4	VXL MARKED 001, 010, 011, 013, 017, 018, 021, 023, 025, 030, 031.	0700
	1	-	-	1233255-7	Kolv, främre	Piston, forward		4	VXL MARKED 003, 008, 009, 012, 014, 015, 016, 019, 020, 022, PP22, 026, 027.	0760
28	1	-	-		.Kulventil	.Ball valve		8		0800
29	1	-	-	1233301-9	Hållare med fjädrar	Retainer with springs		4		0820
	1	-	-		.Hållare	.Retainer		8		0840
	18	-	-		.Fjäder	.Spring		8		0860
30	1	-	-	1233018-9	Lagerbricka	Bearing washer	S	3		0880
31	1	-	-	1233019-7	Axialnållager	Needle thrust bearing	S	3		0900
32	1	-	-	1233031-2	Lagerbricka	Bearing washer	S	3		0920
33	1	-	-	1233411-6	Pump	Pump		5	D20, D24	0940
	1	-	-	1233300-1	Pump	Pump		5	B17, B19, B21, B23, B27, B28. (1233003)	0950
34	1	-	-		.Pumphus	.Pump housing		8		0960
35	1	-	-		.Bussning	.Bushing		8		0980
36	1	-	-		.Drivhjul	.Drive wheel		8		1000
37	1	-	-		.Löphjul	.Blade wheel		8		1020
38	1	-	-	1233009-8	.Tätningring	.Seal ring	S	3		1040
39	1	-	-		.Statoraxel	.Shaft		8		1060
40	2	-	-		.Bussning	.Bushing		8		1080

