



VOLVO PARTS  
1 040 29 867  
(104:4)

Sida Page	Grupp Group	Koppling, HST Hydraulic manövrering	Clutch, HST Hydraulic control	Illustration						
10	4	B19, B21, B23	B19, B21, B23	29867	0100					
				1984-12						
Pos. Fig.	Antal/Quantity			Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
1	1	-	-	1220731-2	Koppling	Clutch	S	8	2, 3) B19A, E, F (1209624)	0020
	1	-	-	381249-2	Koppling	Clutch		8	ERS AV 1220731-2	0040
	1	-	-	1209884-4	Koppling	Clutch		2	1) EXCL TURBO ERS AV 1 ST 1220731-2, 1 ST 1220955-7	0050
	1	-	-	1209884-4	Koppling	Clutch		2	2, 62) B23A, E (1232539)	0060
	1	-	-	1220795-7	Koppling	Clutch		8	2, 62) B19ET, B21ET (1232650)	0061
	1	-	-	1220795-7	Koppling	Clutch		2	2, 63) B19ET, B21ET	0062
	1	-	-	273768-2	Kopplingsatts	Clutch kit		2	B17, B19, B21	0065
	1	-	-	273984-5	Kopplingsatts	Clutch kit		2	B23A, E, M45, M46	0066
2	1	-	-	1209760-6	Lamell	Disc	S	2	EXCL B23.	0070
	1	-	-	1209761-4	Lamell	Disc		2	EXCL TURBO	0075
	1	-	-	1209714-3	Lamell	Disc		2	B23A, E, B21A M47 B19ET, B21ET.	0076
3	1	-	-	275933-0	Lamellbeläggsatts	Clutch facing kit		2		0077
	2	-	-		..Belägg	..Facing				0078
4	18	-	-		..Nit	..Rivet	S			0079
5	6	-	-	959220-5	Skruv	Screw		2		0080
6	-	-	-		Pedalkåpa	Pedal casing			SE GRUPP 5	0081
7	1	-	-	1205727-9	Mutterplatta	Nut plate		8	VXL AUTO. ERS AV 1ST 1272393-8 1ST 948645-7 VXL AUTO.	0100
8	2	-	-	955293-6	Skruv	Screw		2		0120
9	1	-	-	1205721-2	Kopplingspedal	Clutch pedal		5		0140
10	2	-	-	675555-7	Bussning	Bushing		4		0160
11	1	-	-	1206770-8	Axel	Shaft		4		0180
12	1	-	-	1205725-3	Returfjäder	Return spring		2		0200
13	1	-	-	1229285-0	Hylsa	Sleeve		3		0210
14	1	-	-	955333-0	Skruv	Screw		2		0220
15	1	-	-	945654-2	Mutter	Nut		2		0240
16	1	-	-	1272021-5	Gummiskoning	Rubber pad		3		0260
17	20MM	-	-	699856-1	Kantskyddslist	Edge moulding		2	(672172) METERVARA	0280
18	1	-	-	1229929-3	Huvudcylinder	Master cylinder		2		0300
19	1	-	-		.Det se sida 16, 4-A17	.Comps page 16, 4-A17				0320
19a	2	-	-	1329579-5	Packning	Gasket		2	(1273386)	0340
20	2	-	-	946440-5	Skruv	Screw		2		0360
21	1	-	-	955782-8	Mutter	Nut		2		0380
22	1	-	-	964843-7	Bult	Bolt		2		0400
23	1500	-	-	664822-4	Låsfjäder	Lock spring		1		0420
24	1	-	-	946814-1	Bundyrör	Bundy piping		2		0440
25	1	-	-	946816-6	Mutter	Nut		2		0460
26	3	-	-	946815-8	Mutter	Nut		2		0480
27	3	-	-	951188-2	Klammer	Clamp		2		0500
28	1	-	-	955140-9	Skruv	Screw		2		0520
29	1	-	-	1228785-0	Konsol	Bracket		4		0540
30	1	-	-	1206840-9	Slang	Hose		3		0560
31	1	-	-	11994-1	Packning	Packing		2		0580
32	1	-	-	940143-1	Låsbricka	Lock washer		2		0600
	1	-	-	946830-7	Mutter	Nut		2		0620

- Serviceskytten märkt 1. Service plate marked 1. Plaque de service portant le No 1. Serviceschild Kennzeichnung 1. Letrero de servicio marcado 1. Targhetta di assistenza, contrassegnata 1.
  - Serviceskytten märkt 2. Service plate marked 2. Plaque de service portant le No 2. Serviceschild Kennzeichnung 2. Letrero de servicio marcado 2. Targhetta di assistenza, contrassegnata 2.
  - Serviceskytten märkt 3. Service plate marked 3. Plaque de service portant le No 3. Serviceschild Kennzeichnung 3. Letrero de servicio marcado 3. Targhetta di assistenza, contrassegnata 3.
62. 242 CH-237369, 244 CH-939339, 245 CH-506259, 265 CH-34029.
63. 242 CH 237370-, 244 CH 939340-, 245 CH 506260-, 265 CH 34030-.

Sida Page	Grupp Group	Koppling, HST Hydraulisk manövrering	Clutch, HST Hydraulic control	Illustration 29867 1984-12	0100						
12	4	B19, B21, B23	B19, B21, B23								
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
33	1	-	-	-	1205733-7	Manövercylinder..... Det se sida 20, 4-A21	Slave cylinder..... Comps page 20, 4-A21	2			0740 0760
34	1	-	-	-	914463-5	Spårring.....	Circlip.....	2			0780
35	1	-	-	-		Urkopplingsgaffel,..... kmpI	Withdrawal fork,..... cpl	8			0800 0820
36	1	-	-	-	1232052-9	.Urkopplingsgaffel.....	.Withdrawal fork.....	3			0840
	1	-	-	-	381269-0	.Ledkula.....	.Ball.....	3		EXCL M47 ERS AV 1 ST 1220806-2, 1 ST 120265-4	0860 0865 0867
	-	-	-	-	1220806-2	.Ledkula.....	.Ball.....	3		M47	0870
37	1	-	-	-	953046-0	Skruv.....	Screw.....	2			0880
38	1	-	-	-	955782-8	Mutter.....	Nut.....	2			0900
39	1	-	-	-	672122-9	Urkopplingslager.....	Withdrawal bearing.....	2		A = 43 MM	0920
x 39	1	-	-	-	1220955-7	Urkopplingslager.....	Release bearing.....	2		A = 36.5 MM (1220824)	0940 0950
x 40	1	-	-	-	1220759-3	Gummikåpa.....	Rubber guard.....	3		(381298)	0960