



VOLVO PARTS
 1023 34106
 (102:5)

Sida Page	Grupp Group	Mängdmätare	Air-fuel control unit	Illustration	0600						
110	2c	INJE B27E, B28E, B27F, B28F.	INJE B27E, B28E, B27F, B28F.	34106 1984-12							
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	1269 194	1269 010	1269 459	1269 526							
1	1	-	-	-	1269194-5	Mängdmätare	Air-fuel control unit		8		0020
	-	1	-	-	1269010-3	Mängdmätare	Air-fuel control unit		8	ERS AV 1 ST 1269146-5, 1 ST 1269484-0	0040 0060
	-	-	1	-	1269459-2	Mängdmätare	Air-fuel control unit		8	ERS AV 1 ST 1269146-5, 1 ST 1269484-0	0080 0100
	-	-	-	1	1269526-8	Mängdmätare	Air-fuel control unit		8		0120
2	1	1	1	1	243890-1	..O-ring	..O-ring		2		0140
3	3	3	3	3	243892-7	..Skruv	..Screw		2		0160
4	1	-	-	-	1269145-7	..Bränslefördelare	..Fuel distributor		3		0180
	1	-	-	-	5001752-4	..Utbytesbränsle- fördelare	..Exchange fuel distributor		9		0200
	-	1	-	-	1269147-3	..Bränslefördelare	..Fuel distributor		3		0240
	-	1	-	-	5001847-2	..Utbytesbränsle- fördelare	..Exchange fuel distributor		9		0260 0280 0300 0320
	-	-	1	1	1269484-0	..Bränslefördelare	..Fuel distributor		3		0340
5	1	1	1	1	1276089-8	..O-ring	..O-ring	S	2		0360
6	1	-	-	-	1274036-1	..Fjäder	..Spring		2		0380
	-	1	1	1	1276096-3	..Fjäder	..Spring		2		0400
7	ERF	ERF	ERF	ERF	1276091-4	..Justerbricka	..Adjuster washer		2	TJ 0,1	0420
	ERF	ERF	ERF	ERF	1276092-2	..Justerbricka	..Adjuster washer		2	TJ 0,15	0440
	ERF	ERF	ERF	ERF	1276095-5	..Justerbricka	..Adjuster washer		2	TJ 0,5	0460
8	1	1	-	-	1276090-6	..O-ring	..O-ring	S	2		0480
	-	-	1	1	1269608-4	..Tätning	..Seal		2		0500
9	1	1	1	1		..Låsring	..Lock ring	S			0520
10	1	1	1	1		..Ring	..Ring	S			0540
11	1	1	1	1	11994-1	..Packning	..Gasket	S	2	(947282)	0560
12	1	1	1	1		..Fjäder	..Spring	S			0580
13	1	1	1	1		..Förskruvning	..Joint	S			0600
14	1	1	1	1		..Nålventil	..Needle valve	S			0620
15	1	1	1	1	947620-1	..Packning	..Packing	S	2		0640
16	1	1	1	1		..Propp	..Plug	S			0660
17	1	-	-	-	1269332-1	..Mätare	..Control unit		3		0680
	-	1	1	-	1269146-5	..Mätare	..Control unit		3		0700
	-	-	-	1	1269794-2	..Mätare	..Control unit		3		0720
18	1	1	1	1	244229-1	..Hävarm	..Lever		4		0740
19	2	2	2	2	243414-0	..Skruv	..Screw		4		
20	2	2	2	2	244253-1	..Distansbricka	..Spacer washer		3		0760
21	1	1	1	1	244230-9	..Hävarm	..Lever		4		0800
22	1	1	1	1	244231-7	..Pinne	..Pin		3		0820
23	1	1	1	1	462803-8	..Lagersats	..Bearing kit		3		0840
24	1	-	-	-	244233-3	..Platta	..Plate		4		0860
	-	1	1	1	1274056-9	..Platta	..Plate		4		0880
25	1	1	1	1	244235-8	..Skruv	..Screw		3		0900
26	1	1	1	1	244234-1	..Bricka	..Washer		3		0920
27	1	1	1	1	244236-6	..Anslag	..Stop		3		0940
28	2	2	2	2	233173-4	..Skruv	..Screw		2		0960
29	2	2	2	2	955918-8	..Bricka	..Washer		2		0980
30	1	1	1	1	244239-0	..Anslagssats	..Stop kit		3		1000
31	1	1	1	1		...Anslag	...Stop	S			1020
32	1	1	1	1		...Skruv	...Screw	S			1040
33	1	1	1	1		...Bricka	...Washer	S			1060
34	1	1	1	1	462800-4	..Mutter	..Nut	S	2		1080
35	1	-	-	-	1269333-9	..Skruv	..Screw		3		1100
	-	1	1	-	1269334-7	..Skruv	..Screw		3	(244238)	1120
36	-	-	-	1	1317715-9	Plomberingskula	Sealing ball		2		1140
37	1	1	-	-	464923-2	Plomberingsplugg	Sealing plugg		2	B28E	1160
	1	1	1	1	1276097-1	Justerbrickssats	Adjuster washer kit		2		1180
						systemtryckregulator	system press. reg.				1200

Sida Page	Grupp Group	Insprutningspump diesel motor	Injection pump diesel engines	Illustration 28979	0625						
112	2c	D20, D24	D20, D24	1984-12							
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
1	1	-	-	-	1257677-3	Mängdskruv	Quantity screw	3		ALT L = 62 MM	0020
	1	-	-	-	1257678-1	Mängdskruv	Quantity screw	3		ALT L = 60 MM	0040
	1	-	-	-	1257679-9	Mängdskruv	Quantity screw	3		ALT L = 64 MM	0060
2	1	-	-	-	844235-2	O-ring	O-ring	4			0080
3	1	-	-	-	25703-0	Bricka	Washer	3			0100
4	1	-	-	-	955800-8	Mutter	Nut	2			0120
5	1	-	-	-	844652-8	Distanshylsa	Spacer sleeve	3			0140
6	2	-	-	-	955781-0	Mutter	Nut	2			0160
7	1	-	-	-	844237-8	Hålskruv	Hollow screw	4			0180
10	1	-	-	-	844178-4	Radialtätning	Radial seal	4			0200
11	1	-	-	-	844176-8	O-ring	O-ring	3			0240
12	2	-	-	-	6638096-5	Skruv	Screw	3			0260
13	1	-	-	-	844176-8	O-ring	O-ring	3			0280
14	2	-	-	-	6638096-5	Skruv	Screw	3			0300
15	1	-	-	-	1257676-5	Elventil	Electric valve	3			0320
16	1	-	-	-	942888-9	Flatstift	Cable terminal	2			0380
17	1	-	-	-	941905-2	Bricka	Washer	2			0400
18	1	-	-	-	955780-2	Mutter	Nut	2			0420
19	1	-	-	-	243572-5	O-ring	O-ring	3			0440
20	6	-	-	-	244688-8	Nippel	Nipple	5	(243558) D24		0460
	5	-	-	-	244688-8	Nippel	Nipple	5	(243558) D20		0480
21	6	-	-	-	243560-0	Bricka	Washer	4	D24		0500
	5	-	-	-	243560-0	Bricka	Washer	4	D20		0520
22	6	-	-	-	238309-9	Tryckfjäder	Compression spring	4	D24		0540
	5	-	-	-	238309-9	Tryckfjäder	Compression spring	4	D20		0560
23	6	-	-	-	1257675-7	Tryckventil	Delivery valve	4	D24		0580
	5	-	-	-	1257675-7	Tryckventil	Delivery valve	4	D20		0600
24	6	-	-	-	243562-6	Tätningbricka	Packing washer	4	D24		0620
	5	-	-	-	243562-6	Tätningbricka	Packing washer	4	D20		0640
25	1	-	-	-	1277235-6	Stoppskruv, tomgång	Grub screw, idling	3			0660
26	1	-	-	-	844228-7	Stoppskruv, max. varv	Grub screw, top speed	2			0680
27	1	-	-	-	1542407-0	Hylsa	Sleeve	3			0700
28	1	-	-	-	1257741-7	Justerbricka, tändförställning	Adjuster washer, ignition timing	2	TJ 1,2		0740
29	1	-	-	-	845737-6	Luftningsskruv	Air screw	3			
30	1	-	-	-	947620-1	Packning	Gasket	2	(233321)		