



VOLVO PARTS
 1 023 34102
 (102:2)

Sida Page	Grupp Group	Bränslesystem dieselmotor	Fuel system diesel engine	Illustration							
62	2c	D20, D24	D20, D24	34102	0225						
				1984-12							
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	D20	D24									
1	1	1	-	-	1257156-8	Konsol.....	Bracket.....	5			0020
2	3	3	-	-	955319-9	Skruv.....	Screw.....	2			0040
3	3	3	-	-	941906-0	Fjädrande bricka.....	Resilient washer.....	2			0060
4	3	3	-	-	960148-5	Bricka.....	Washer.....	2			0080
5	1	1	-	-	1257259-0	Stöd.....	Support.....	5			0100
6	2	2	-	-	955296-9	Skruv.....	Screw.....	2			0120
7	2	2	-	-	941907-8	Fjädrande bricka.....	Resilient washer.....	2			0140
8	2	2	-	-	1257634-4	Bricka.....	Washer.....	3			0160
9	1	-	-	-	1257518-9	Insprutningspump.....	Fuel injection pump.....	5	STD		0180
	-	1	-	-	1257157-6	Insprutningspump.....	Fuel injection pump.....	5	57)		0200
	-	1	-	-	1257157-6	Insprutningspump.....	Fuel injection pump.....	5	55)EXCL USA/CANADA		
	-	1	-	-	1328367-6	Insprutningspump.....	Fuel injection pump.....	5	55) USA/CANADA		0240
	-	-	-	-		.Det se sida 112, 2-E17.....	.Comps page 112, 2-E17.....				0260
	1	-	-	-	5001716-9	Insprutningspump, utbytesenhet	Fuel injection pump, exchange unit	9	VXL MAN		0280
	1	-	-	-	5001879-5	Insprutningspump, utbytesenhet	Fuel injection pump, exchange unit	9	VXL AUTO		0300
	-	1	-	-	5001715-1	Insprutningspump, utbytesenhet	Fuel injection pump, exchange unit	9	57)VXL MAN		0320
	-	1	-	-	5001715-1	Insprutningspump, utbytesenhet	Fuel injection pump, exchange unit	9	55)VXL MAN, EXCL USA/CANADA		0380
	-	1	-	-	5001878-7	Insprutningspump, utbytesenhet	Fuel injection pump, exchange unit	9	57)VXL AUTO		0400
	-	1	-	-	5001878-7	Insprutningspump, utbytesenhet	Fuel injection pump, exchange unit	9	55)VXL AUTO, EXCL USA/CANADA		0420
	-	1	-	-	5002846-3	Insprutningspump, utbytesenhet	Fuel injection pump, exchange unit	5	55)USA/CANADA, VXL AUTO		0440
	-	1	-	-	5002849-7	Insprutningspump, utbytesenhet	Fuel injection pump, exchange unit	5	55)USA/CANADA VXL MAN		0460
10	1	1	-	-	1257593-2	Hylsa.....	Sleeve.....	3			0480
11	2	2	-	-	1257632-8	Skruv.....	Screw.....	2			0500
12	1	1	-	-	1257633-6	Skruv.....	Screw.....	2			0600
13	3	3	-	-	941907-8	Fjädrande bricka.....	Resilient washer.....	2			0620
14	3	3	-	-	955894-1	Bricka.....	Washer.....	2			0640
15	1	1	-	-	1257631-0	Skruv.....	Screw.....	2			0660
16	1	1	-	-	941907-8	Fjädrande bricka.....	Resilient washer.....	2			0680
17	1	1	-	-	1257630-2	Bricka.....	Washer.....	3			0700
18	1	1	-	-	1257592-4	Mutter.....	Nut.....	3			0720
19	1	1	-	-	1257166-7	Kuggremhjul.....	Pulley.....	3			0740
20	1	1	-	-	910113-0	Kil.....	Key.....	2			0800
21	1	1	-	-	955923-8	Fjäder bricka.....	Spring washer.....	2			0820
22	1	1	-	-	955784-4	Mutter.....	Nut.....	2			0840
23	1	1	-	-	1257808-4	Fjäder.....	Washer.....	3			0860
24	1	1	-	-	1277275-2	Fjäder.....	Washer.....	3			0880
25	1	1	-	-	1257388-7	Bränsleledning, tillopp.....	Fuel inlet, inlet.....	3			0900
26	1	1	-	-	74040-7	Hålskruv.....	Union bolt.....	4	M12		0920
27	2	2	-	-	11994-1	Packning.....	Gasket.....	2	(947282)		0940
28	1	1	-	-	1257663-3	Mellanstycke.....	Spacer.....	4			0960
29	1	1	-	-	11994-1	Packning.....	Gasket.....	2	(947282)		0980
30	130	130	-	-	1257639-3	Slang.....	Hose.....	2	METERVARA		1000
31	1	1	-	-	1257543-7	Slangklamma.....	Hose clamp.....	2			1020
32	1	1	-	-	1257390-3	Nippel.....	Nipple.....	3			1040
33	2	2	-	-	11994-1	Packning.....	Gasket.....	2			1060
34	1	1	-	-	844237-8	Hålskruv.....	Union bolt.....	4			1080
35	2	2	-	-	945650-0	Slangklämma.....	Hose clamp.....	2			1100
36	620	620	-	-	1266870-3	Slang.....	Hose.....	2			1120
37	-	1	-	-	1328347-8	Aneroidbrytare.....	Switch.....	3	USA/CANADA		1140
38	-	2	-	-	960862-1	Skruv.....	Screw.....	2	USA/CANADA		1160
39	-	1	-	-	1328374-2	Konsol.....	Bracket.....	3	USA/CANADA		1190

