



VOLVO PARTS  
 1 024 33400  
 (103:1)

Sida Page		Grupp Group		Konstant farthållare INJE, SEN UTF		Cruise control INJE, SEN UTF		Illustration 33400		10145	
26		2d		EXCL B21F, B23F LH- JETRONIC		EXCL B21F, B23F LH- JETRONIC		1984-12			
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	B21E B23E B21F	B27E B28E B28F									
1	1	1	-	-	1128862-8	Konstantfarthållar- sats	Cruise control kit	6			0020
2	1	1	-	-	1348132-0	.Regulator	.Regulator	4	(1272256)		0040
3	1	1	-	-	1272257-5	.Ledningsmatta	.Wiring harness	5			0060
3a	1	1	-	-	1259270-5	.Säkring	.Fuse	1			0080
4	1	1	-	-	1272796-2	.Servoenhet, kmpl.	.Servo unit, cpl	4			0100
	1	1	-	-		..Servoenhet, kmpl	..Servo unit, cpl	8			0120
5	1	1	-	-	1272259-1	..Skarvdon	..Connector	2			0140
6	1	1	-	-	1272260-9	.Vakuumentil	.Vaccum valve	4			0160
7	2	2	-	-	1272287-2	.Mutter	.Nut	2			0180
8	1	1	-	-	1272261-7	.Retardationsbrytare	.Retardation breaker	4			0200
9	1	1	-	-	1235238-1	.Strömställare	.Switch	3			0240
10	2	2	-	-	1235237-3	.Mutter	.Nut	2			0260
	1	-	-	-	1128725-7	Monteringssats, konstantfarthållare	Installation kit, cruise control	6	VST.		0280
	1	-	-	-	1188791-6	Monteringssats, konstantfarthållare	Installation kit, cruise control	4	HST.		0300
	-	1	-	-	1128724-0	Monteringssats, konstantfarthållare	Installation kit, cruise control	6	VST.		0320
11	1	1	-	-	1272184-1	.Konsol	.Bracket	5			0340
12	2	-	-	-	40136-4	.Gummibussning	.Rubber bushing	2			0360
13	2	-	-	-	960136-0	.Bricka	.Washer	2			0400
14	2	-	-	-	947226-7	.Skruv hb 14x19	.Screw hb 14x19	2			0420
	-	2	-	-	190666-8	.Skruv hb 14x13	.Screw hb 14x13	2	VST		0440
15	1	1	-	-	1272183-3	.Konsol	.Bracket	5	VST		0460
	1	-	-	-	1188788-2	.Konsol	.Bracket	5	HST		0480
16	2	2	-	-	955138-3	.Skruv	.Screw	2			0500
17	2	2	-	-	965395-7	.Skruv	.Screw	2			0520
18	2	2	-	-	955120-1	.Skruv	.Screw	2			0540
19	1	-	-	-	955137-5	.Skruv	.Screw	2			0560
20	1	1	-	-	955825-5	.Mutter	.Nut	2			0580
21	2	2	-	-	955122-7	.Skruv	.Screw	2			0600
22	1	1	-	-	1272270-8	.T-nippel	.T-nipple	3			0620
23	340	230	-	-	948958-4	.Slang	.Hose	2	VST.METERVARA		0640
	1250	-	-	-	948958-4	.Slang	.Hose	2	HST.METERVARA		0660
24	1300	1300	-	-	948478-3	.Slang	.Hose	2	VST.METERVARA		0680
	1600	-	-	-	948478-3	.Slang	.Hose	2	HST.METERVARA		0700
25	2	2	-	-	947935-3	.Slangklamma	.Hose clamp	2			0720
26	1	-	-	-	1272182-5	.Gasväjer	.Throttle cable	3	VST.		0740
	1	-	-	-	1188787-4	.Gasväjer	.Throttle cable	1	HST.		0760
	-	1	-	-	1272181-7	.Gasväjer	.Throttle cable	3	VST.		0780
27	1	1	-	-	947515-3	.Spärryttare	.Retaining ring	2			0800
28	1	1	-	-	1272254-2	.Konsol	.Bracket	5	VST.		0820
28a	1	-	-	-	1188794-0	.Konsol	.Bracket	5	HST.		0840
29	1	1	-	-	955294-4	.Skruv	.Screw	2			0860
30	1	1	-	-	955782-8	.Mutter	.Nut	2			0880
31	1	1	-	-	1272245-0	.Konsol	.Bracket	5	VST.		0900
31a	1	-	-	-	1188795-7	.Konsol	.Bracket	5	HST.		0920
32	1	1	-	-	1259264-8	.Induktionsgivare	.Induktion sender	2	VDO		0940
	1	1	-	-	1308635-0	.Induktionsgivare (ingår ej i sats 1128725-7, 1188791-6, 1128724-0)	.Induktion sender (not included in kit 1128725-7, 1188791-6, 1128724-0)	2	YASAKI		0960
33	1	1	-	-	941269-3	.Bussning	.Bushing	2			0980
34	1	1	-	-	1258398-5	.Körvisaromkopplare	.Direction indicator switch	2			1000
35	1	1	-	-	1234518-7	.Bussning	.Bushing	4	262C		1020
36	4	4	-	-	948211-8	.Bandklamma	.Clamp	2			1040
37	1	-	-	-	1306240-1	.Gasreglage	.Throttle control	5			1060

Sida Page	Grupp Group	Konstant farthållare INJE, SEN UTF	Cruise control INJE, SEN UTF	Illustration 33400	0145						
28	2d	EXCL B21F, B23F LH- JETRONIC	EXCL B21F, B23F LH- JETRONIC	1984-12							
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
		B21E	B27E								
		B23E	B28E								
		B21F	B28F								
38	-	1	-	-	1269420-4	..Gasreglage .....	..Throttle control .....	5		VST.	1280
38a	1	-	-	-	1306238-5	..Konsol .....	..Bracket .....	3			1300
39	-	1	-	-	1274025-4	..Konsol .....	..Bracket .....	8		VST.	1320
39a	1	-	-	-	1317544-3	..Reglagerulle, undre .....	..Bobbin, lower .....	4		(1276136)	1340
40	-	1	-	-	1274405-8	..Reglagerulle, undre .....	..Bobbin, lower .....	2		(1274125)	1360
41	1	1	-	-	1257291-3	...Kulbult .....	...Ball stud .....	3			1380
42	1	1	-	-	1306246-8	..Fjäderstyrning, undre .....	..Spring guide, lower .....	3		VST.	1400
43	1	1	-	-	1274240-9	..Fjäder, inre .....	..Spring, inner .....	2			1420
44	1	1	-	-	1306244-3	..Fjäder, yttre .....	..Spring, outer .....	2			1440
45	1	1	-	-	1306245-0	..Fjäderstyrning, övre .....	..Spring guide, upper .....	3			1460
46	2	2	-	-	1276512-9	..Bussning .....	..Bushing .....	2			1480
47	2	2	-	-	1274034-6	..Fjäderstyrning, undre .....	..Spring guide, lower .....	3			1500
48	2	2	-	-	1274031-2	..Fjäder .....	..Spring .....	2			1520
49	1	1	-	-	1274035-3	..Fjäderstyrning, övre .....	..Spring guide, upper .....	3			1540
50	1	-	-	-	1326370-2	..Reglagerulle, mellan .....	..Bobbin, middle .....	4		(1274127)VST.	1560
51	1	-	-	-	1326370-2	..Reglagerulle, mellan .....	..Bobbin, middle .....	8		HST.	1580
	1	1	-	-	1326195-3	..Reglagerulle, övre .....	..Bobbin, upper .....	4		(1274128)VST.	1600
	1	-	-	-	1326195-3	..Reglagerulle, övre .....	..Bobbin, upper .....	4		HST.	1620
	1	1	-	-	955894-1	..Bricka .....	..Washer .....	2			1640
	1	1	-	-	951669-1	..Spårryttare .....	..Circlip .....	2			1660