



VOLVO PARTS
 1 021 37125
 (101:6)

Sida Page	Grupp Group	Insugningsrör	Induction manifold	Illustration	0700				
84	2a	B27E, B27F, B28E. B28F(498628,498629)	B27E, B27F, B28E. B28F(498628,498629)	37125 1984-12					
Pos. Fig.	Antal/Quantity			Artikel nr Part No	Benämning	Description	Sats Kit	B Anmärkning Notes	
1	1	-	-	1269374-3	Insugningsrör.....	Induction manifold.....	4	(269648)	0020
2	2	-	-	955088-0	.Hattplugg.....	.Cap plug.....	2		0100
3	1	-	-	946600-4	Nippel.....	Nipple.....	2	(943818)	0120
4	1	-	-	947043-6	Nippel.....	Nipple.....	3	ALT 1	0140
5	1	-	-	952075-0	Propp.....	Plug.....	2	ALT 2	0160
6	1	-	-	947043-6	Nippel.....	Nipple.....	3	ALT 1	0180
7	1	-	-	952075-0	Propp.....	Plug.....	2	ALT 2	0200
8	1	-	-	1276445-2	Nippel.....	Nipple.....	3	ALT 1	0220
9	1	-	-	952069-3	Propp.....	Plug.....	2	ALT 2	0240
10	1	-	-	1276445-2	Nippel.....	Nipple.....	3	ALT 1	0260
11	1	-	-	952069-3	Propp.....	Plug.....	2	ALT 2	0
12	1	-	-	269431-3	Konsol, H.....	Bracket, R.....	4	B27E(498616-498619) B27F	0300 0320
	1	-	-	1269396-6	Konsol, H.....	Bracket, R.....	3	B27E(498624-498627), B28E, B28F	0340 0360
13	1	-	-	246052-5	Konsol, V.....	Bracket, L.....	3	B27E(498616-498619), B27F	0380 0
	1	-	-	1269393-3	Konsol, V.....	Bracket, L.....	3	B27E(498624-498627), B28E, B28F	0420 0440
14	4	-	-	942001-9	Skruv.....	Screw.....	2		0460
15	4	-	-	941906-0	Fjädrande bricka.....	Resilient washer.....	2		0480
16	2	-	-	269171-5	Packning.....	Gasket.....	S 1		0500
17	1	-	-	269168-1	Förbindelserör.....	Intermediate inlet.....	4		0520
18	2	-	-	952069-3	Propp.....	Plug.....	2		0540
19	2	-	-	925091-1	O-ring.....	O-ring.....	S 2		0560
20	2	-	-	943711-2	Stödtring.....	Support ring.....	2		0580
21	1	-	-	269173-1	Underdel, mängdmätare.....	Lower section, metering device.....	4	B27E, B27F, B28F, B28E(498634-498637, 498662,498663,498664, 498685)	0600 0601 0602 0603
	1	-	-	269173-1	Underdel, mängdmätare.....	Lower section, metering device.....	4	58)B28E(498664,498665)	0610 0611
	1	-	-	1269856-9	Underdel, mängdmätare.....	Lower section, metering device.....	4	59)B28E(498664,498665)	0620 0621
	1	-	-	1269856-9	Underdel, mängdmätare.....	Lower section, metering device.....	4	B28E(498686,498687)	0630 0631
22	2	-	-	1269347-9	.Bussning.....	.Bushing.....	3	(942593)	0640
23	1	-	-	946771-3	.Plugg.....	.Plug.....	2		06
24	1	-	-	955083-1	.Hattplugg.....	.Cap plug.....	2	D 14.5	0680
25	1	-	-	269376-0	.O-ring, rör tillsats-luftslid.....	.O-ring, pipe auxilliary air slide.....	S 2	FÖR/FOR 269173-1	0700 0701
x 25a	1	-	-	269174-9	.Ring.....	.Ring.....	5		0720
26	1	-	-	952069-3	Propp.....	Plug.....	2	ALT 1	0740
26a	1	-	-	946600-4	Nippel.....	Nipple.....	2	ALT 2	07
27	1	-	-	237568-1	Plugg.....	Plug.....	2		0700
28	3	-	-	947114-5	O-ring.....	O-ring.....	2		0800
29	3	-	-	269835-5	Tomgångsjusterskruv.....	Idle metering screw.....	3		0820
30	2	-	-	1269819-7	Skyddsplugg.....	Protecting plug.....	2	(269793)	0840
31	1	-	-	1276445-2	Nippel.....	Nipple.....	3	ALT 1	0860
32	1	-	-	949012-9	Nippel.....	Nipple.....	2	ALT 2	0880
33	1	-	-	952069-3	Propp.....	Plug.....	2	ALT 3	0900
34	1	-	-	952069-3	Propp.....	Plug.....	2	ALT	0920
35	1	-	-	949012-9	Nippel.....	Nipple.....	2		0940
36	1	-	-	948373-6	Skruv.....	Screw.....	2		0960
37	1	-	-	946599-8	Fjädrande bricka.....	Resilient washer.....	2		0980
38	4	-	-	946480-1	Skruv.....	Screw.....	2		1000
39	4	-	-	946599-8	Fjädrande bricka.....	Resilient washer.....	2		1020
40	1	-	-	269677-1	Spjällaxel.....	Spindle.....	3		1040

58. 242 CH -223939, 244 CH -812609, 245 CH -434459, 262, 264 CH -131509, 265 -33009.

59. 242 CH 223940-, 244 CH 812610-, 245 CH 434460-, 264 CH 131510-, 265 CH 33010-.

Sida Page	Grupp Group	Insugningsrör B27E, B27F, B28E. B28F(498628,498629)	Induction manifold B27E, B27F, B28E. B28F(498628,498629)	Illustration 37125 1984-12	0700					
Pos. Fig.	Antal/Quantity			Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
41	2	-	-	269177-2	Spjällskiva	Throttle disc	2		B27E(498617-498619, 498625-498627) B28E(498635-498637, 498663-498665,498685- 498687) B27F	1060 1080 1100 1120 1125 1130
	2	-	-	1269192-9	Spjällskiva	Throttle disc	2		B27E(498616,498624) B28E(498634,498662, 498684) B28F	1140 1160 1170 1180
42	4	-	-	943781-5	Skruv	Screw	2			1
43	1	-	-	419568-1	Tätningarring	Seal ring	S	2		1240
44	1	-	-	269513-8	Fjäder	Spring	3			1260
45	1	-	-	269512-0	Fjäderhållare	Spring retainer	3			1280
46	1	-	-	1269284-4	Hävarm	Lever	3		B27E(498616-498619), B27F	1300 1320
	1	-	-	1269448-5	Hävarm	Lever	4		B27E(498624-498627), B28E, B28F	1340
47	1	-	-	946036-1	Låsmutter	Lock nut	2			1380
48	1	-	-	1269017-8	Konsol	Bracket	3		B27E(498616-498619), B27F	1400 1420
	1	-	-	269516-1	Konsol	Bracket	3		B27E(498624-498627), B28E, B28F	1440 1460
49	2	-	-	942000-1	Skruv	Screw	2			1480
50	2	-	-	944925-7	Justerskruv	Adjuster screw	2		(269794)	1500
51	2	-	-	955780-2	Mutter	Nut	2			1520
52	1	-	-	269377-8	Täcklock	Cover plate	4			1560
53	1	-	-		Nippel, kmpl	Nipple, cpl			MAC, SWEDEN, AUSTRALIA SE GRUPP 9	1580 1600
54	1	-	-	464517-2	Packning	Gasket	2			1620
55	2	-	-	955271-2	Skruv	Screw	2			1640
56	2	-	-	941906-0	Fjädrande bricka	Resilient washer	2			1660