



VOLVO PARTS
 1 021 34925
 (101:6)

Sida Page	Grupp Group		Insugningsrör, spjällhus B21F LH-JETRONIC B23F LH-JETRONIC		Induction manifold, throttle housing B21F LH-JETRONIC B23F LH-JETRONIC		Illustration 34925 1984-12		0305		
52	2a										
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	B21F	B23F									
1	1	-	-	-		Insugningsrör, kmpl	Induction manifold, cpl	8		B21F	0020
	-	1	-	-		Insugningsrör, kmpl	Induction manifold, cpl	8		B23F	0030
2	-	-	-	-	1306884-6	Insugningsrör	Induction manifold	4			0040
	-	1	-	-	1326101-1	Insugningsrör	Induction manifold	4			0050
3	3	3	-	-	953044-5	Skruv	Screw	2			0060
4	1	-	-	-	1306732-7	Rörnippel	Nipple	3			0080
5	2	1	-	-	947043-6	Nippel	Nipple	3			0100
5a	-	1	-	-	1276445-2	Nippel	Nipple	3			0110
6	3	2	-	-	1276445-2	Nippel	Nipple	3			0120
6a	-	1	-	-	191026-4	Propp	Plug	2			0130
7	2	1	-	-	948990-7	Plugg	Plug	3			0
7a	-	1	-	-	1266539-4	Nippel	Nipple	2			0150
7b	-	1	-	-	943835-9	Plugg	Plug	2			0154
7c	-	1	-	-		Täckplåt	Cover plate	8		TID UTF	0155
7d	-	1	-	-		Packning	Gasket	8		TID UTF	0156
7e	-	2	-	-	948746-3	Skruv	Screw	8		TID UTF	0157
8	1	-	-	-		Spjällhus, kmpl	Throttle housing, cpl	8		B21F	0
	-	1	-	-		Spjällhus, kmpl	Throttle housing, cpl	8		B23F	0150
9	1	-	-	-	1326576-4	Spjällhus	Throttle housing	3		(1317725)	0180
	-	1	-	-	1332460-3	Spjällhus	Throttle housing	3			0190
10	2	2	-	-	942593-5	Bussning	Bushing	2			0200
11	1	-	-	-	946771-3	Plugg	Plug	2			0220
12	1	1	-	-	419568-1	Tätningssring	Seal ring	S 2			0240
13	1	-	-	-	463729-4	Spjällaxel	Spindle	3			0260
	-	1	-	-	1326015-3	Spjällaxel	Spindle	2			0270
14	1	-	-	-	460462-5	Spjällskiva	Shutter plate	3			0280
	-	1	-	-	419758-8	Spjällskiva	Shutter plate	3			0290
15	2	2	-	-	943781-5	Skruv	Screw	2			0300
16	1	1	-	-	1266710-1	Fjäder	Spring	3			0320
17	1	1	-	-	1266711-9	Bricka	Washer	3			0340
18	1	-	-	-	1317522-9	Hävarm	Lever	4			0360
	-	1	-	-	1332286-2	Hävarm	Lever	3			0370
19	1	1	-	-	963106-0	Mutter	Nut	2			0380
20	1	1	-	-	944925-7	Skruv	Screw	2			0400
21	1	1	-	-	955780-2	Mutter	Nut	2			0420
22	1	1	-	-	946600-4	Nippel	Nipple	2			0440
23	1	1	-	-	949013-7	Nippel	Nipple	2			0460
24	1	1	-	-	463766-6	Packning	Gasket	S 2			0
25	1	-	-	-	1317742-3	Fläns	Flange	4			0500
26	-	1	-	-	1336085-4	Ventilhus	Valve housing	3			0520
27	-	1	-	-	1219554-1	Tomgångsskruv	Slow running screw	3			0540
28	-	1	-	-	947114-5	O-ring	O-ring	S 2			0560
29	2	-	-	-	941460-8	Skruv	Screw	2			0580
30	-	2	-	-	959190-0	Skruv	Screw	2			06
31	-	2	-	-	941905-2	Fjädrande bricka	Resilient washer	2			06
32	-	1	-	-	1326016-1	Konsol	Bracket	3			0640
33	-	2	-	-	956162-2	Skruv	Screw	2			0660
34	-	1	-	-	949046-7	Propp	Plug	3			0680
35	1	1	-	-	463527-2	Packning	Packing	S 2			0700
36	3	3	-	-	941907-8	Fjädrande bricka	Resilient washer	2			0720
37	3	3	-	-	955782-8	Mutter	Nut	2			0740
38	1	1	-	-	1266796-0	Packning	Gasket	S 1		(463224)	0760
39	8	8	-	-	955894-1	Bricka	Washer	2			0780
40	8	8	-	-	955782-8	Mutter	Nut	2			0800
41	-	1	-	-	1332579-0	Stag	Stay	4		(1332578)	0820
42	-	1	-	-	946173-2	Skruv	Screw	2		B23F(499802,499803, 499890), B23F(499846) MO -6537, B23F(499847) MO -14483	0940 0941 0942 0943
42a	-	1	-	-	949846-0	Skruv, självgående	Screw, self-tapping	3		B23F(499846) MO 6538-, B23F(499847) MO 14484- B23F(499944,499945)	0950 0951 0952
43	-	1	-	-		Skruv	Screw			SE SIDA 10, 1-D11	0960