



VOLVO PARTS
1 090 31960
(110:7)



Sida Page	Grupp Group	Mikrofon, Högtalare Antenn, Balanskontroll	Microphone, Loudspeaker, Antenna, Fader control	Illustration 31960 1984-12	1625						
160	9										
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
1	1	-	-	-	1128282-9	Mikrofon	Microphone		8	4-STEREO EXECUTIVE	0020
2	1	-	-	-	600056-6	Ledning	Cable		6	4-STEREO EXECUTIVE	0040
	1	-	-	-	600609-2	Ledning	Cable		6		0060
3	1	-	-	-	600135-8	.Säkring 3 A	.Fuse 3 A		6	4-STEREO EXECUTIVE	0080
	1	-	-	-	600134-1	.Säkring 2 A	.Fuse 2 A		6		0100
4	1	-	-	-	600061-6	Jordledning	Earth cable		6		0120
5	1	-	-	-	282465-4	Högtalare, sats instrument panel	Loudspeaker, sats dash-board				0140
	4	-	-	-	946220-1	.Skruv	.Screw		2		0160
7	4	-	-	-	946214-4	.Fjädermutter	.Spring nut		2		0180
8	1	-	-	-	1307095-8	Högtalargaller	Loudspeaker grille		5	FOR 282465 (1214061)	0200
9	1	-	-	-	1128506-1	Högtalare, sats dörr	Loudspeaker, kit door		8	10W, TID UTF ERS AV 1129599-5	0220
10	2	-	-	-	1234859-5	.Högtalare	.Loudspeaker		8		0260
11	2	-	-	-	1234790-2	.Högtalarkabel	.Loudspeaker cable		6		0280
12	4	-	-	-	955137-5	.Skruv	.Screw		2		0300
13	-	-	-	-		Högtalargaller	Loudspeaker grille			FOR 1128506	0320
	2	-	-	-	1264445-6	.Svart	.Black		4		0340
	2	-	-	-	1264759-0	.Beige	.Beige		4		0360
	2	-	-	-	1264760-8	.Ljusbeige	.Light beige		4		0380
14	4	-	-	-	944602-2	Clip	Clips		2		0400
15	1	-	-	-	1129599-5	Högtalare, sats dörr	Loudspeaker, kit door		3	10W, SEN UTF	0420
16	2	-	-	-	1323065-1	.Högtalare	.Loudspeaker		3		0440
17	8	-	-	-	1323413-3	.Fjädermutter	.Spring nut		2		0460
18	8	-	-	-	947246-5	.Skruv	.Screw		2	(955127)	0480
19	2	-	-	-	283194-9	Högtalare	Loudspeaker		8	15W	0500
20	1	-	-	-	1235864-4	Högtalargaller	Loudspeaker grille		4		0520
21	4	-	-	-	955779-4	.Mutter	.Nut		2		0540
22	4	-	-	-	960137-8	.Bricka	.Washer		2		0560
23	4	-	-	-	955945-1	.Låsbricka	.Lock washer		2		0580
24	2	-	-	-	283195-6	.Högtalare	.Loudspeaker		6	20W	0600
25	1	-	-	-	1128483-3	Stolpantenn	Pillar antenna		6		0620
26	1	-	-	-	1235423-9	.Stöd, antenspröt	.Support		2	19)	0640
	1	-	-	-	1307833-2	.Stöd, antenspröt	.Support		2	20)	0660
27	1	-	-	-		.Antennkabel	.Antenna cable		8		0680
28	1	-	-	-	949480-8	.Skruv	.Screw		2	M5X10	0700
29	1	-	-	-	1128690-3	Teleskopantenn	Telescopic antenna		8	ERS AV 1 ST 1128735-6, 1 ST 1128705-9	0720
30	1	-	-	-	1235834-7	.Antennkabel	.Antenna cable		6	L = 4600 MM (1128705)	0740
31	1	-	-	-	1128735-6	.Teleskopantenn	.Telescopic antenna		6		0760
32	1	-	-	-	1128693-7	Toppantenn	Top antenna		6		0780
33	1	-	-	-	1258473-6	.Antenn	.Antenna		6		0800
34	1	-	-	-	1235834-7	.Antennkabel	.Antenna cable		6	L = 4600 MM (1128705)	0820
35	1	-	-	-	1129937-7	Motordriven antenn	Motor driven antenna		3	ERS AV 1129869-2	0840
36	1	-	-	-	1259532-8	.Ledningsmatta	.Cable harness		6		0860
37	1	-	-	-	1203048-2	.Spännband	.Steel band		3		0880
38	1	-	-	-	1128866-9	.Knapp	.Switch		6	19)	0900
	1	-	-	-	1308065-0	.Knapp	.Switch		4	20)	0920
39	1	-	-	-	1129569-8	Högtalarsats, bakre, blå	Rear speaker kit, blue		8	245 (283196)	0940
	1	-	-	-	1129032-7	Högtalarsats, bakre, beige	Rear speaker kit, beige		8	245DL	0960
	1	-	-	-	1129570-6	Högtalarsats, bakre, beige	Rear speaker kit, beige		8	245GL (1129033)	0980
	1	-	-	-	1129568-0	Högtalarsats, bakre, svart	Rear speaker kit, black		8	245 (283199)	1000
40	2	-	-	-		.Panel	.Panel		8		1020
41	2	-	-	-	1258753-1	.Högtalare	.Loudspeaker		6		1040
											1060
											1080
											1100
											1120
											1140
											1160
											1200

19. 242 CH-189179, 244 CH-592109, 245 CH-317939, 262 CH- 8374, 264 CH-107609, 265 CH-28319.

20. 242 CH 189180-, 244 CH 592110-, 245 CH 317940-, 262 CH 8375-, 264 CH 107610-, 265 CH 28320-.

Sida Page	Grupp Group	Mikrofon, Högtalare Antenn, Balanskontroll	Microphone, Loudspeaker, Antenna, Fader control	Illustration 31960 1984-12	1625						
162	9										
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
42	8	-	-	-		.Blindnit.....	.Blind rivet.....	8			1220
43	8	-	-	-	955891-7	.Bricka.....	.Washer.....	2			1240
44	2	-	-	-	1225678-0	.Galler, blått.....	.Grille, blue.....	4			1260
	2	-	-	-	1264445-6	.Galler, svart.....	.Grille, black.....	4			1280
	2	-	-	-	1264759-0	.Galler, beige.....	.Grille, beige.....	4	245DL		1300
	2	-	-	-	1225679-8	.Galler, beige.....	.Grille, beige.....	4	245GL		1320
45	8	-	-	-	944602-2	.Klips.....	.Clip.....	2			1340
46	1	-	-	-	1129420-4	Balanskontroll.....	Fader control.....	3	FOR BOOSTER		1360
	1	-	-	-	1129461-8	Balanskontroll.....	Fader control.....	3			1380