



VOLVO PARTS  
 1090 37177  
 (110:2)

Sida Page	Grupp Group	Värmeelement UCOMBU	Heater, UCOMBU	Illustration 37177 1984-12	0150					
20	9									
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	-	-	-	1215516-4	Värmeelement	Heater	6		0020
2	1	-	-	-	1129007-9	.Kåpa, kompl.	.Casing, cpl.	5		0040
3	4	-	-	-	684807-1	.Clips	.Clip	3		0060
4	1	-	-	-		.Fläkt	.Fan	8		0080
5	1	-	-	-	1211081-3	..Motor	..Motor	8	ELEKTROLUX	0100
6	1	-	-	-	1234885-0	elborstesats	carbon brush kit	2		0120
7	1	-	-	-		...Fläkthjul	...Fan wheel	8		0140
8	1	-	-	-	950010-9	..Skruv	..Screw	2		0145
x 9	1	-	-	-	1259325-7	..Motor	..Motor	3	BOSCH ERS AV 1211081-3	0160 0165
10	1	-	-	-	685277-6	..Ledskena	..Flap	5		0180
10a	3	-	-	-	680331-6	..Kudde	..Pad	4		0220
11	7	-	-	-	1215113-0	.Packning	.Packing	4		0240
12	1	-	-	-	1234222-6	.Spjäll, golv	.Shutter, floor	4		0260
13	1	-	-	-	1234223-4	.Spjäll, friskluft	.Shutter, air	4		0280
14	1	-	-	-	1234224-2	.Spjäll, defroster	.Shutter, defroster	4		0320
15	3	-	-	-	191694-9	.Spärrbricka	.Catch washer	2		0340
16	1	-	-	-	1211303-1	.Värmeväxlare	.Heat exchanger	4		0360
17	1	-	-	-	685359-2	.Packning	.Gasket	3		0380
18	2	-	-	-	1214721-1	.Tätningssring	.Seal ring	2		0400
19	19	-	-	-	948218-3	.Clips	.Clip	3		0420
20	1	-	-	-	1211490-6	.Luftfördelare, V	.Air distributor, L	5		0440
21	1	-	-	-	1211491-4	.Luftfördelare, H	.Air distributor, R	5		0460
x 22	1	-	-	-	1348251-8	.Kontrollventil	.Control valve	2	(1323302)	0480
23	1	-	-	-	1214059-6	.Klammer	.Clamp	3	TID UTF	0500
24	1	-	-	-	1214060-4	.Skruv	.Screw	2	TID UTF	0520
25	3	-	-	-	1214023-2	.Kapillärhållare	.Capillary holder	3	TID UTF	0540
26	1	-	-	-	1214756-7	.Slang	.Hose	3		0560
27	1	-	-	-	1214755-9	.Slang	.Hose	3		0580
28	1	-	-	-	1214757-5	.Slang	.Hose	3		0600
29	1	-	-	-	1234909-8	.Genomföring	.Gromet	3		0620
30	1	-	-	-	461405-3	.Mellanlägg	.Spacer	3		0640
31	6	-	-	-	943472-1	.Slangklammer	.Hose clip	2		0660
32	1	-	-	-	1214754-2	.Konsol, V	.Bracket, L	5		0680
33	1	-	-	-	685366-7	.Konsol, H	.Bracket, R	5		0700
34	2	-	-	-	955141-7	.Skruv	.Screw	2		0720
35	2	-	-	-	955140-9	.Skruv	.Screw	2		0740
36	2	-	-	-	955127-6	.Skruv	.Screw	2		0760
37	2	-	-	-	192557-7	.Fjädersmutter	.Spring nut	2		0780
38	1	-	-	-	942888-9	.Plattstift	.Flat pin	2		0800
39	1	-	-	-	955947-7	.Låsbricka	.Lock washer	2		0820
40	1	-	-	-	1234348-9	.Värmeregglage	.Heater control	5		0840
41	2	-	-	-	955138-3	Det se sida 26, 8-B03	Comps page 26, 8-B03	2		0860
42	1	-	-	-	1214037-2	.Skruv	.Screw	2		0880
43	1	-	-	-	1215377-1	.Klamma, V	.Clamp, L	3		0900
44	1	-	-	-	1215377-1	.Klamma, H	.Clamp, R	3		0920
45	3	-	-	-	684340-3	.Packning	.Gasket	2	SEN UTF	
					1211599-4	.Clips	.Clip	2		