


TID UTF.



SEN UTF.

VOLVO PARTS
1 023 32626
(102:4)



Sida Page	Grupp Group	Vevhusventilation B17, B19, B21, B23		Crankcase ventilation B17, B19, B21, B23		Illustration 32626 1984-12	0635				
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	-	-	-	-		Vevhusventilation,..... kmpl.	Crankcase ventilation cpl.	8		TID UTF	0020
1	1	-	-	-	947836-3	.Slang.....	.Hose.....	2			0040
2	1	-	-	-	943475-4	.Klammer.....	.Clamp.....	2			0060
3	1	-	-	-	463835-9	.Flamskydd.....	.Flame shield.....	2			0080
4	1	-	-	-	463737-7	.T-rör.....	.T-pipe.....	2			0100
5	270	-	-	-	944075-1	.Slang.....	.Hose.....	2			0120
	1	-	-	-		.Slang.....	.Hose.....	2			0140
										CARB MAC SE GRUPP 9 AC-KOMPENSERING/ AC-COMPENSATION	0160 0180 0200 C
6	1	-	-	-	1219088-0	.Klammer.....	.Clamp.....	2			0240
7	ERF	-	-	-	1276438-7	.Slang.....	.Hose.....	2		(1276310)	0260
8	ERF	-	-	-	942390-6	.Slang.....	.Hose.....	2			0280
9	1	-	-	-	948211-8	.Bandklammer.....	.Strip clamp.....	2			0300 0320
						Vevhusventilation..... kmpl	Crankcase ventilation cpl.	8		SEN UTF	C
10	1	-	-	-	1306398-7	.Oljefälla.....	.Oil trap.....	3			0300 0380
11	1	-	-	-	949659-7	O-ring.....	O-ring.....	S 2		(925065)	0400
12	2	-	-	-	955295-1	.Skruv.....	.Screw.....	2		L 20. ALT 1	0420
	2	-	-	-	955297-7	.Skruv.....	.Screw.....	2		L 25. ALT 2	0440
12a	2	-	-	-	955894-1	.Bricka.....	.Washer.....	2			0460
13	1	-	-	-	419771-1	.Flamskydd.....	.Flame guard.....	2		ALT 1	0480
14	1	-	-	-	949700-9	.Slang.....	.Hose.....	8		ALT 1.ERS AV	0500
										1 ST 1336682-8, 1 ST 463835-9, 1 ST 1336681-0.	0520 0540 0560
15	1	-	-	-	1306598-2	.Nippel.....	.Nipple.....	8		ALT 1.ERS AV	0580
										1 ST 1336682-8, 1 ST 463835-9, 1 ST 1336681-0	0600 0620 0640
16	1	-	-	-	1336682-8	.Slang.....	.Hose.....	2		ALT 2	0660
17	1	-	-	-	463835-9	.Flamskydd.....	.Flame guard.....	2		ALT 2	0680
18	1	-	-	-	1336681-0	.Nippel.....	.Nipple.....	3		ALT 2	0700
19	ERF	-	-	-	948958-4	.Slang.....	.Hose.....	2		EXCL TURBO	0720
						insugningsrör.....	induction manifold.....				0740
20	1	-	-	-	949668-8	.Bandklammer.....	.Cable tie.....	2		(948616)	C
21	1	-	-	-	1306599-0	.Slang,..... friskluftslang	.Hose,..... air intake	2		CARB.ALT 1.EXCL B19K	0760 0800
	1	-	-	-	1317899-1	.Slang,..... luftintag	.Hose,..... air intake	2		B19K	0820 0840
	1	-	-	-	1306602-2	.Slang,..... mängdmätare	.Hose,..... air-fuel control unit	2		INJE.(K-JETRONIC) EXCL TURBO	0860 0880
	1	-	-	-	1317667-2	.Slang,..... friskluftssläng	.Hose,..... air inlet hose	2		INJE.(LH-JETRONIC) EXCL TURBO	0900 0920
22	1	-	-	-	1306931-5	.Slang.....	.Hose.....	2		TURBO	0940
23	ERF	-	-	-	1276438-7	.Slang.....	.Hose.....	2		(1276310)TURBO	0960
24	1	-	-	-	418646-6	.Gummihatt.....	.Rubber cap.....	2		TURBO	0980
25	1	-	-	-	1306196-5	.Slang.....	.Hose.....	2			1020