



VOLVO PARTS
 1 021 28978
 (101:2)

Sida Page	Grupp Group	Cylinderblock B27, B28	Cylinder block B27, B28	Illustration 28978 1984-12	0450						
72	2a										
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
1	1	-	-	-	1218159-0	Cylinderblock	Cylinder block		5	B27	0020
	1	-	-	-	1218164-0	Cylinderblock	Cylinder block		5	B28	0030
2	4	-	-	-		.Lageröverfall	.Bearing cap		8		0040
3	8	-	-	-	1218077-4	.Pinnskruv	.Stud		2		0060
4	8	-	-	-	1218026-1	.Bricka	.Washer		2		0080
5	8	-	-	-	955803-2	.Mutter	.Nut		2		0100
6	2	-	-	-	1232544-5	.Rörpinne	.Tubular pin		2	D 8	0120
7	3	-	-	-	951987-7	.Rörpinne	.Tubular pin		2	D 8	0140
8	4	-	-	-	947382-8	.Rörpinne	.Tubular pin		2	D 16 X 14	0160
9	1	-	-	-	1218146-7	.Propp	.Plug		2	M25	0180
10	1	-	-	-	1218023-8	.Packning	.Packing		S 2	D 25	
11	1	-	-	-	1218020-4	.Propp	.Plug		2	M12	
12	1	-	-	-	1218019-6	.Propp	.Plug		2	D 14,5	0240
	1	-	-	-	1218018-8	.Propp	.Plug		5	D 25,5	0250
x 13	3	-	-	-	1218192-1	.Propp	.Plug		2	M18	0260
x 14	3	-	-	-	1218191-3	.Packning	.Packing		2	D 18	0280
15	2	-	-	-	269272-1	.Avtappningskran	.Drain cock		2		
16	2	-	-	-	11996-6	.Packning	.Packing		S 1	D 16	
17	1	-	-	-	245145-8	.Centereringsring	.Centering ring		2		0340
18	1	-	-	-	947386-9	.O-ring	.O-ring		S 2		0360
19	1	-	-	-	245367-8	.Tätning	.Seal		4		0380
20	1	-	-	-	1218027-9	.Tätning	.Seal		S 2		0400
21	1	-	-	-	245368-6	.Packning	.Gasket		S 2		0420
22	5	-	-	-	947388-5	.Skruv	.Screw		2		0440
23	5	-	-	-	946599-8	.Bricka	.Washer		2		0460
24	1	-	-	-		.Oljepump	.Oil pump			SE SIDA 92, 1-G21	0480
25	1	-	-	-	247439-3	Vevhus, övre	Crankcase, upper		5	(269644)	0500
26	2	-	-	-	1218005-5	.Propp	.Plug		2		0520
27	12	-	-	-	955303-3	Skruv	Screw		2		0540
28	12	-	-	-	941907-8	Fjädrande bricka	Resilient washer		2		0560
29	2	-	-	-	946518-8	Skruv	Screw		2		0580
30	2	-	-	-	946599-8	Fjädrande bricka	Resilient washer		2		0600
31	-	-	-	-		Svänhjulskåpa	Flywheel casing			SE GRUPP 4	0620
32	1	-	-	-		.Ledkula	.Ball			SE GRUPP 4	0640