



VOLVO PARTS
 1 050 34893
 (106:3)

Sida Page	Grupp Group				Komplettenheter	Complete units	Illustration	0350		
14	5						34893			
	Antal/Quantity				Artikel nr	Benämning	Description	Sats Kit	Anmärkning Notes	
Pos. Fig.	242 244	245	262 264	265	Part No			P S R		
1	1	1	1	1	1229928-5	Vakuumbromscylinder..... 10" GIRLING kännetecken: svartmålad eller gulchromaterad .Det se sida 18, 4-J19.....	Vacuum brake cylinder.... 10" GIRLING characteristic: painted black or yellow chromated .Comps page 18, 4-J19..	8	ALT 1. TID UTF. ERS AV 1 ST 1272159-3.	0020 0040 0060 0080 0100 0120 0140 0160 0180 0200
										0240 0260 0280 0300 0320 0340 0360 0380 0400 0420 0440 0460 0480 0500
	1	1	1	1	1272159-3	Vakuumbromscylinder..... 10" DBA kännetecken: varmförzinkad (grå) .Det se sida 20, 4-J21.....	Vacuum brake cylinder.... 10" DBA characteristic: hot galvanized (grey) .Comps page 20, 4-J21..	3	ALT 1. SEN UTF.	0520 0540 0560 0580 0600 0620 0640 0660 0680 0700 0720 0740
1a	1	1	1	1	1229336-1	Vakuumbromscylinder..... 2x8" DBA kännetecken: omålad .Det se sida 20, 4-J21.....	Vacuum brake cylinder.... 2x8" DBA characteristic: un- painted .Comps page 20, 4-J21..	3	ALT 2	0760 0780 0800 0820 0840 0860 0880 0900 0920 0940 0960 0980 1000 1020 1040 1060 1080 1100 1120 1140 1160 1180 1200 1220 1240 1260
1b	1	1	1	1	1229493-0	Vakuumbromscylinder..... 2x8" GIRLING kännetecken: svart- målad .Det se sida 22, 4-J23.....	Vacuum brake cylinder.... 2x8" GIRLING characteristic: painted black .Comps page 22, 4-J23..	8	ALT 3 ERS AV 1 ST 1229336-1.	
1c	-	-	1	1	1228272-9	Backventil.....	Check valve.....	3	B27F, B28F	
2	4	4	4	4	948645-7	Mutter.....	Nut.....	2		
2a	1	1	1	1	1272078-5	Tätningssring.....	Seal ring.....	3		
x 3	1	1	1	1	1330800-2	Tandemhuvudcylinder..... (uttag "A" på höger sida)	Tandem master cylinder (outlet "A" on the right-hand side)	3	ALT 1 (1205894)	
x	1	1	1	1	1330799-6	Tandemhuvudcylinder..... (uttag "A" på vänster sida) .Det se sida 24, 4-K01.....	Tandem master cylinder (outlet "A" on the left-hand side) .Comps page 24, 4-K01..	3	ALT 2 (1205893)	
4	1	1	1	1	1273052-9	Varningsventil.....	Warning valve.....	3	(1272196)	
4a	2	2	2	2		..Plugg.....	..Plug.....	8		
4b	2	2	2	2	1330797-0	..O-ring.....	..O-ring.....	2		
5	1	1	1	1	272702-2	..Kontaktsats.....	..Contact kit.....	1		
6	1	1	1	1		..Kontaktus.....	..Contact housing.....	S		
7	1	1	1	1		..Tätning.....	..Seal.....	S		
8	1	1	1	1		..Fjäder.....	..Spring.....	S		
9	1	1	1	1		..Stift.....	..Pin.....	S		
10	1	1	1	1		..Bussning.....	..Bushing.....	S		
11	1	1	1	1	941110-9	Skruv.....	Screw.....	2		
12	1	1	1	1	960140-2	Bricka.....	Washer.....	2		
13	1	1	1	1	1229684-4	Konsol.....	Bracket.....	4		
14	1	1	1	1	948893-3	Flänsskruv.....	Flange screw.....	2		
15	2	-	-	-	1228738-9	Reduceringsventil.....	Reduction valve.....	3		
	2	-	-	-	1228688-6	Reduceringsventil.....	Reduction valve.....	3	DIES	1000
	-	2	-	-	1228738-9	Reduceringsventil.....	Reduction valve.....	3	DIES	1020
	-	2	-	-	1228738-9	Reduceringsventil.....	Reduction valve.....	3	TURBO	1040
	-	2	-	-	1229148-0	Reduceringsventil.....	Reduction valve.....	3	EXCL TURBO	1060
	-	-	2	-	1228688-6	Reduceringsventil.....	Reduction valve.....	3		1080
	-	-	-	2	1228738-9	Reduceringsventil.....	Reduction valve.....	3		1100
16	1	1	1	1	1221757-6	Konsol.....	Bracket.....	4		1120
17	2	2	2	2	963106-0	Mutter.....	Nut.....	2		1140
18	2	2	2	2	941907-8	Fjädrande bricka.....	Resilient washer.....	2		1160
19	2	2	2	2	940199-3	Skruv.....	Screw.....	2		1180
20	-	-	2	-	1248360-8	Distanshylsa.....	Spacer sleeve.....	4	262C	1200
21	-	-	1	1	1228559-9	Vakuumpump.....	Vacuum pump.....	4	B27, B28F. B28E VXL AUTO SEN UTF	1220 1240
	-	-	-	-		.Det se sida 26, 4-K03.....	.Comps page 26, 4-K03..			1260

Sida Page	Grupp Group				Komplettenheter	Complete units	Illustration	0350			
16	5						34893 1984-12				
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	242 244	245	262 264	265							
22	-	-	1	1	269736-5	O-ring	O-ring	2		B27F TID UTF.	1280
	-	-	1	1	269883-5	Packning	Gasket	2		B27F, B28F SEN UTF.	1300
										B28E VXL AUTO SEN UTF	1320
23	-	-	4	4	953045-2	Skruv	Screw	2		B27F, B28F. L=40 MM	1340
										B28E VXL AUTO SEN UTF	1360
24	-	-	4	4	941907-8	Fjädrande bricka	Resilient washer	2		B27F, B28F.	1380
										B28E VXL AUTO SEN UTF	1400
25	-	-	4	4	955782-8	Mutter	Nut	2		B27F, B28F.	1420
										B28E VXL AUTO SEN UTF	1440
26	ERF	ERF	ERF	ERF	1272328-4	Slang	Hose	2			
27	1	1	1	1	1272121-3	Slangklamma	Hose clamp	2			1400
28	1	1	1	1	1272121-3	Slangklamma	Hose clamp	2			1500
29	1	1	-	-	952630-2	Klamma	Clamp	2		VST	1520
30	1	1	-	-	955780-2	Mutter	Nut	2		VST	1540
31	1	1	-	-	1228334-7	Hållare	Retainer	3		VST	1560
32	1	1	-	-	955243-1	Skruv	Screw	2		VST	1580
33	2	2	-	-	963107-8	Låsmutter	Lock nut	2			
34	-	-	ERF	ERF	1272328-4	Slang	Hose	2		B27F, B28F	1620
										B28E VXL AUTO SEN UTF	1640
										(947908)	1660
35	-	-	1	1	1272121-3	Slangklammer	Hose clamp	2		B27F, B28F.	1680
										B28E VXL AUTO SEN UTF	1700
36	-	-	1	1	1218716-7	Ventil	Valve	3		B27F, B28F.	1720
										B28E VXL AUTO SEN UTF	1740
37	-	-	1	1	1229191-0	4-vägsnippel	4-ways nipple	2		VST	1760
38	-	-	2	2	1221906-9	T-rör	T-pipe	2		HST	1780
39	-	-	1	1	1228272-9	Backventil	Check valve	3			1800
40	-	-	ERF	ERF	1272328-4	Slang	Hose	2		(947908)	1820
41	-	-	2	2	1272121-3	Slangklamma	Hose clamp	2			1840
42	ERF	ERF	ERF	ERF	948211-8	Bandklamma	Strip clamp	2		(948210)	1860
43	1	1	1	1		Bromspedal med	Brake pedal with			SE SIDA 28, 4-K05	1880
						monteringsdetaljer	installation component				1900
44	1	1	-	-	1257206-1	Vakuumpump	Vacuum pump	4		DIES	1920
45	2	2	-	-	953043-7	Skruv	Screw	2		DIES	1940
46	2	2	-	-	941907-8	Bricka	Washer	2		DIES	1960
47	1	1	-	-	1328593-7	O-ring	O-ring	3		DIES	1980
48	1	1	-	-	1257207-9	Stötstång	Push rod	4		DIES	2000
	1	1	-	-	272723-8	Sats för byte av	Kit for exchanging of	3		DIES	2040
						ventiler, vakuumpump	valve, vacuum pump				2060
	1	1	-	-	272722-0	Sats för byte av	Kit for exchanging of	3		DIES	2080
						tätningar, vakuumpump	gasket, vacuum pump				2100