



VOLVO PARTS  
1 060 29075  
(107:3)

Sida Page	Grupp Group	Pump, oljebehållare			Hydraulic pump, oil reservoir			Illustration	0450	
56	6							29075		
								1984-12		
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	1276 495	1273 595	1274 123							
1	1	-	-	-	1276495-7	Pump.....	Hydraulic pump.....	8	B17,B19,B21,B23 D20,D24 ERS AV 1 ST 1273595-7, 1ST 1272424-1, 1 ST 1272426-6.	0020 0040 0060 0080 0100 0120
	-	1	-	-	1273595-7	Pump.....	Hydraulic pump.....	8	B17,B19,B21,B23,D20,D2 ERS AV 1 ST 1273972-8.	0140 0160 0180 0200 0
	-	-	1	-	1274123-7	Pump.....	Hydraulic pump.....	8	B27,B28 ERS AV 1ST 1273973-6, 1ST 464538-8, 1ST 1229492-2.	0240 0260 0280 0300 0320 0
2	1	1	1	-		.Hus.....	.Housing.....	8		0380 0400
3	1	1	-	-		.Drivaxelsats.....	.Drive shaft kit.....	8		0420 0440 0460 0480
	-	-	1	-	273935-7	.Drivaxelsats.....	.Drive shaft kit.....	2		0500 0520 0540
4	1	1	1	-		..Drivaxel.....	..Drive shaft.....	S		0560 0580 0600 0620
5	1	1	1	-	1272423-3	..Låsring.....	..Lock ring.....	S 4		0640 0660 0680 0700 0720 0740 0
5a	ERF	ERF	-	-	1272634-5	.Justerbricka.....	.Shim.....	4	6) 0,05 MM	0760 0780 0800 0820 0840 0860 0880 0900 0920 0940 0960 0980
	ERF	ERF	-	-	1272635-2	.Justerbricka.....	.Shim.....	4	6) 0,1 MM	
	ERF	ERF	-	-	1272636-0	.Justerbricka.....	.Shim.....	4	6) 0,2 MM	
	ERF	ERF	-	-	1272637-8	.Justerbricka.....	.Shim.....	4	6) 0,3 MM	
6	1	1	1	-	464538-8	.Nav.....	.Hub.....	4		
7	1	1	1	-	1272412-6	.Tätning.....	.Seal.....	4		
8	1	1	-	-		.Rotorsats.....	.Rotor kit.....	8		
	-	-	1	-	273901-9	.Rotorsats.....	.Rotor kit.....	2		
9	1	1	1	-		..Rotor.....	..Rotor.....	S		
10	1	1	1	-		..Vinge.....	..Vane.....	S		
11	1	1	1	-		..Ring.....	..Ring.....	S		
12	1	1	-	-	1272419-1	.Ventilsats.....	.Valve kit.....	4		
	-	-	1	-	1272418-3	.Ventilsats.....	.Valve kit.....	4		
13	1	1	1	-		..Ventil.....	..Valve.....	S		
14	1	1	1	-		..Fjäder.....	..Spring.....	S		
15	2	2	2	-	1272427-4	.Pinne.....	.Pin.....	4		
16	1	1	1	-	1272428-2	.Platta.....	.Plate.....	4		
17	1	1	1	-	1272429-0	.Platta.....	.Plate.....	4		
18	1	1	1	-	1272430-8	.Fjäder.....	.Spring.....	4		
19	1	1	1	-	1272411-8	.Tätningssats.....	.Sealing kit.....	2		
20	1	1	1	-		..O-ring.....	..O-ring.....	S		
21	1	1	1	-		..O-ring.....	..O-ring.....	S		
22	2	2	2	-		..O-ring.....	..O-ring.....	S		
23	2	2	2	-		..O-ring.....	..O-ring.....	S		
24	1	1	1	-	1272431-6	..Låsring.....	..Lock ring.....	S 4		
25	1	1	-	-	1272422-5	.Oljebehållaresats.....	.Reservoir kit.....	3		
	-	-	1	-	1272421-7	.Oljebehållaresats.....	.Reservoir kit.....	4		
26	1	1	1	-		..O-ring.....	..O-ring.....	S		
27	1	1	1	-		..O-ring.....	..O-ring.....	S		
28	2	2	2	-		..O-ring.....	..O-ring.....	S		
29	1	-	-	-	1272424-1	.Förskruvning.....	.Fitting.....	4		
	-	-	1	-	1272425-8	.Förskruvning.....	.Fitting.....	4		
30	1	-	1	-	1272426-6	.O-ring.....	.O-ring.....	4		

6. Ej standard utrustning,service alternativ. Not standard equipment,service alternative. Pas en equipment standard service au choix. Nicht serienmässig,ausführung für kundenienst- Werkstätten. No equipo standard,opcion de servicio. Attrezzatura non di serie, alternativa di assistenza.

Sida Page	Grupp Group	Pump, oljebehållare			Hydraulic pump, oil reservoir			Illustration 36423 1984-12	0500	
58	6									
Pos. Fig.	Antal/Quantity			Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
	1273 972	1273 973	1359 116							
1	1	-	-	-	1273972-8 Pump	Hydraulic pump		8	B17,B19,B21,B23,D20,24 ERS AV 1 ST 1359116-9	0020
	-	1	-	-	1273973-6 Pump	Hydraulic pump		5	B27,B28	0040
	-	-	1	-	1359116-9 Pump	Hydraulic pump		5		0060
2	1	1	1	-	.Hus	.Housing		8		0080
	1	-	1	-	.Drivaxelsats	.Drive shaft kit		8		0100
	-	1	-	-	273935-7 .Drivaxelsats	.Drive shaft kit		2		0120
3	1	1	1	-	..Drivaxel	..Drive shaft	S	4		0140
4	1	1	1	-	1272423-3 ..Låsring	..Lock ring	S	4		0160
	1	1	1	-	273881-3 .Låsingsats	.Lock ring kit		2		0180
6	1	1	1	-	464538-8 .Nav	.Hub		4		0200
7	1	1	1	-	1272412-6 .Tätning	.Seal		4		0240
	1	-	1	-	.Rotorsats	.Rotor kit		8		0260
	-	1	-	-	273901-9 .Rotorsats	.Rotor kit		2		0280
8	1	1	1	-	..Rotor	..Rotor	S	8		0300
9	1	1	1	-	..Vinge	..Vane	S	8		0320
10	1	1	1	-	..Ring	..Ring	S	8		
11	1	1	1	-	273905-0 .Ventilsats	.Valve kit		2		0340
12	1	1	1	-	..Ventil	..Valve	S	8		0380
13	1	1	1	-	.Fjäder	.Spring		8		0400
14	2	2	2	-	1272427-4 .Styrpinne	.Locating pin		4		0420
15	1	1	1	-	.Platta	.Plate		8		0440
16	1	-	1	-	1329586-0 .Platta	.Plate		8		0460
	-	1	-	-	1329588-6 .Platta	.Plate		4		0480
17	1	1	1	-	1329589-4 .Fjäder	.Spring		4		0500
	1	1	1	-	1272411-8 .Tätningssats	.Sealing kit		2		0520
18	1	1	1	-	..O-ring	..O-ring	S	8		0540
19	1	1	1	-	..O-ring	..O-ring	S	8		0560
20	2	2	2	-	..O-ring	..O-ring				0580
21	2	2	2	-	..O-ring	..O-ring				0600
22	1	1	1	-	1272431-6 ..Låsring	..Lock ring		4		0620
	1	-	1	-	1272422-5 .Oljebehållarsats	.Reservoir kit		3		0640
	-	1	-	-	273906-8 .Oljebehållarsats	.Reservoir kit		2		0660
23	1	1	1	-	..O-ring	..O-ring	S	8		0680
24	1	1	1	-	..O-ring	..O-ring	S	8		0700
25	1	1	1	-	..O-ring	..O-ring	S	8		0720
26	1	1	1	-	1272425-8 .Förskruvning	.Fitting		4		0740
27	1	1	1	-	1272426-6 .O-ring	.O-ring		4		0760
x 28	1	-	1	-	1330839-0 .Lock	.Cover		4		0780