



VOLVO
Genuine Parts
PV 435 44764

A	B	C	D	E	AUTOMATIC GEARBOX		AUTOMATVÄXELLÅDA		Group		
					AW70		Grupp				
1208481	1208482								43		
									Page		
									Sida		
									675		
Fig	Part No. Artikel nr	Quantity /Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	(1208481)	1	-	-	-	-	SP	Automatic gearbox	Automatväxellåda	REPL 1 PCS 1208359-8, 1 PCS 949656-3, 1 PCS 381385-4, 1 PCS 955271-2, 1 PCS 1220234-7	
	(1208482)	-	1	-	-	-	SP	Automatic gearbox	Automatväxellåda	REPL 1 PCS 1208411-7, 1 PCS 949656-3, 1 PCS 381385-4, 1 PCS 955271-2, 1 PCS 1220234-7	
	(1208485)	-	-	1	-	-	SP	Automatic gearbox	Automatväxellåda	REPL 1 PCS 1208418-2, 1 PCS 949656-3, 1 PCS 381385-4, 1 PCS 955271-2, 1 PCS 1220234-7	
2	1239686-7	-	-	1	-	-		•Torque converter	•Momentomvandlare		4
	1239882-2	1	1	-	-	-		•Torque converter	•Momentomvandlare		4
3	3502072-6	1	1	1	-	-		•Converter housing	•Momentomvandlarkåpa	(1239977)	5
4	1233328-2	2	2	2	-	-		•Safety net	•Skyddsnet		5
5	1239691-7	4	4	4	-	-		•Screw	•Skruv	LG 118 mm	3
	1239690-9	2	2	2	-	-		•Screw	•Skruv	LG 98 mm	3
6	941908-6	4	4	4	-	-		•Spring washer	•Fjäderbricka	D1 10.5 mm	2
	940280-1	2	2	2	-	-		•Spring washer	•Fjäderbricka	D1 13.5 mm	2
7		-	-	-	-	-	NS	•Gearbox housing	•Växellådshus		
		-	-	-	-	-		••Front planet gear pump housing - clutch housing	••Främre planetväxel- kopplingshus	SEE 43 • 689	
		-	-	-	-	-		••Centre wall - planet gear - output shaft	••Mellangavel- planetväxel- utgående axel	SEE 43 • 651	
☆ 8	6814812-1	1	1	1	-	-		•Sealing ring	•Tätningring	(1239689)	3
9	1340097-3	1	1	1	-	-		•Housing, rear	•Hus, bakre	(1340123)	5
10	235878-6	1	1	1	-	-		••Bushing	••Bussning		3
	235728-3	1	1	1	-	-	IK	•Sealing ring	•Tätningring		3
☆ 12	3520331-4	1	1	1	-	-	IK	•Gasket	•Packning	(1233137)	3
13	1239883-0	4	4	4	-	-		•Screw	•Skruv		4
	1239884-8	2	2	2	-	-		•Screw	•Skruv		4
14	1340099-9	1	-	-	-	-		•Control system ••SEE 43 • 705	•Kontrollsystem ••SEE 43 • 705		4
	1340105-4	-	-	1	-	-		•Control system ••SEE 43 • 705	•Kontrollsystem ••SEE 43 • 705		4
	1340098-1	-	1	-	-	-		•Control system ••SEE 43 • 705	•Kontrollsystem ••SEE 43 • 705		4
15	955272-0	2	2	2	-	-		•Screw	•Skruv	LG 20 mm	2
	955274-6	2	2	2	-	-		•Screw	•Skruv	LG 25 mm	2
	955275-3	5	5	5	-	-		•Screw	•Skruv	LG 30 mm	2
	955276-1	3	3	3	-	-		•Screw	•Skruv	LG 35 mm	2
	940101-9	1	1	1	-	-		•Screw	•Skruv	LG 40 mm	2
	1239826-9	1	1	1	-	-		•Screw	•Skruv	LG 47 mm	3
	955279-5	3	3	3	-	-		•Screw	•Skruv	LG 55 mm	2
15 a	941906-0	17	17	17	-	-		•Spring washer	•Fjäderbricka		2
16	1340136-9	1	1	1	-	-		•Intermediate section	•Mellanstycke		5
☆ 16 a	3520329-8	1	1	1	-	-	IK	•Gasket	•Packning	(1239828)	2
☆ 16 b	3520329-8	1	1	1	-	-	IK	•Gasket	•Packning	(1239828)	2
17	1239829-3	1	1	1	-	-		•Oil strainer	•Oljesil		5
18	955249-8	5	5	5	-	-		•Screw	•Skruv	LG 25 mm	2
19	941905-2	5	5	5	-	-		•Spring washer	•Fjäderbricka		2
20	1239930-9	-	1	-	-	-		•Control cable	•Reglagewire		4
	1340048-6	1	-	-	-	-		•Control cable	•Reglagewire		3
	1239932-5	-	-	1	-	-		•Control cable	•Reglagewire		4
21	1233141-9	1	1	1	-	-	IK	•O-ring	•O-ring		3

A		1208481					AUTOMATIC GEARBOX		AUTOMATVÄXELLÅDA		Group
B		1208482									Grupp
C											43
D											Page
E							AW70				Sida
Fig	Part No. Artikel nr	Quantity /Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
22		1	1	1	-	-		• Cam	• Kam	SEE 43-705	
23	1239744-4	1	1	1	-	-		• Shaft	• Axel		4
24	1239936-6	1	1	1	-	-		• Gear selector cam	• Växelväljarkam		3
25	1233098-1	1	1	1	-	-	IK	• Retaining ring	• Spårring		3
26	1239832-7	1	1	1	-	-		• Lock pin	• Låspinne		3
27	1233064-3	2	2	2	-	-		• Sealing ring	• Tätningssring		3
	1239658-6	1	1	1	-	-		• Sleeve	• Hylsa		4
28		1	1	1	-	-		• Locking spring	• Spärrfjäder	SEE 43-705	
29	1239880-6	1	1	1	-	-		• Parking pawl	• Parkeringsspärr		3
30	1233116-1	1	1	1	-	-		• Bearing bolt	• Lagerbult		3
31	1233117-9	1	1	1	-	-		• Retaining ring	• Spårring		3
32	1239750-1	1	1	1	-	-		• Torsion spring	• Vridfjäder		3
33	1239662-8	1	1	1	-	-		• Push rod	• Tryckstång		4
		1	1	1	-	-	NS	• Push rod	• Tryckstång		
34	1233121-1	1	1	1	-	-		• Spring	• Fjäder		4
35		1	1	1	-	-	NS	• Thrust sleeve	• Tryckhylsa		
36		1	1	1	-	-	NS	• Stop ring	• Anslagsring		
37	1239885-5	1	1	1	-	-		• Lock plate	• Låsplatta		4
38	955271-2	2	2	2	-	-		• Screw	• Skruv		2
39	941906-0	2	2	2	-	-		• Spring washer	• Fjäderbricka		2
40	1233415-7	1	1	1	-	-		• Sump	• Oljesump		4
40a	1239961-4	1	1	1	-	-		• Plug	• Plugg		2
40b	1239960-6	1	1	1	-	-	IK	• Sealing ring	• Tätningssring		2
41	235739-0	1	1	1	-	-		• Magnet	• Magnet		4
42	1239683-4	1	1	1	-	-	IK	• Gasket	• Packning		5
43	955271-2	14	14	14	-	-		• Screw	• Skruv	(955270)	2
44	941906-0	14	14	14	-	-		• Spring washer	• Fjäderbricka		2
45		1	1	1	-	-	NS	• Plug	• Propp		
46	1239928-3	1	1	1	-	-		• Solenoid	• Solenoid		3
47	955294-4	2	2	2	-	-		• Screw	• Skruv	LG 16 mm	2
48	941907-8	2	2	2	-	-		• Spring washer	• Fjäderbricka		2
49	1239834-3	1	1	1	-	-	IK	• O-ring	• O-ring		3
50	1239835-0	1	1	1	-	-	IK	• O-ring	• O-ring		3
51	1239699-0	1	1	1	-	-		• Clamp	• Klamma		4
52	1239698-2	1	1	1	-	-		• Clamp	• Klamma		4
53	955268-8	1	1	1	-	-		• Screw	• Skruv	LG 10 mm	2
54	941906-0	1	1	1	-	-		• Spring washer	• Fjäderbricka		2
55	1340038-7	1	1	1	-	-		• Pipe C1	• Rör C1		3
56	1239821-0	1	1	1	-	-		• Tube B0	• Rör B0		3
57	1340035-3	1	1	-	-	-	IK	• Spring	• Fjäder		4
	1239948-1	-	-	1	-	-	IK	• Spring 2nd, B2	• Fjäder 2:an, B2		4
58	1239576-0	1	-	1	-	-		• Piston 2nd, B2	• Kolv 2:an, B2		3
	1239823-6	-	1	-	-	-		• Piston 2nd, B2	• Kolv 2:an, B2		4
59	1239577-8	1	1	1	-	-	IK	• O-ring	• O-ring		3
60	1239578-6	1	1	1	-	-	IK	• O-ring	• O-ring		3
61	1239746-9	1	1	1	-	-	IK	• Spring 3rd, C2	• Fjäder 3:an, C2		4
62	1239825-1	1	1	1	-	-		• Piston 3rd, C2	• Kolv 3:an, C2		4
63	1239581-0	1	1	1	-	-	IK	• O-ring	• O-ring		3
64	1239582-8	1	1	1	-	-	IK	• O-ring	• O-ring		3
65	1239583-6	1	1	-	-	-	IK	• Spring 1st, C1	• Fjäder 1:an, C1		4
	1340060-1	-	-	1	-	-		• Spring 3rd, C2	• Fjäder 3:an, C2		4
66	1239584-4	1	1	1	-	-		• Piston 1st, C1	• Kolv 1:an, C1		4
67	1239585-1	1	1	1	-	-	IK	• O-ring	• O-ring		3
68	1239582-8	1	1	1	-	-	IK	• O-ring	• O-ring		3
		1	1	-	-	-	NS	Spring kit accumulator plunger	Fjädersats ackumulatorkolv		
		-	-	1	-	-	NS	Spring kit accumulator plunger	Fjädersats ackumulatorkolv		
		1	1	1	-	-		Sealing kit	Tätningssats	SEE 43-651	
		1	1	1	-	-		Gasket kit	Packningsats	SEE 43-651	