



© **VOLVO**
Genuine Parts
PV 233 51140

A			FUEL PUMP WITH FITTINGS		BRÄNSLEPUMP MED MONTERINGS- DETALJER		Group				
							Grupp				
							23				
							Page				
							Sida				
B			B200E, B230E, B28E		233						
C											
D											
E											
Fig	Part No. Artikel nr	Quantity /Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	1389447-2	1	-	-	-	-		Fuel pump	Bränslepump		3
2	1272072-8	1	-	-	-	-		Clamp	Klamma		3
3	956083-0	1	-	-	-	-		Screw	Skruv		2
4	1272073-6	1	-	-	-	-		Nut	Mutter		2
5	955269-6	2	-	-	-	-		Screw	Skruv		2
6	946035-3	2	-	-	-	-		Lock nut	Låsmutter		2
7	462547-1	1	-	-	-	-		Pressure accumulator	Tryckackumulator	B200E,B230E	4
	1269808-0	1	-	-	-	-		Pressure accumulator	Tryckackumulator	B28E	4
8	1255015-8	1	-	-	-	-		Spacer ring	Distansring	B200E,B230E	2
9	1255017-4	1	-	-	-	-		Clamp	Klamma		3
10	955271-2	1	-	-	-	-		Screw	Skruv		2
11	1255014-1	1	-	-	-	-		Bracket	Konsol		4
12	1255018-2	3	-	-	-	-		Rubber cushion	Gummikudde		2
13	1254720-4	1	-	-	-	-		Bracket	Konsol		4
14	1255042-2	1	-	-	-	-		Stay	Stag		3
15	944926-5	3	-	-	-	-		Flange screw	Flänskruv		2
16	1312257-7	X	-	-	-	-		Fuel hose	Bränsleslang	LG 950 mm	2
17	943472-1	2	-	-	-	-		Hose clamp	Slangklamma		2
☆ 18	1336649-7	X	-	-	-	-		Hose	Slang	(192034) LG 1000 mm	2
19	946709-3	2	-	-	-	-		Hose clamp	Slangklamma		2
20	1255255-0	1	-	-	-	-		Bracket	Konsol		4
21	947243-2	1	-	-	-	-		Screw	Skruv		2
22	952631-0	1	-	-	-	-		Clamp	Klamma		2
23	948211-8	2	-	-	-	-		Strip clamp	Bandklamma		2
24	1312320-3	1	-	-	-	-		Fuel pipe	Bränslerör		2
25	1272389-6	1	-	-	-	-		Nut	Mutter		2
☆ 26	947282-0	2	-	-	-	-		Gasket	Packning		2
27	1312287-4	1	-	-	-	-		Feed line	Tryckledning	L.H.D	3
	1312286-6	1	-	-	-	-		Feed line	Tryckledning	R.H.D	3
☆ 28	1389725-1	1	-	-	-	-		Absorber	Dämpare	1)	3

1) Service alternative. / Service alternativ.