



© **VOLVO**
 Genuine Parts
 PV 370 42715
 (104:3)

A							ELEC. DISTRIBUTION CENTRE, FUSEBOX AND FUSES		ELCENTRAL, SÄKRINGSDOSOR OCH SÄKRINGAR		Group Grupp
	B	C	D	E							37
											Page Sida
											525
Fig	Part No. Artikel nr	Quantity /Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
☆ 1	3515987-0	1	-	-	-	-		Fuse box	Säkringsdosa	(1347767)	3
2	273598-3	1	-	-	-	-		Fuse kit	Säkringsats		1
	942545-5	2	-	-	-	-		• Fuse	• Säkring	5A	1
	11433-0	4	-	-	-	-		• Fuse	• Säkring	8A	1
	942785-7	1	-	-	-	-		• Fuse	• Säkring	16A	1
	943905-0	1	-	-	-	-		• Fuse	• Säkring	25A	1
☆	11434-8	2	-	-	-	-		• Fuse	• Säkring	25A	1
3	965394-0	1	-	-	-	-		Screw	Skruv		2
4	955129-2	1	-	-	-	-		Screw	Skruv		2
5		1	-	-	-	-		Cover	Lock	SEE 85-1113	
6	1304368-2	1	-	-	-	-		Anchorage	Fäste		2
7	1304398-9	1	-	-	-	-		Clip	Clips		2
8	955131-8	1	-	-	-	-		Screw	Skruv		2
9	1235419-7	1	-	-	-	-		Fuse box	Säkringsdosa	(l). -1985	4
10								main and dipped beams	hel och halvljus		
10	955123-5	2	-	-	-	-		Screw	Skruv	(l). -1985	2
11	1258953-7	1	-	-	-	-		Bracket	Konsol	(l). -1985	3
12	965354-4	1	-	-	-	-		Screw	Skruv	(l). -1985	2
13	1234048-5	1	-	-	-	-		Junction box	Kopplingsdosa		3
14								Lower section	Underdel		
14	1234263-0	1	-	-	-	-		Terminal	Anslutningsstift		3
15	1234264-8	1	-	-	-	-		Cover	Lock		3
16	955127-6	2	-	-	-	-		Screw	Skruv		2
17	1323312-7	1	-	-	-	-		Fuse holder	Säkringshållare		3
☆ 18	969163-5	1	-	-	-	-		Blade fuse	Bladsäkring	(966330) 25A	1
19	966334-5	1	-	-	-	-		Fuse holder	Säkringshållare	4DRS CH 200094-215299. 5DRS CH 705540-718699.	4