



© **VOLVO**  
Genuine Parts  
PV 270 49480

A		B200E B230E					P	S	Description	Benämning	Notes Anmärkning	S	R
B		Quantity /Antal											
C		A	B	C	D	E							
D		B200E, B230E, B28E - 1985											
E													
									CRUISE CONTROL	KONSTANTFARTHÅLLARE		Group Grupp	
												27	
												Page Sida	
												351	
Fig	Part No. Artikel nr	A	B	C	D	E							
1	1333962-7	1	1	-	-	-		Cruise control kit .....	Konstantfarthållarsats .....			6	
2	1348132-0	1	1	-	-	-		• Regulator .....	• Regulator .....			4	
3	1272257	1	1	-	-	-	OP	• Cable harness .....	• Ledningsmatta .....			5	
4	1272796-2	1	1	-	-	-		• Servo unit .....	• Servoenhet .....			4	
5	1272259-1	1	1	-	-	-		• Connector .....	• Skarvdon .....			2	
6	1272260-9	1	1	-	-	-		• Vacuum valve .....	• Vakuumentil .....			4	
7	1272287-2	2	2	-	-	-		• Nut .....	• Mutter .....			2	
8	1272261-7	1	1	-	-	-		• Retardation breaker .....	• Retardationsbrytare .....			4	
9	1235238-1	1	1	-	-	-		• Switch .....	• Brytkontakt .....			3	
10	1235237-3	2	2	-	-	-		• Nut .....	• Mutter .....			2	
	1128725-7	1	-	-	-	-		Mounting kit .....	Monteringssats .....	L.H.D.		6	
								Cruise control	Konstantfarthållare				
	1188791-6	1	-	-	-	-		Mounting kit .....	Monteringssats .....	R.H.D.		4	
								Cruise control	Konstantfarthållare				
	1128724	-	1	-	-	-	OP	Mounting kit .....	Monteringssats .....	L.H.D.		6	
								Cruise control	Konstantfarthållare				
11	1272184-1	1	1	-	-	-		• Bracket .....	• Konsol .....			5	
12	40136-4	2	-	-	-	-		• Rubber bushing .....	• Gummibussning .....			2	
13	960136-0	2	-	-	-	-		• Washer .....	• Bricka .....			2	
14	947226-7	2	-	-	-	-		• Screw .....	• Skruv .....			2	
	190666-8	-	2	-	-	-		• Screw .....	• Skruv .....	L.H.D.		2	
15	1272183-3	1	1	-	-	-		• Bracket .....	• Konsol .....	L.H.D.		5	
	1188788-2	1	-	-	-	-		• Bracket .....	• Konsol .....	R.H.D.		5	
☆	16 969278-1	2	2	-	-	-		• Screw .....	• Skruv .....	(955138)		2	
	17 965395-7	2	2	-	-	-		• Screw .....	• Skruv .....			2	
	18 955120-1	2	2	-	-	-		• Screw .....	• Skruv .....			2	
☆	19 969473-8	1	-	-	-	-		• Screw .....	• Skruv .....	(955137)		2	
	20 955825-5	1	1	-	-	-		• Nut .....	• Mutter .....			2	
	21 955122-7	2	2	-	-	-		• Screw .....	• Skruv .....			2	
	22 1272270-8	1	1	-	-	-		• Nipple .....	• Nippel .....			3	
	23 1306703-8	-	X	-	-	-		• Hose .....	• Slang .....	(948958)		2	
										L.H.D LG 230 mm			
	1306703-8	X	-	-	-	-		• Hose .....	• Slang .....	(948958)		2	
										L.H.D LG 340 mm			
	1306703-8	X	-	-	-	-		• Hose .....	• Slang .....	(948958)		2	
										R.H.D LG 1250 mm			
24	948478-3	X	X	-	-	-		• Rubber hose .....	• Gummislang .....	L.H.D LG 1300 mm		2	
	948478-3	X	-	-	-	-		• Rubber hose .....	• Gummislang .....	R.H.D LG 1600 mm		2	
☆	25 975275-9	2	2	-	-	-		• Hose clamp .....	• Slangklamma .....	(943471)		2	
	26 1272182-5	1	-	-	-	-		• Throttle control cable .....	• Gasreglagewire .....	L.H.D.		3	
	1188787-4	1	-	-	-	-		• Throttle control cable .....	• Gasreglagewire .....	R.H.D.		1	
	1272181-7	-	1	-	-	-		Throttle control cable .....	Gasreglagewire .....	L.H.D.		3	
27	947515-3	1	1	-	-	-		• E-clip .....	• Spårryttare .....			2	
28	1272254-2	1	1	-	-	-		• Bracket .....	• Konsol .....	L.H.D.		5	
28a	1188794-0	1	-	-	-	-		• Bracket .....	• Konsol .....	R.H.D.		5	
29	955294-4	1	1	-	-	-		• Screw .....	• Skruv .....			2	
☆	30 968862-3	1	1	-	-	-		• Flange nut .....	• Flänsmutter .....	(955782)		8	
	31 1272245-0	1	1	-	-	-		• Bracket .....	• Konsol .....	L.H.D.		5	
	32 1188795-7	1	-	-	-	-		• Bracket .....	• Konsol .....	R.H.D.		5	
	33 941269-3	1	1	-	-	-		• Rubber bushing .....	• Gummibussning .....			2	
34		1	1	-	-	-		• Direction ind. switch .....	• Körvisaromkopplare .....	SEE 36-471			

A	B200E B230E					P	S	Description	Benämning	Notes Anmärkning	S									
	B	B28E										C	D	E	R					
		C														CRUISE CONTROL	KONSTANTFARTHÅLLARE			
			D																	
				E																
B200E, B230E, B28E - 1985																				
Group Grupp																				
27																				
Page Sida																				
353																				
35	948211-8	4	4	-	-	-	• Strip clamp .....	• Bandklamma .....			2									
36	1306240-1	1	-	-	-	-	• Throttle control .....	• Gasreglage .....			5									
	1269420-4	-	1	-	-	-	• Throttle control .....	• Gasreglage .....	L.H.D		5									
37	1306238-5	1	-	-	-	-	• Bracket .....	• Konsol .....			3									
	1269420-4	-	1	-	-	-	• Throttle control .....	• Gasreglage .....	(1274025) L.H.D		5									
39	1317544-3	1	-	-	-	-	• Control bobbin .....	• Reglagerulle .....			4									
	1274405-8	-	1	-	-	-	• Control bobbin .....	• Reglagerulle .....			2									
39a	1257291-3	1	1	-	-	-	• Ball stud .....	• Kulbult .....			3									
40	1306246-8	1	1	-	-	-	• Spring guide .....	• Fjäderstyrning .....	L.H.D.		2									
41	1274240-9	1	1	-	-	-	• Spring .....	• Fjäder .....			3									
42	1306244-3	1	1	-	-	-	• Spring .....	• Fjäder .....			2									
43	1306245-0	1	1	-	-	-	• Spring guide .....	• Fjäderstyrning .....			3									
44	1276512-9	2	2	-	-	-	• Bushing .....	• Bussning .....			2									
45	1274034-6	2	2	-	-	-	• Spring guide .....	• Fjäderstyrning .....			3									
46	1274031-2	2	2	-	-	-	• Spring .....	• Fjäder .....			2									
47	1274035-3	2	2	-	-	-	• Spring guide .....	• Fjäderstyrning .....			3									
48	1326370-2	1	1	-	-	-	• Control bobbin .....	• Reglagerulle .....	L.H.D		4									
	1326370-2	1	-	-	-	-	• Control bobbin .....	• Reglagerulle .....	R.H.D.		4									
49	1326195-3	1	1	-	-	-	• Control bobbin, upper .....	• Reglagerulle, övre .....	L.H.D		4									
	1326195-3	1	-	-	-	-	• Control bobbin, upper .....	• Reglagerulle, övre .....	R.H.D.		4									
50	955894-1	1	1	-	-	-	• Washer .....	• Bricka .....			2									
51	951669-1	1	1	-	-	-	• E-circlip .....	• Spårtrytare .....			2									
52	1259264-8	1	1	-	-	-	Induction sensor .....	Induktionsgivare .....	VDO		2									
	1308635-0	1	1	-	-	-	Induction sensor .....	Induktionsgivare .....	YASAKI		2									