



A	B	C	D	E	MASTER CYLINDER SERVO CYLINDER		HUVUDCYLINDER SERVOCYLINDER		Group		
					VACUUM PUMP		VAKUUMPUMP		Grupp		
									52		
									Page		
									Sida		
									795		
Fig	Part No. Artikel nr	Quantity /Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	(1272159)	1	-	-	-	-	SP	Servo cylinder .....	Servocylinder .....	1) ALTER 1 REPL 1 PCS 3516654-5	3
		-	-	-	-	-		•SEE 52-803 .....	•SEE 52-803 .....		
2	1229336-1	1	-	-	-	-		Servo cylinder .....	Servocylinder .....	2) ALTER 2	3
		-	-	-	-	-		•SEE 52-803 .....	•SEE 52-803 .....		
3	948645-7	4	-	-	-	-		Flange lock nut .....	Flänslåsmutter .....		2
4	1272078-5	1	-	-	-	-		Sealing ring .....	Tätningring .....		3
5	1330800-2	1	-	-	-	-		Master cylinder (outlet "a" on R.H. side) .....	Huvudcylinder (uttag "A" på höger sida) .....	ALTER 1	3
	1330799-6	1	-	-	-	-		Master cylinder (outlet "a" on L.H. side) .....	Huvudcylinder (uttag "A" på vänster sida) .....	ALTER 2	3
		-	-	-	-	-		•SEE 52-801 .....	•SEE 52-801 .....		
☆ 6	971089-8	2	-	-	-	-		Lock nut .....	Låsmutter .....	(963107)	2
7	1273052-9	1	-	-	-	-		Warning valve .....	Varningsventil .....		3
8		2	-	-	-	-	NS	•Plug .....	•Plugg .....		
9	1330797-0	2	-	-	-	-		•O-ring .....	•O-ring .....		2
10		1	-	-	-	-	KN	•Contact housing .....	•Kontakthus .....		
10a		1	-	-	-	-	KN	•Seal .....	•Tätning .....		
10b		1	-	-	-	-	KN	•Spring .....	•Fjäder .....		
10c		1	-	-	-	-	KN	•Pin .....	•Stift .....		
10d		1	-	-	-	-	KN	•Bushing .....	•Bussning .....		
11	941110-9	1	-	-	-	-		Screw .....	Skruv .....		2
12	960140-2	1	-	-	-	-		Washer .....	Bricka .....		2
13	1229684-4	1	-	-	-	-		Bracket .....	Konsol .....		4
14	948893-3	1	-	-	-	-		Flange screw .....	Flänsskruv .....		2
15	1228738-9	2	-	-	-	-		Reducing valve .....	Reducerventil .....	3) 4CYL TURBO,6CYL,DSL	3
	1228738-9	2	-	-	-	-		Reducing valve .....	Reducerventil .....	4) 4CYL	3
	1229148-0	2	-	-	-	-		Reducing valve .....	Reducerventil .....	3) 4CYL EXC TURBO	3
	1228688-6	2	-	-	-	-		Reducing valve .....	Reducerventil .....	4) 6CYL,DSL	3
16	1221757-6	1	-	-	-	-		Bracket .....	Konsol .....		4
17	963106-0	2	-	-	-	-		Lock nut .....	Låsmutter .....		2
18	941907-8	2	-	-	-	-		Spring washer .....	Fjäderbricka .....		2
19	940199-3	2	-	-	-	-		Screw .....	Skruv .....		2
20	1228559-9	1	-	-	-	-		Vacuum pump •SEE 52-807 .....	Vakuumpump •SEE 52-807 .....	B28E AUTO.TRANS	4
21	3514107-6	1	-	-	-	-		Gasket .....	Packning .....	(269883)	2
22	953045-2	4	-	-	-	-		Stud .....	Pinnskruv .....		2
23	941907-8	4	-	-	-	-		Spring washer .....	Fjäderbricka .....		2
☆ 24	968862-3	4	-	-	-	-		Flange nut .....	Flänsmutter .....	(955782)	8
25	1215591-7	1	-	-	-	-		Connector .....	Förbindningsstycke .....		5
26		-	-	-	-	-		Brake pedal with fittings .....	Bromspedal med monteringsdetaljer .....	SEE 52-805	
27	1257206-1	1	-	-	-	-		Vacuum booster .....	Vakuumförstärkare .....	DSL	4
28	953043-7	2	-	-	-	-		Stud .....	Pinnskruv .....	DSL	2
29	941907-8	2	-	-	-	-		Spring washer .....	Fjäderbricka .....	DSL	2
30	1328593-7	1	-	-	-	-		Sealing ring .....	Tätningring .....	DSL	3
31	1257207-9	1	-	-	-	-		Push rod .....	Stötstång .....	DSL	4
32	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 310 B230A,L.H.D	2
	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 375 B200K,B230K,L.H.D	2
	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 550 B230F,L.H.D	2
	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 500 B200E,B230E,L.H.D	2

- 1) 10 inch DBA, characteristic: hot galvanized (grey) / 10" DBA, kännetecken:varmförzinkad (grå)
- 2) 2x8 inch DBA, characteristic: unpainted / 2x8" DBA, kännetecken:omålad
- 3) Five-door cars. / Vagnar med 5 dörrar.
- 4) Four-door cars. / Vagnar med 4 dörrar.

A	B	C	D	E	MASTER CYLINDER SERVO CYLINDER VACUUM PUMP				HUVUDCYLINDER SERVOCYLINDER VAKUUMPUMP				Group Grupp				
																	52
																	Page Sida
																	797
Fig	Part No. Artikel nr	Quantity /Antal					P S	Description	Benämning	Notes Anmärkning							
		A	B	C	D	E											
	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 560 B200K,B230A,R.H.D							
	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 780 B230F							
	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 530 B200E,B230E,B230F,R.H.D							
33	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 640 DSL W/O COMBU							
34	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 250 DSL COMBU							
35	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 375 DSL COMBU							
36	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 375 B28E,MAN.TRANS							
37	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 250 B28E,AUTO.TRANS,R.H.D COMBU							
	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 530 B28E,AUTO.TRANS,R.H.D W/O COMBU							
38	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 250 B28E,AUTO.TRANS,R.H.D COMBU							
39	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 60 B28E,AUTO.TRANS							
40	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 95 B28E,AUTO.TRANS,L.H.D							
	1272328-4	X	-	-	-	-		Hose .....	Slang .....	LG 140 B28E,AUTO.TRANS,R.H.D							
41	1272121-3	X	-	-	-	-		Hose clamp .....	Slangklamma .....								
42	1221906-9	X	-	-	-	-		T-pipe .....	T-rör .....								
43	1229191-0	1	-	-	-	-		Four-way union .....	Fyrvägsförgrening .....	W/O COMBU							
44	1228272-9	1	-	-	-	-		Non-return valve .....	Backventil .....								
45	1276516-0	1	-	-	-	-		Rubber cap .....	Gummihatt .....	W/O COMBU							
46	948211-8	X	-	-	-	-		Strip clamp .....	Bandklamma .....								
	272723-8	1	-	-	-	-		Repair kit replacement of valves	Reparationssats byte av ventiler	DSL							
	272722-0	1	-	-	-	-		Repair kit replacement of seals	Reparationssats byte av tätningar	SEE 52•811 DSL							
	272702-2	-	-	-	-	-		Contact kit .....	Kontaktsats .....	SEE 52•809							