



© **VOLVO**  
Genuine Parts  
PV 230 41626  
(102:2)

A		B200E					FUEL SYSTEM		BRÄNSLESYSTEM		Group
B		B230E									Grupp
C											23
D											Page
E							B200E, B230E				Sida
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1		-	-	-	-	-		Injectors .....	Insprutare .....	SEE 23-171	
		-	-	-	-	-		Fuel pipe engine .....	Bränslerör motor .....	SEE 23-171	
		-	-	-	-	-		Fuel filter .....	Bränslefilter .....	SEE 23-171	
2	(1357446)	1	-	-	-	-	SP	Volumeter .....	Mängdmätare .....	REPL 1 PCS 1357450-4, 1 PCS 1266808-3.	
	(1357447)	-	1	-	-	-	SP	Volumeter .....	Mängdmätare .....	E.G.R REPL 1 PCS 1357450-4, 1 PCS 1357451-2.	
	(1357591)	-	1	-	-	-	SP	Volumeter .....	Mängdmätare .....	W/O E.G.R REPL 1 PCS 1357450-4, 1 PCS 1357666-5.	
								SEE 23-173	SEE 23-173		
3	1378490-5	1	1	-	-	-	IK	Gasket .....	Packning .....		2
4	1276524-4	1	1	-	-	-		Lower section .....	Underdel .....		4
5	942247-8	6	6	-	-	-		Screw .....	Skruv .....	(955138)	2
6	941906-0	6	6	-	-	-		Spring washer .....	Fjäderbricka .....		2
7	1276367-8	1	1	-	-	-		Bracket .....	Konsol .....		3
8	955296-9	2	2	-	-	-		Screw .....	Skruv .....		2
9	1219090-6	1	1	-	-	-		Bracket .....	Konsol .....		2
10	956000-4	1	1	-	-	-	IK	O-ring .....	O-ring .....		2
11	940142-3	2	2	-	-	-		Screw .....	Skruv .....		2
12	941907-8	2	2	-	-	-		Spring washer .....	Fjäderbricka .....		2
13	463515-7	3	3	-	-	-		Rubber cushion .....	Gummikudde .....		2
14	955782-8	3	3	-	-	-		Nut .....	Mutter .....		2
15	955894-1	3	3	-	-	-		Washer .....	Bricka .....		2
16	3517065-3	1	1	-	-	-		Starter valve .....	Startventil .....	(1276498)	2
17	949761-1	1	1	-	-	-	IK	O-ring .....	O-ring .....		2
18	942001-9	2	2	-	-	-		Screw .....	Skruv .....	(966802)	2
19	1219731-5	1	1	-	-	-		Thermo time sensor .....	Termotidgivare .....		2
20	463971-2	1	1	-	-	-		Control pressure valve .....	Styrtrycksventil .....		2
21	959207-2	2	2	-	-	-		Hex. socket screw .....	Insexskruv .....		2
22	941906-0	2	2	-	-	-		Spring washer .....	Fjäderbricka .....		2
23	1346476-3	1	1	-	-	-		Auxiliary air valve .....	Tillsatsluftventil .....	MAN.TRANS	2
	1346477-1	1	1	-	-	-		Auxiliary air valve .....	Tillsatsluftventil .....	AUTO.TRANS	2
24	942001-9	2	2	-	-	-		Screw .....	Skruv .....	(966802)	2
25	941906-0	2	2	-	-	-		Spring washer .....	Fjäderbricka .....		2
26	1306750-9	1	1	-	-	-		Hose .....	Slang .....		2
27	463804-5	1	1	-	-	-		Hose .....	Slang .....		2