



© **VOLVO**  
 Genuine Parts  
 PV 230 41629  
 (102:2)

A		B200E					INJECTOR WITH ENGINE FUEL PIPES AND FUEL FILTER		INSPRUTARE MED BRÄNSLERÖR MOTOR, BRÄNSLEFILTER		Group
B		B230E									Grupp
C											23
D											Page
E							B200E, B230E				Sida
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	1357088-2	1	1	-	-	-	Connecting pipe .....	Anslutningsrör .....		3	
2	943484-6	1	1	-	-	-	Hose clamp .....	Slangklamma .....	(947215)	2	
3	967765-9	1	1	-	-	-	Hose clamp .....	Slangklamma .....	(943480)	2	
4		1	1	-	-	-	Hose .....	Slang .....	SEE 25-221		
5		1	1	-	-	-	Air filter .....	Luftfilter .....	SEE 25-221		
6	1389562-8	1	1	-	-	-	Filter .....	Filter .....	(1389450)	1	
7	3514420-3	1	1	-	-	-	Bracket .....	Konsol .....	(1336338)	4	
8	948746-3	1	1	-	-	-	Flange screw .....	Flänsskruv .....	(946934) LG 16mm	2	
9	969278-1	1	1	-	-	-	Six point socket screw .....	Sextandhålskruv .....	(955138)	2	
10	947282-0	1	1	-	-	-	Gasket .....	Packning .....		2	
11	1276069-0	1	1	-	-	-	Nipple .....	Nippel .....		3	
13	1346225-4	1	1	-	-	-	Fuel pipe inlet .....	Bränslerör tillopp .....		3	
14	973950-9	1	1	-	-	-	Hollow screw .....	Hålskruv .....	(968178)	2	
15	947282-0	2	2	-	-	-	Gasket .....	Packning .....		2	
16	1346231-2	1	1	-	-	-	Fuel pipe return .....	Bränslerör retur .....		3	
17	973950-9	1	1	-	-	-	Hollow screw .....	Hålskruv .....	(968178)	2	
18	947282-0	2	2	-	-	-	Gasket .....	Packning .....		2	
19	1266343-1	1	1	-	-	-	Fuel pipe cold start valve .....	Bränslerör kallstartsventil .....		3	
20	966833-6	2	2	-	-	-	Hollow screw .....	Hålskruv .....		2	
21	947620-1	4	4	-	-	-	Gasket .....	Packning .....		2	
22	1266343-1	1	1	-	-	-	Fuel pipe .....	Bränslerör .....		3	
23	966833-6	1	1	-	-	-	Hollow screw .....	Hålskruv .....		2	
24	947620-1	2	2	-	-	-	Gasket .....	Packning .....		2	
25	968177-6	1	1	-	-	-	Hollow screw .....	Hålskruv .....		2	
26	947281-2	2	2	-	-	-	Gasket .....	Packning .....		2	
27	3517425-9	1	1	-	-	-	Fuel pipe .....	Bränslerör .....		3	
28	966833-6	1	1	-	-	-	Hollow screw .....	Hålskruv .....		2	
29	947620-1	2	2	-	-	-	Gasket .....	Packning .....		2	
30	966833-6	1	1	-	-	-	Hollow screw .....	Hålskruv .....		2	
31	947620-1	2	2	-	-	-	Gasket .....	Packning .....		2	
32	1219887-5	1	1	-	-	-	Fuel pipe cylinder 1 .....	Bränslerör cylinder 1 .....		3	
33	3547014-5	1	1	-	-	-	Fuel pipe cylinder 2 .....	Bränslerör cylinder 2 .....	(1266341)	3	
34	1219889-1	1	1	-	-	-	Fuel pipe cylinder 3 .....	Bränslerör cylinder 3 .....		3	
35	1219890-9	1	1	-	-	-	Fuel pipe cylinder 4 .....	Bränslerör cylinder 4 .....		3	
36	946235-9	1	1	-	-	-	• Nut .....	• Mutter .....		2	
37	966833-6	3	3	-	-	-	Hollow screw .....	Hålskruv .....		2	
38	966834-4	1	1	-	-	-	Hollow screw .....	Hålskruv .....	LG 24mm	2	
	966833-6	1	1	-	-	-	Hollow screw .....	Hålskruv .....	LG 16mm	2	
39	947620-1	8	8	-	-	-	Gasket .....	Packning .....		2	
40	1276037-7	4	4	-	-	-	Injection valve .....	Insprutningsventil .....		2	
41	947115-2	4	4	-	-	-	O-ring .....	O-ring .....		2	
42	463864-9	4	4	-	-	-	Retainer .....	Hållare .....		2	
43	947113-7	4	4	-	-	-	O-ring .....	O-ring .....		2	
44	955272-0	4	4	-	-	-	Screw .....	Skruv .....		2	
45	941906-0	4	4	-	-	-	Spring washer .....	Fjäderbricka .....		2	
46	948211-8	1	1	-	-	-	Strip clamp .....	Bandklamma .....	LG 75 mm	2	
	949668-8	1	1	-	-	-	Strip clamp .....	Bandklamma .....	LG 100 mm	2	
47	968179-2	1	1	-	-	-	Hollow screw .....	Hålskruv .....	L.H.D	2	
48	18838-3	2	1	-	-	-	Gasket .....	Packning .....	L.H.D	2	
49	948474-2	1	1	-	-	-	Nipple .....	Nippel .....	R.H.D	2	
50	18838-3	1	1	-	-	-	Gasket .....	Packning .....	R.H.D	2	