



VOLVO PARTS  
 1 040 20723  
 (104:4)

A	B	C	D	E	KOPPLING					KUPPLUNG					Grupp Gruppe
															41
															Sida Seite
															687
Pos	Artikel nr Artikelnr.	Antal /Anzani					P S	Benämning	Bezeichnung	Anmärkning Anmerkung	S R				
		A	B	C	D	E									
1	1232912-4	1	-	-	-	-		Koppling .....	Kupplung .....	(381207)	2				
2	1377562-2	1	-	-	-	-		Lamell .....	Lamelle .....	(381296) M50, M51	2				
	1209801-8	1	-	-	-	-		Lamell .....	Lamelle .....	(381297) M45, M46	2				
3		1	-	-	-	-	NS	• Lamellbeläggsats .....	• Lamellenbelagsatz .....	M50, M51.					
	275930	1	-	-	-	-	OP	• Lamellbeläggsats .....	• Lamellenbelagsatz .....	M45, M46.	2				
		2	-	-	-	-	KN	• • Belägg .....	• • Belag .....						
4		32	-	-	-	-	KN	• • Nit .....	• • Niet .....						
5	955295-1	6	-	-	-	-		Skruv .....	Schraube .....		2				
6		1	-	-	-	-		Pedalkåpa .....	Pedalgehäuse .....	SEE 52 • 931					
7	(1205727)	1	-	-	-	-	SP	Mutterplatta .....	Gewindeplatte .....	BW55 REPL 1PCS 1272393-8 1PCS 948645-7	2				
	1272393-8	1	-	-	-	-		• Täckbricka .....	• Abdeckscheibe .....		2				
	948645-7	2	-	-	-	-		• Flänslåsmutter .....	• Flanschverschlussmutter .....		2				
8	955293-6	2	-	-	-	-		Skruv .....	Schraube .....	BW 55	2				
9	1205719-6	1	-	-	-	-		Kopplingspedal .....	Kupplungspedal .....	L.H.D	5				
	1205721-2	1	-	-	-	-		Kopplingspedal .....	Kupplungspedal .....	R.H.D	5				
10	675555-7	2	-	-	-	-		Bussning .....	Buchse .....		4				
11	1206770-8	1	-	-	-	-		Axel .....	Welle .....		4				
12	1205725-3	1	-	-	-	-		Returfjäder .....	Ruckholfeder .....		2				
12a	1229285-0	1	-	-	-	-		Hylsa .....	Hülse .....		3				
13	(955333)	1	-	-	-	-	SP	Skruv .....	Schraube .....		2				
14	945654-2	1	-	-	-	-		Låsmutter .....	Sicherungsmutter .....		2				
15	1272021-5	1	-	-	-	-		Pedalskoning .....	Pedalbeslag .....	(666176)	3				
16	699856-1	X	-	-	-	-		Kantskyddslist .....	Schonleiste .....	LG 20 mm (672172)	2				
17	1205729-5	1	-	-	-	-		Huvudcylinder .....	Hauptzylinder .....		3				
		-	-	-	-	-		• SEE 41 • 691 .....	• SEE 41 • 691 .....						
18	946440-5	2	-	-	-	-		Flänsskruv .....	Flanschschraube .....		2				
19	955782-8	2	-	-	-	-		Mutter .....	Mutter .....		2				
20	913123-6	1	-	-	-	-		Ledtapp .....	Drehzapfen .....	ALTER 1.	2				
	947609-4	1	-	-	-	-		Bult .....	Bolzen .....	REPL 1 PCS 964843-7, 1 PCS 664822-4	2				
21	907824-7	1	-	-	-	-		Saxpinne .....	Splint .....	ALTER 1.	2				
	951669-1	1	-	-	-	-		Spårryttare .....	Nutenläufer .....	ALTER 2.	2				
22	1205730-3	1	-	-	-	-		Rör .....	Rohrleitung .....	L.H.D	3				
23	946814-1	X	-	-	-	-		Bundyrör .....	Bundy-rohr .....	LG 1500 mm R.H.D	2				
24	946816-6	1	-	-	-	-		Mutter .....	Mutter .....	R.H.D	2				
25	946815-8	1	-	-	-	-		Mutter .....	Mutter .....	R.H.D	2				
26	951188-2	2	-	-	-	-		Klamma .....	Klemme .....	R.H.D	2				
27	955140-9	2	-	-	-	-		Skruv .....	Schraube .....	R.H.D	2				
28	1228785-0	1	-	-	-	-		Konsol .....	Konsole .....		4				
29	1206840-9	1	-	-	-	-		Slang .....	Schlauch .....		3				
30	11994-1	1	-	-	-	-		Packning .....	Dichtung .....	CH-38889	2				
31	940143-1	1	-	-	-	-		Låsbricka .....	Sicherungsscheibe .....		2				
32	946830-7	1	-	-	-	-		Mutter .....	Mutter .....		2				
32a	952629-4	1	-	-	-	-		Klamma .....	Klemme .....		2				
32b	947243-2	1	-	-	-	-		Skruv .....	Schraube .....		2				
33	(1206239)	1	-	-	-	-	SP	Manövercylinder .....	Steuerzylinder .....	M50, M51 REPL 1 PCS 1272370-6	2				
								SEE 41 • 693	SEE 41 • 693						
	1272370-6	1	-	-	-	-		Manövercylinder .....	Steuerzylinder .....	M45, M46.	2				
								• SEE 41 • 693	• SEE 41 • 693						
34	940142-3	2	-	-	-	-		Skruv .....	Schraube .....		2				
35	381274-0	1	-	-	-	-		Urkopplingsgaffel .....	Ausruckgabel .....		3				
36	381280-7	1	-	-	-	-		Ledkula .....	Gelenkkugel .....	STD. TRANS M45, M46 M50, M51. SEE 43 • 715	4				
	381686-5	1	-	-	-	-		Ledkula .....	Gelenkkugel .....	O.S	4				
37	381213-8	1	-	-	-	-		Urkopplingslager .....	Ausrucklager .....		2				
38	381288-0	1	-	-	-	-		Gummikåpa .....	Gummimanschette .....		3				