



VOLVO PARTS  
 1 023 28016  
 (102:2)

A	B	C	D	E	BRÄNSLESYSTEM					KRAFTSTOFFANLAGE					Grupp Gruppe
					1975 B27E					Sida Seite					
Pos	Artikel nr Artikelnr.	Antal /Anzahl					P S	Benämning	Bezeichnung	Anmärkning Anmerkung	S R				
		A	B	C	D	E									
1	948211-8	1	-	-	-	-		Bandklamma .....	Bandklammer .....		2				
2	269245	1	-	-	-	-	OP	Mellanstycke .....	Einsatzstück .....	CH -APP 5500	3				
3	1218629-2	1	-	-	-	-		Gummibussning .....	Gummibuchse .....	CH -110.	2				
4	1218528	1	-	-	-	-	OP	Konsol .....	Konsole .....	CH -110	4				
5	955138-3	2	-	-	-	-		Skruv .....	Schraube .....	(955139) CH -110	2				
6	968178-4	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(74040) CH -110	2				
7	11994-1	2	-	-	-	-	IK	Packning .....	Dichtung .....	(947282) CH-110	2				
8	948198-7	1	-	-	-	-		Nippel .....	Nippel .....	CH 111- APP 5500	2				
9	11994-1	1	-	-	-	-	IK	Packning .....	Dichtung .....	REPL 1 PCS 948212-6 CH 111- APP 5500 (947282)	2				
10	948212-6	1	-	-	-	-		Rörkoppling .....	Rohrkupplung .....	CH APP 5500-	2				
11	269283-8	1	-	-	-	-		Bränslerör .....	Kraftstoffrohr .....		3				
12	966833-6	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(74033)	2				
13	947620-1	2	-	-	-	-	IK	Packning .....	Dichtung .....		2				
14	3517066-1	1	-	-	-	-		Startventil .....	Startmengenventil .....	(269292)	3				
15	947113-7	1	-	-	-	-	IK	O-ring .....	O-ring .....		2				
16	942001-9	2	-	-	-	-		Skruv .....	Schraube .....		2				
17	941906-0	2	-	-	-	-		Fjäderbricka .....	Federscheibe .....		2				
18	269244-0	1	-	-	-	-		Bränslerör .....	Kraftstoffrohr .....		3				
19	947975-9	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(947277)	2				
20	11994-1	3	-	-	-	-	IK	Packning .....	Dichtung .....	(947282)	2				
21	968178-4	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(74040)	2				
22	11994-1	2	-	-	-	-	IK	Packning .....	Dichtung .....	(947282)	2				
23	(269294)	1	-	-	-	-	SP	Mängdmätare • SEE 23 • 267 .....	Mengenmesser • SEE 23 • 267 .....	REPL 1 PCS 1269148-1,  1 PCS 243894-3, 1 PCS 462802-0. (1276809)	3				
24	1378490-5	1	-	-	-	-		Packning .....	Dichtung .....		2				
25	269215	1	-	-	-	-	OP	Underdel .....	Unterteil .....		4				
26	269298-6	1	-	-	-	-		Konsol, främre .....	Konsole, v .....		4				
27	269055	1	-	-	-	-	NS	Konsol .....	Konsole .....						
28	940326-2	6	-	-	-	-		Skruv .....	Schraube .....		2				
29	941906-0	6	-	-	-	-		Fjäderbricka .....	Federscheibe .....		2				
30	955271-2	4	-	-	-	-		Skruv .....	Schraube .....		2				
31	941906-0	4	-	-	-	-		Fjäderbricka .....	Federscheibe .....		2				
32	955892-5	2	-	-	-	-		Bricka .....	Scheibe .....		2				
33	269016-2	1	-	-	-	-		Anslutningsrör .....	Anschlussrohr .....		3				
34	943484-6	1	-	-	-	-		Slangklamma .....	Schlauchschelle .....		2				
35	943480-4	1	-	-	-	-		Slangklamma .....	Schlauchschelle .....		2				
36	269712-6	1	-	-	-	-		Bränslerör .....	Kraftstoffrohr .....	(269280)	3				
37	269710-0	3	-	-	-	-		CYLINDER 1 Bränslerör .....	CYLINDER 1 Kraftstoffrohr .....	(269278)	3				
38	269724-1	1	-	-	-	-		CYLINDER 2, 3, 5 Bränslerör .....	CYLINDER 2, 3, 5 Kraftstoffrohr .....	(269278)	3				
39	269711-8	1	-	-	-	-		CYLINDER 6 Bränslerör .....	CYLINDER 6 Kraftstoffrohr .....	(269279)	3				
40	966833-6	6	-	-	-	-		CYLINDER 4 Hålskrav .....	CYLINDER 4 Hohlschraube .....	(74033)	2				
41	947620-1	12	-	-	-	-	IK	Packning .....	Dichtung .....		2				
42	1269274-5	6	-	-	-	-		Insprutningsventil .....	Einspritzventil .....	(269184)	2				
43	1269275-2	6	-	-	-	-		Tätningring .....	Dichtring .....		2				
44	245372-8	6	-	-	-	-		Hållare .....	Halter .....		3				
45	245371-0	6	-	-	-	-		Clips .....	Klemme .....		3				
46	966833-6	6	-	-	-	-		Hålskrav .....	Hohlschraube .....	(74033)	2				
47	947620-1	12	-	-	-	-	IK	Packning .....	Dichtung .....		2				
48	269696-1	1	-	-	-	-		Bränslerör .....	Kraftstoffrohr .....	(269281)	3				
49	966833-6	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(74033)	2				
50	947620-1	2	-	-	-	-	IK	Packning .....	Dichtung .....		2				
51	968177-6	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(48634)	2				
52	18665-0	2	-	-	-	-	IK	Packning .....	Dichtung .....	(947281)	2				
53	269531-0	1	-	-	-	-		Styrtrycksventil .....	Steuerdruckregler .....	(269291)	3				

A	B	C	D	E	BRÄNSLESYSTEM					KRAFTSTOFFANLAGE					Grupp Gruppe
					1975 B27E					Sida Seite					
Pos	Artikel nr Artikelnr.	Antal /Anzahl					P S	Benämning	Bezeichnung	Anmärkning Anmerkung	S R				
		A	B	C	D	E									
50	941747-8	2	-	-	-	-		Skruv .....	Skrave .....		2				
51	941906-0	2	-	-	-	-		Fjäderbricka .....	Federscheibe .....		2				
52	269127-7	1	-	-	-	-		Bränslerör .....	Kraftstoffrohr .....	(269282) LG 390 mm	3				
53	966833-6	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(74033)	2				
54	947620-1	2	-	-	-	-	IK	Packning .....	Dichtung .....		2				
55	269243-2	1	-	-	-	-		Bränslerör .....	Kraftstoffrohr .....		3				
56	968178-4	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(74040)	2				
57	11994-1	2	-	-	-	-	IK	Packning .....	Dichtung .....	(947282)	2				
58	947975-9	1	-	-	-	-		Hålskrav .....	Hohlschraube .....	(947277)	2				
59	11994-1	3	-	-	-	-	IK	Packning .....	Dichtung .....	(947282)	2				
59a	1219815-6	X	-	-	-	-		Skydds slang .....	Schutzschlauch .....	I.DIA 6 mm	3				
								Ledning .....	Leitung .....						
	1219816-4	X	-	-	-	-		Skydds slang .....	Schutzschlauch .....	I.DIA 9.5 mm	3				
								Ledning .....	Leitung .....						
59b	948211-8	8	-	-	-	-		Bandklamma .....	Bandklammer .....	(948210)	2				
60	269180-6	1	-	-	-	-		Slang .....	Schlauch .....		3				
61		1	-	-	-	-		T-rör .....	T-stück .....	SEE 28-479					
62		1	-	-	-	-		Slang .....	Schlauch .....	SEE 28-479					
62a	943473-9	2	-	-	-	-		Slangklamma .....	Schlauchschele .....		2				
63		2	-	-	-	-		Slang .....	Schlauch .....	SEE 28-479					
64		1	-	-	-	-		Tillsatsluftventil .....	Zusatzluftventil .....	SEE 28-479					
65		2	-	-	-	-		Skruv .....	Skrave .....	SEE 28-479					
66		2	-	-	-	-		Fjäderbricka .....	Federscheibe .....	SEE 28-479					
67	269110-3	1	-	-	-	-		Ventilhus .....	Ventilgehäuse .....		3				
67a	947099-8	1	-	-	-	-	IK	• O-ring .....	• O-ring .....		2				
67b	237568-1	1	-	-	-	-		• Propp .....	• Stöpsel .....		2				
68	269181-4	1	-	-	-	-		Slang .....	Schlauch .....		3				
69	269297-8	1	-	-	-	-		Fördelningshus .....	Verteilerdose .....		3				
70	942390-6	X	-	-	-	-		Slang .....	Schlauch .....	2 PCS LG 35 mm	2				
71	943469-7	1	-	-	-	-		Slangklamma .....	Schlauchschele .....	(945652)	2				
72	1266500-6	X	-	-	-	-		Bränsleslang .....	Kraftstoffschlauch .....	LG 750 mm	2				
										(419796) L.H.D					
73	943469-7	1	-	-	-	-		Slangklamma .....	Schlauchschele .....	(945652) W/O COMBU	2				
										R.H.D					
74	947462-8	1	-	-	-	-		T-rör .....	T-stück .....	COMBU	2				
76	943472-1	1	-	-	-	-		Slangklamma .....	Schlauchschele .....	COMBU	2				
										(947908) COMBU					
77	1219731-5	1	-	-	-	-		Termotidgivare .....	Thermo-zeitschalter .....		3				
78	269314-1	1	-	-	-	-		Mellanstycke .....	Einsatzstück .....		3				
79	947624-3	1	-	-	-	-	IK	Packning .....	Dichtung .....		2				
80		1	-	-	-	-		Kolfilter .....	Kohlefilter .....	1) SEE 23-271					
81	273674-2	1	-	-	-	-		Monteringssats .....	Einbausatz .....		3				
82	464916-6	1	-	-	-	-		• Bränslerör .....	• Kraftstoffrohr .....		3				
83	968177-6	1	-	-	-	-		• Hålskrav .....	• Hohlschraube .....	(48634)	2				
84	18665-0	2	-	-	-	-		• Packning .....	• Dichtung .....	(947281)	2				
85	464875-4	1	-	-	-	-		• Nippel .....	• Nippel .....		3				
86	18665-0	1	-	-	-	-		• Packning .....	• Dichtung .....	(947281)	2				
87	966833-6	1	-	-	-	-		• Hålskrav .....	• Hohlschraube .....	(74033)	2				
88	947620-1	2	-	-	-	-		• Packning .....	• Dichtung .....		2				
89	464914-1	1	-	-	-	-		• Magnetventil .....	• Magnetventil .....		2				
90	955268-8	2	-	-	-	-		• Skruv .....	• Skrave .....		2				
91	955294-4	1	-	-	-	-		• Skruv .....	• Skrave .....		2				
92	955894-1	1	-	-	-	-		• Bricka .....	• Scheibe .....		2				
93	464876	1	-	-	-	-	OP	Konsol .....	Konsole .....		4				

1) Med bensinavdunstningskontrolli. / Mit Benzinverdunstungskontrolle.