

A	1273236 L.H.D					STYRVÄXEL	LENKGETRIEBE	Grupp Gruppe			
	B	1273237 R.H.D							64		
C								Sida Seite			
D								995			
E						P.S					
Pos	Artikel nr Artikelnr.	Antal /Anzahl					P S	Benämning	Bezeichnung	Anmärkning Anmerkung	S R
		A	B	C	D	E					
1	1273236-8 (1273237)	1	-	-	-	-	SP	Styrväxel	Lenkgetriebe		5
2		-	1	-	-	-	NS	Styrväxel	Lenkgetriebe		5
3	1206922-5	1	1	-	-	-		• Hus	• Gehäuse		2
4	1228963-3	1	1	-	-	-		•• Lager	•• Lager		4
5	1272939-8	1	1	-	-	-	IK	•• Tätning	•• Dichtung		4
6	1273593-2	1	1	-	-	-	IK	•• Stödtring	•• Stutzring	(1272940)	4
7	1272933-1	1	1	-	-	-	IK	• Tätning	• Dichtung		4
8	1272936-4	1	1	-	-	-	IK	• Bussning	• Buchse		4
9	1272943-0	1	1	-	-	-	IK	• Låstråd	• Säkerhetsdraht		4
10	1359701-8	1	1	-	-	-	IK	• Kolvring	• Kolbenring	(1206904)	3
11	1359700-0	1	1	-	-	-	IK	• O-ring	• O-ring	(1206994)	2
12	1272944-8	1	-	-	-	-		• Kuggstång	• Zahnstange		4
	1272945-5	-	1	-	-	-		• Kuggstång	• Zahnstange		4
13		1	1	-	-	-	NS	• Ventil	• Ventil		
14	1272467-0	1	1	-	-	-	IK	•• Lock	•• Deckel		4
15	1206947-2	1	1	-	-	-		••• Lager	••• Lager		3
16	1272468-8	1	1	-	-	-	IK	••• Dammskydd	••• Staubschutz		4
17	1206996-9	1	1	-	-	-	IK	•• O-ring	•• O-ring		4
18	1273918-1	1	1	-	-	-	IK	•• Tryckfjäder	•• Druckfeder		4
19	955304-1	3	3	-	-	-		•• Skruv	•• Schraube		2
20	1272858-0	1	-	-	-	-		• Ventilhus	• Ventilgehäuse		4
	1272859-8	-	1	-	-	-		• Ventilhus	• Ventilgehäuse		4
21	1206983-7	1	1	-	-	-		• Spårring	• Nutring		4
22	1229008-6	1	-	-	-	-		•• Kuggdrev	•• Zahnradgetriebe		4
	1229009-4	-	1	-	-	-		•• Kuggdrev	•• Zahnradgetriebe		4
23	1272926-5	1	1	-	-	-	IK	• Ansättningskolv	• Ansetzkolben		4
24	1206921-7	1	1	-	-	-		• Lock	• Deckel		4
25	1329652-0	1	1	-	-	-	IK	• Fjäder	• Feder	(1272971)	3
26	1272972-9	X	X	-	-	-	IK	• Justerbleck	• Nachstellblech		4
	1272973-7	X	X	-	-	-	IK	• Justerbleck	• Nachstellblech		4
	1272974-5	X	X	-	-	-	IK	• Justerbleck	• Nachstellblech		4
	1272975-2	X	X	-	-	-	IK	• Justerbleck	• Nachstellblech		4
	1272976-0	X	X	-	-	-	IK	• Justerbleck	• Nachstellblech		4
27	955296-9	4	4	-	-	-		• Skruv	• Schraube		2
28	1206997-7	1	1	-	-	-	IK	• O-ring	• O-ring		4
29	1206932-4	1	1	-	-	-		• Lock	• Deckel		4
30	963917-0	1	1	-	-	-		• Mutter	• Mutter	(1206975)	2
31	1206979-5	1	1	-	-	-	IK	• Låsbricka	• Säkeringsskiva		4
32	1228966-6	1	1	-	-	-		• Kullager	• Kugellager		3
33	1273394-5	2	2	-	-	-	IK	• Packning	• Dichtung		4
34	1273393-7	1	1	-	-	-	IK	• Låsbricka	• Säkeringsskiva		4
35	1273392-9	1	1	-	-	-		• Spårring	• Nutring		4
36	1206998-5	1	1	-	-	-	IK	• O-ring	• O-ring		4
38	1272947-1	2	2	-	-	-		• Styrstag	• Lenkstange		2
39	1205658-6	2	2	-	-	-		• Styrstagsända	• Lenkstangenkopf		1
40	1272965-3	1	-	-	-	-		• Oljerör	• Ölrohr		4
	1272967-9	-	1	-	-	-		• Oljerör	• Ölrohr		4
41	1272966-1	1	-	-	-	-		• Oljerör	• Ölrohr		4
	1272968-7	-	1	-	-	-		• Oljerör	• Ölrohr		4
42	1272941-4	1	1	-	-	-		• Överströmningsrör	• Überstromrohr		4
43	270881-6	1	1	-	-	-		Bälgsats	Bälgsatz		2
44		1	1	-	-	-	KN	• Skyddsbalg	• Schutzbalg		
45	1273389-5	1	1	-	-	-	IK	• Klamma	• Klemme		3
46	1329649-6	1	1	-	-	-	IK	• Klamma	• Klemme	(1273391)	3
47	961977-6	1	1	-	-	-	IK	• Mutter	• Mutter		2
48	270882-4	1	1	-	-	-		Bälgsats	Bälgsatz		2
49		1	1	-	-	-	KN	• Skyddsbalg	• Schutzbalg		
50	1273390-3	1	1	-	-	-	IK	• Klamma	• Klemme		3
51	1329649-6	1	1	-	-	-	IK	• Klamma	• Klemme	(1273391)	3
52	961977-6	1	1	-	-	-	IK	• Mutter	• Mutter		2
	271547-2	1	1	-	-	-		Reparationssats	Reparatursatz	SEE 64 • 1001	2