



VOLVO PARTS
1040 16603

| Sida Page | Grupp Group | CVT, primär . Remskiva, kmpl | CVT, primary . Pulley, cpl | Illustration 16603 1984-12 | 0375 | | | | | |
|--------------|----------------|---------------------------------|-------------------------------|----------------------------------|-----------------------|-----------------------|-------------|------------------|---------------------|------|
| 30 | 4 | | | | | | | | | |
| Pos. Fig. | Antal/Quantity | | | Artikel nr Part No | Benämning | Description | Sats Kit | B P S R | Anmärkning Notes | |
| | | | | | | | | | | |
| 1 | 2 | - | - | 3290627-3 | Remskiva..... | Pulley..... | | 3 | | 0020 |
| 2 | 2 | - | - | 3103992-8 | Oljetätning..... | Oil seal..... | | 3 | | 0040 |
| 3 | 2 | - | - | 3103990-2 | O-ring..... | O-ring..... | | 3 | | 0060 |
| 4 | 2 | - | - | 3291442-6 | Remskiva..... | Pulley..... | | 5 | | 0080 |
| 5 | 2 | - | - | 3291977-1 | Diskfjäder..... | Disc-spring..... | | 5 | | 0100 |
| 6 | 2 | - | - | 3293557-9 | Hylsa..... | Sleeve..... | | 5 | (3293556) | 0120 |
| 7 | 8 | - | - | 3293558-7 | Nållager..... | Needle bearing..... | | 3 | | 0140 |
| 8 | 4 | - | - | 3293555-3 | Axel..... | Shaft..... | | 5 | | 0160 |
| 9 | 8 | - | - | 3103160-2 | Låsbricka..... | Lock washer..... | | 6 | | 0180 |
| 10 | 4 | - | - | 3293709-6 | Vikt..... | Weight..... | | 5 | | 0200 |
| 11 | 4 | - | - | 3101691-8 | Fjäder..... | Spring..... | | 5 | | 022 |
| 12 | 2 | - | - | 3105466-1 | Ring..... | Ring..... | | 3 | | 0240 |
| 13 | 2 | - | - | 3100997-0 | Membran..... | Diaphragm..... | | 3 | | 0260 |
| 14 | 2 | - | - | 3102805-3 | Hus..... | Housing..... | | 5 | | 0280 |
| 15 | 2 | - | - | 3103953-0 | Tättningsbricka..... | Seal washer..... | | 3 | | 0300 |
| 16 | 2 | - | - | 6629799-5 | Fjädrande bricka..... | Resilient washer..... | | 2 | | 0320 |
| 17 | 2 | - | - | 3103818-5 | Mutter..... | Nut..... | | 2 | | 034 |
| 18 | 2 | - | - | 3103963-9 | Tättningsring..... | Oil seal..... | | 3 | | 0360 |
| 19 | 2 | - | - | 3101300-6 | Ring..... | Ring..... | | 3 | | 0380 |
| 20 | 2 | - | - | 914446-0 | Låsring..... | Circlip..... | | 2 | | 0400 |
| 21 | 2 | - | - | 181717-0 | Lager..... | Bearing..... | | 3 | | 0420 |
| 22 | 2 | - | - | 914515-2 | Låsring..... | Circlip..... | | 2 | | 0440 |
| 23 | 2 | - | - | 3102806-1 | Lock..... | Cover..... | | 4 | | 0460 |
| 24 | 2 | - | - | 3103809-4 | Låsring..... | Circlip..... | | 3 | | 0480 |
| 25 | 2 | - | - | 914515-2 | Låsring..... | Circlip..... | | 2 | | 0500 |
| 26 | 2 | - | - | 181717-0 | Lager..... | Bearing..... | | 3 | | 0520 |
| 27 | 2 | - | - | 914446-0 | Låsring..... | Circlip..... | | 2 | | 0540 |
| 28 | 2 | - | - | 3103897-9 | Tättningsring..... | Oil seal..... | | 3 | | 0560 |
| 29 | 2 | - | - | 3101299-0 | Axel..... | Shaft..... | | 4 | | 0580 |