



VOLVO PARTS
 1023 17231

Sida Page	Grupp Group	Bränsletank med monteringsdetaljer	Fuel tank with installation components	Illustration	0100						
16	2c	B14	B14	17231 1984-12							
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
1	1	-	-	-	3273118-4	Bränsletank.....	Fuel tank.....	4		EXCL ACTION MODEL SPRING 84	0020
	1	-	-	-	3295650-0	Bränsletank.....	Fuel tank.....	4		ACTION MODEL SPRING 84	0022 0025 0027
2	4	-	-	-	955299-3	Skruv.....	Screw.....	2			0040
3	4	-	-	-	955921-2	Fjäderbricka.....	Spring washer.....	2			0060
4	4	-	-	-	3297074-1	Fjäderbricka.....	Spring washer.....	3	(3103763)		0080
5	4	-	-	-	3102649-5	Distansrör.....	Distance pipe.....	2			0100
6	4	-	-	-	3100848-5	Gummimellanlägg.....	Rubber spacer.....	3			0120
7	4	-	-	-	3102722-0	Gummimellanlägg.....	Rubber spacer.....	3			0140
8	1	-	-	-	3140686-1	Tankarmatur.....	Fuel gauge sender.....	2		SMITH	0160
	1	-	-	-	3205815-8	Tankarmatur.....	Fuel gauge sender.....	2		VDO, 4E, 4S	01
8a	1	-	-	-	3277476-2	.Filter.....	.Filter.....	2			0170
9	1	-	-	-	3140782-8	Packning.....	Gasket.....	2			0180
10	ERF	-	-	-	192034-7	Slang.....	Rubber hose.....	2			0200
11	1	-	-	-	3140690-3	Slang.....	Rubber hose.....	2			0220
12	2	-	-	-	947331-5	Slangklammer.....	Hose clamp.....	2			0240
13	ERF	-	-	-	946709-3	Slangklammer.....	Hose clamp.....	2			02
14	1	-	-	-	3140783-6	Packning.....	Gasket.....	2			0200
15	1	-	-	-	3273014-5	Slang.....	Rubber hose.....	3			0300
16	2	-	-	-	943480-4	Slangklammer.....	Hose clamp.....	2	(3103310)		0320
17	1	-	-	-	3273252-1	Påfyllningsrör.....	Filler tube.....	4	CH -614468		0340
17a	1	-	-	-	3273253-9	.Lockhållare.....	.Cap retainer.....	3			0345
18	1	-	-	-	3273251-3	Lock.....	Cap.....	1	CH -614468		0360
18a	1	-	-	-	3273104-4	.Packning.....	.Seal ring.....	2			0370
19	ERF	-	-	-	3273271-1	Slang.....	Hose.....	3			0380
20	ERF	-	-	-	945652-6	Slangklammer.....	Hose clamp.....	2	(3269017)		0400
21	ERF	-	-	-	3272720-8	Slang.....	Hose.....	2			0420
22	1	-	-	-	3272726-5	Genomföring.....	Grommet.....	2			0440
23	1	-	-	-	3140677-0	Genomföring.....	Grommet.....	3			0460
24	1	-	-	-	3273015-2	Genomföring.....	Grommet.....	3			0480
25	1	-	-	-	948211-8	Slangklammer.....	Hose clamp.....	2			0500
26	1	-	-	-	284430-6	Lock med två nycklar.....	Cap with two keys.....	6	ACC, CH -609999		0520
	1	-	-	-	284678-0	Lock med två nycklar.....	Cap with two keys.....	2	ACC, CH 610000-		0525
27	2	-	-	-	3273922-9	Hylsa.....	Bush.....	2			0540
28	2	-	-	-	3273923-7	Hylsa.....	Bush.....	2			0560
29	1	-	-	-	3102808-7	Bränsleledning.....	Fuel pipe.....	6	(3140687)		0580
30	1	-	-	-	3140692-9	Bränsleledning.....	Fuel pipe.....	3			0600
31	5	-	-	-	3269012-5	Klamma.....	Clamp.....	2			06
32	1	-	-	-	3273610-0	Clips.....	Clip.....	2	SWEDEN		0640
33	2	-	-	-	3272594-7	Konsol.....	Bracket.....	4	DI 6MM		0660
	2	-	-	-	3273361-0	Konsol.....	Bracket.....	4	DI 5MM		0680
34	1	-	-	-	3285113-1	Lock.....	Cap.....	1	CH 614469-		0700
35	1	-	-	-	3273104-4	.Packning.....	.Gasket.....	2			0720
36	1	-	-	-	3298395-9	Påfyllningsrör.....	Filler tube.....	4	CH 614469-		07
37	1	-	-	-	3273253-9	.Lockhållare.....	.Cap retainer.....	3			0700
38	2	-	-	-	3273610-0	Clips.....	Clip.....	2			0780
39	1	-	-	-	3298367-8	Expansionstank.....	Expansion tank.....	4	CH 614469-		0800
40	1	-	-	-	3283842-7	Insats.....	Insertion.....	4	CH 614469-		0820
41	1	-	-	-	3298368-6	T-rör.....	T-pipe.....	3	CH 614469-		0840
42	1	-	-	-	3298366-0	Ventil.....	Valve.....	3	CH 614469-		0860
43	1	-	-	-	960137-8	Bricka.....	Washer.....	2			0880
44	1	-	-	-	3106714-3	Skruv.....	Screw.....	6			0900
45	1	-	-	-	3286028-0	Mutter.....	Nut.....	3	(3103970)		0920
46	1	-	-	-	3200212-3	Clips.....	Clip.....	2			0940
47	2	-	-	-	967919-2	Slangklammer.....	Hose clamp.....	2			0960
48	ERF	-	-	-	3284126-4	Slang.....	Hose.....	2			0980
49	1	-	-	-	3273922-9	Rör.....	Pipe.....	2			1000
50	ERF	-	-	-	946234-2	Slang.....	Hose.....	2			1020
51	1	-	-	-	3272726-5	Genomföring.....	Grommet.....	2			1040