



VOLVO PARTS
1030 17446

Sida Page	Grupp Group	Strömförsörjnings-och startsystem	Power and starter system	Illustration							
10	3	B19	B19	17446	0125						
				1984-12							
Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
1	1	-	-	-	1306792-1	Tändfördelare	Distributor		3	B19A, CH -810500	0010
						Det se sida 24, 1-H11	Comps page 24, 1-H11				0015
1	1	-	-	-	1317298-6	Tändfördelare	Distributor		3	B19A, CH 810501-	0020
						Det se sida 26, 1-H13	Comps page 26, 1-H13				0030
	1	-	-	-	1326626-7	Tändfördelare	Distributor		3	B19E, CH-810500	0033
						.Det se sida 28, 1-H15	.Comps page 28, 1-H15				0034
	1	-	-	-	1336695-0	Tändfördelare	Distributor		3	B19E, CH 810501-	0035
2	1	-	-	-	949659-7	O-ring	O-ring		S	(925065)	0040
3	1	-	-	-	955296-9	Skruv	Screw		2		0060
4	1	-	-	-	960141-0	Bricka	Washer		2		0080
5	1	-	-	-	1219680-4	Positionsgivare	Position sender		3	EUROPE	0100
	1	-	-	-	1219678-8	Positionsgivare	Position sender		3	SWEDEN	0120
6	1	-	-	-	1219674-7	Konsol	Bracket		4		0140
7	1	-	-	-	948305-8	Hylsisolator	Sleeve insulator		2		0160
8	1	-	-	-	1219677-0	Skyddslock	Protector cover		2		0180
9	ERF	-	-	-	948958-4	Vakuumslang	Vacuum hose		2		0200
10	-	-	-	-		Tändspole, kmpl	Ignition coil, cpl		8		0210
10a	1	-	-	-	1219230-8	.Tändspole	.Ignition coil		2	B19A	0220
	1	-	-	-	3285229-5	.Tändspole	.Ignition coil		2	B19E	0225
10b	1	-	-	-	3285889-6	.Konsol	.Support		4		0230
11	1	-	-	-	3270157-5	Skruv	Screw		2		0240
12	1	-	-	-		Ratt-och startlås	Column lock and ignition switch			SE SIDA 80, 1-J19	0260
13	1	-	-	-	273597-5	Tändstiftssats	Sparking plug kit		S	B19A	0300
	1	-	-	-	273596-7	Tändstiftssats	Sparking plug kit		1	B19E	0305
	4	-	-	-		.Tändstift	.Sparking plug		S		0320
14	1	-	-	-	275693-0	Tändledningssats	Ignition cable kit		1	CH-609999	0340
	1	-	-	-	275694-8	Tändledningssats	Ignition cable kit		1	B19A CH 610000-810500	0341
	1	-	-	-	275695-5	Tändledningssats	Ignition cable kit		1	B19A CH 810501-	0342
	1	-	-	-	275696-3	Tändledningssats	Ignition cable kit		1	B19E	0343
15	1	-	-	-		.Tändledning	.Ignition cable		S		0360
16	2	-	-	-	954513-8	..Ledningssko	..Cable terminal		S		0380
17	2	-	-	-	241608-9	..Skyddsmuff	..Cap		S		0400
18	2	-	-	-	461385-7	..Dämpmotstånd	..Damping resistance		S		0420
19	4	-	-	-		.Tändledning	.Ignition cable		S		0440
20	4	-	-	-	954513-8	..Ledningssko	..Cable terminal		S		0460
21	4	-	-	-	241608-9	..Skyddsmuff	..Cap		1		0480
22	4	-	-	-	463727-8	..Dämpmotstånd	..Damping resistance		S		0500
23	1	-	-	-	463858-1	Konsol	Bracket		2		0520
24	2	-	-	-	1266019-7	Hållare	Holder		2		0540
25	1	-	-	-	1266020-5	Hållare	Holder		2		0560
26	2	-	-	-	955352-0	Skruv	Screw		2		0580
27	2	-	-	-	940280-1	Fjädrande bricka	Resilient washer		2		0600
28	2	-	-	-	955784-4	Mutter	Nut		2		0620
29	-	-	-	-		Växelströmgenerator med upphängning	Alternator mounting			SE SIDA 40, 1-103	0640
30	1	-	-	-		Laddningsregulator	Charging relay			SE SIDA 40, 1-103	0650
31	1	-	-	-		Ledning, tändspole- brytare	Low-tension cable		8	B19A	0700
32	2	-	-	-	949210-9	.Ledningssko	.Cable terminal		1	(956953)	0720
33	1	-	-	-	959046-4	.Ledningsskoskydd	.Cable terminalcap		2		0760
34	1	-	-	-	1308914-9	Batteri torrladdat	Battery dry charged		1	55 AH, (3277968)	0780
	1	-	-	-	1308743-2	Batteri	Battery		1	55AH, (3279722)	0800
35	1	-	-	-	3279721-9	Fastplåt	Anchorage plate		4		0820
36	1	-	-	-	955271-2	Skruv	Screw		2		0860
37	2	-	-	-	3102946-5	Bricka	Washer		2		0880
38	1	-	-	-	3279734-2	Batteriledning, +	Battery cable, +		3	B19A	0900
	1	-	-	-	3285393-9	Batteriledning, +	Battery cable, +		3	B19E	0905
39	1	-	-	-	3265993-0	.Skruv	.Screw		2		0920
40	1	-	-	-	3202879-7	.Mutter	.Nut		2		0940
41	1	-	-	-	3269889-6	Batteriledning	Battery cable		3	(3279723)	0960
42	1	-	-	-	3265993-0	.Skruv	.Screw		2		0980

