



VOLVO PARTS
 1060 17201

| Sida Page | Grupp Group | Styrkolonn | Steering column | Illustration | 17201 1984-12 | 0100 | | | | |
|-----------|----------------|------------|-----------------|--------------------|--------------------|-----------------------|----------|------------------|---|----------------------|
| 4 | 6 | | | | | | | | | |
| Pos. Fig. | Antal/Quantity | | | Artikel nr Part No | Benämning | Description | Sats Kit | B P S R | Anmärkning Notes | |
| 1 | 1 | - | - | 3290968-1 | Mutter | Nut | | 3 | | 0020 |
| 2 | - | - | - | | Ratt | Steering wheel | | | SE SIDA 22, 2-F23 SE SIDA 24, 2-G01 | 0040 0060 |
| 3 | 2 | - | - | 945494-3 | Låsring | Circlip | | 2 | | 0080 |
| 4 | 2 | - | - | 3290068-0 | Fjäder | Spring | | 3 | | 0100 |
| 5 | 2 | - | - | 3266719-8 | Ring | Ring | | 3 | | 0120 |
| 6 | 1 | - | - | 3266718-0 | Lager | Bearing | | 3 | | 0125 |
| 7 | 1 | - | - | 3280214-2 | Styrkolonn | Steering column | | 4 | B14 HST, CH-545499 B14 VST, B19 VST, CH-709999 | 0140 0142 0143 |
| | 1 | - | - | 3288612-9 | Styrkolonn | Steering column | | 4 | VST, CH 710000- | 0145 |
| | 1 | - | - | 3280520-2 | Styrkolonn | Steering column | | 4 | HST, CH 545500-709999 | (|
| | 1 | - | - | 3288613-7 | Styrkolonn | Steering column | | 4 | HST, CH 710000- | 0165 |
| 8 | 1 | - | - | 955294-4 | Skruv | Screw | | 2 | | 0280 |
| 9 | 1 | - | - | 946036-1 | Mutter | Nut | | 2 | | 0300 |
| 10 | 4 | - | - | 955271-2 | Skruv | Screw | | 2 | | 0320 |
| 11 | 4 | - | - | 941906-0 | Fjäderbricka | Spring washer | | 2 | | 0340 |
| 12 | 2 | - | - | 3103805-2 | Skruv | Screw | | | | (|
| 13 | 2 | - | - | 942767-5 | Fjäderbricka | Spring washer | | 2 | | 0350 |
| 14 | 1 | - | - | 3293635-3 | Konsol | Bracket | | 4 | B14, VST, CH-545499 | 0400 |
| | 1 | - | - | 3293636-1 | Konsol | Bracket | | 4 | B14, HST, CH-545499 | 0420 |
| 15 | 1 | - | - | 3271061-8 | Konsol | Bracket | | 4 | | 0440 |
| 16 | 1 | - | - | 3292867-3 | Konsol | Bracket | | 4 | VST | 0460 |
| | 1 | - | - | 3292435-9 | Konsol | Bracket | | 4 | HST, (3292432) | 0480 |
| 17 | 1 | - | - | 3294251-8 | Konsol | Bracket | | 4 | VST, CH-709999 | 0500 |
| | 1 | - | - | 3285869-8 | Konsol | Bracket | | 3 | VST, CH 710000- | 0505 |
| | 1 | - | - | 3292433-4 | Konsol | Bracket | | 4 | HST, CH-709999 | 0520 |
| | 1 | - | - | 3285870-6 | Konsol | Bracket | | 3 | HST, CH 710000- | 0525 |
| 18 | 2 | - | - | 3272305-8 | Klamma | Clamp | | 3 | | 0540 |
| 19 | 1 | - | - | 3294045-4 | Skyddsbälg | Concertina | | 3 | | 0560 |
| 20 | 1 | - | - | 3293628-8 | Rattaxel | Steering shaft | | 4 | B14 VST, CH-550491 | 0580 |
| | 1 | - | - | 3297198-8 | Rattaxel | Steering shaft | | 4 | B14 VST, CH 550492- B19 VST | 0600 0620 |
| | 1 | - | - | 3293629-6 | Rattaxel | Steering shaft | | 4 | B14 HST, CH-549786 | 0640 |
| | 1 | - | - | 3297199-6 | Rattaxel | Steering shaft | | 4 | B14 HST, CH 549787- B19 HST | 0660 0680 |
| 21 | 2 | - | - | 3266718-0 | Kullager | Ball bearing | | 3 | | 0700 |
| 22 | 2 | - | - | 3266719-8 | Ring | Ring | | 3 | | 0720 |
| 23 | 2 | - | - | 3290068-0 | Fjäder | Spring | | 3 | |) |
| 24 | 2 | - | - | 945494-3 | Låsring | Circlip | | 2 | | 0760 |
| 25 | 1 | - | - | 3266720-6 | Medbringare | Companion | | 4 | | 0780 |
| 26 | 2 | - | - | 940132-4 | Skruv | Screw | | 2 | | 0800 |
| 27 | 2 | - | - | 946036-1 | Mutter | Nut | | 2 | | 0820 |
| 28 | 1 | - | - | 3292414-4 | Rattaxel | Steering shaft | | 4 | B14, VST CH-550491 B14, HST CH-549786 | 0840) |
| | 1 | - | - | 3297189-7 | Rattaxel | Steering shaft | | 4 | B14 VST, CH 550492- B14 HST, CH 549787- B19 VST | 0900 0920 |
| | 1 | - | - | 3294111-4 | Rattaxel | Steering shaft | | 4 | B19 HST | 0940 |
| 29 | 2 | - | - | 3270125-2 | Skruv | Screw | | 3 | | 0960 |
| 30 | 5 | - | - | 955138-3 | Skruv | Screw | | 2 | | 0970 |
| 31 | 1 | - | - | 3290157-1 | Hållare | Retainer | | 3 | | 1000 |
| 32 | 1 | - | - | 3290156-3 | Dammskydd | Dust cap | | 3 | | 1020 |
| 33 | 1 | - | - | 3291520-9 | Bussning | Bushing | | 3 | | 1040 |
| 34 | 1 | - | - | 3292416-9 | Dammskydd | Cover | | 4 | CH-545499 | 1060 |
| | 1 | - | - | 3294095-9 | Dammskydd | Cover | | 4 | B14, CH 545500- B19, VST | 1080 1100 |
| 35 | 1 | - | - | 3297470-1 | Konsol | Bracket | | 4 | VST, CH 545500-709999 | 1120 |
| | 1 | - | - | 3283363-4 | Konsol | Bracket | | 3 | VST, CH 710000- | 1125 |
| | 1 | - | - | 3297471-9 | Konsol | Bracket | | 4 | HST, CH 545500-709999 | 1140 |
| | 1 | - | - | 3284931-7 | Konsol | Bracket | | 3 | HST, CH 710000- | 1145 |
| 36 | 5 | - | - | 3103805-2 | Skruv | Screw | | | | 1160 |
| 37 | 5 | - | - | 3270132-8 | Fjäderbricka | Spring washer | | 2 | | 1180 |

| Sida Page | Grupp Group | Styrkolonn | Steering column | Illustration | 0100 | | | | | |
|--------------|----------------|------------|-----------------|-----------------------|----------------------------|------------------------------------|-------------|------------------|---|--------------|
| 6 | 6 | | | 17201 1984-12 | | | | | | |
| Pos. Fig. | Antal/Quantity | | | Artikel nr Part No | Benämning | Description | Sats Kit | B P S R | Anmärkning Notes | |
| | | | | | | | | | | |
| 38 | 2 | - | - | 3290053-2 | Skruv..... | Screw..... | 2 | | | 1200 |
| 39 | 1 | - | - | 3297223-4 | Koppling..... | Coupling..... | 3 | | | 1220 |
| x | - | - | - | 3208578-9 | Koppling..... | Coupling..... | 3 | | AUSTRALIA | 1225 |
| 40 | 2 | - | - | 946036-1 | Mutter..... | Nut..... | 2 | | | 1240 |
| 41 | 1 | - | - | 3270034-6 | Skruv..... | Screw..... | 3 | | | 1260 |
| 42 | 1 | - | - | 3290060-7 | Medbringare..... | Companion..... | 3 | | | 1280 |
| 43 | 1 | - | - | 946036-1 | Mutter..... | Nut..... | 2 | | | 1300 |
| 44 | 2 | - | - | 946036-1 | Mutter..... | Nut..... | 2 | | | 1320 |
| 45 | 1 | - | - | 3268831-9 | Styrväxel..... | Steering box..... | 5 | | B14, VST, CH-616107 ERS AV 3289818-1 | 1340 1345 |
| | 1 | - | - | 3290164-7 | Styrväxel..... | Steering box..... | 5 | | B14, HST, CH-593523 ERS AV 3281026-9 | 136 1380 |
| | - | - | - | | .Det se sida 8, 2-F09..... | .Comps page 8, 2-F09..... | | | | 1400 |
| | 1 | - | - | 3289818-1 | Styrväxel..... | Steering box..... | 5 | | B19, VST, (3280540) | 1420 |
| | 1 | - | - | 3289820-7 | Styrväxel..... | Steering box..... | 5 | | B14, VST, CH 616108- (3281026) | 1422 |
| | - | - | - | | | | | | B14, HST, CH 593524- (3290164) | 1425 142 |
| | 1 | - | - | 3289819-9 | Styrväxel..... | Steering box..... | 5 | | B19, HST, (3280541) | 1426 1440 |
| | - | - | - | | Det se sida 10, 2-F11..... | Comps page 10, 2-F11..... | | | | 1480 |
| 46 | 2 | - | - | 951204-7 | Mutter..... | Nut..... | 2 | | | 1500 |
| 47 | 2 | - | - | 955894-1 | Bricka..... | Washer..... | 2 | | | 1520 |
| 48 | 2 | - | - | 955300-9 | Skruv..... | Screw..... | 2 | | | 1540 |
| 49 | 2 | - | - | 955297-7 | Skruv..... | Screw..... | 2 | | | 1560 |
| 50 | 1 | - | - | 3294075-1 | Konsol..... | Bracket..... | 4 | | (3290839) | 1580 |
| 51 | 1 | - | - | 3294074-4 | Konsol..... | Bracket..... | 4 | | (3290838) | 1600 |
| 52 | 2 | - | - | 946036-1 | Mutter..... | Nut..... | 2 | | | 1620 |
| 53 | - | - | - | | Ratt- och startlås..... | Column lock and ignition switch | | | SE GRUPP 3 | 1640 1660 |
| 54 | 2 | - | - | 941761-9 | Skruv..... | Screw..... | 2 | | | 1680 |
| 55 | 2 | - | - | 959222-1 | Skruv..... | Screw..... | 2 | | | 1700 |
| 56 | 2 | - | - | 3291524-1 | Mutter..... | Nut..... | 2 | | | 1720 |
| 57 | 2 | - | - | 907847-8 | Saxpinne..... | Split pin..... | 2 | | | 1740 |
| 58 | - | - | - | | Konsol..... | Bracket..... | | | SE SIDA 22, 2-F23 | 1760 |
| 59 | 4 | - | - | 963105-2 | Mutter..... | Nut..... | 2 | | | 1780 |
| 60 | 4 | - | - | 955892-5 | Fjäderbricka..... | Spring washer..... | 2 | | | 1800 |