



VOLVO PARTS
 1023 17932

A							FUEL TANK WITH FITTING PARTS		BRÄNSLETANK OCH ANSLUTNINGSDETALJER		Group Grupp 23
B											Page Sida 173
C											
D											
E									B14, B172		
Fig Pos	Part no. Artikel nr.	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	3343236-0	1	-	-	-	-	Fuel tank	Bränsletank	(32956500)	4	
2	955299-3	4	-	-	-	-	Screw	Skruv			
3	955921-2	4	-	-	-	-	Washer	Bricka			
4	3297074-1	4	-	-	-	-	Washer	Bricka		3	
5	3102649-5	4	-	-	-	-	Spacer ring	Distansring		2	
6	3100848-5	4	-	-	-	-	Rubber ring	Gummiring		3	
7	3102722-0	4	-	-	-	-	Rubber bushing	Gummibussning		3	
8	3202495-2	1	-	-	-	-	Fuel gauge sender	Bränslenivågivare	B14.3E	2	
	3205815-8	1	-	-	-	-	Fuel gauge sender	Bränslenivågivare	B14.4E/S	2	
		-	-	-	-	-			B172, CH -766366		
	3213293-8	1	-	-	-	-	Fuel gauge sender	Bränslenivågivare	B172, CH 766367-	2	
9	3342840-0	1	-	-	-	-	• Filter	• Filter	B14 (33423179)	2	
		-	-	-	-	-			B172, CH -766366		
10	3140690-3	1	-	-	-	-	Hose	Slang	1)	2	
	3209485-6	1	-	-	-	-	Hose	Slang	2)	3	
11	1336649-7	X	-	-	-	-	Hose	Slang	(1920347)		
12	976572-8	2	-	-	-	-	Hose clamp	Slangklamma	(9473315)		
13	946709-3	X	-	-	-	-	Hose clamp	Slangklamma			
14	3298368-6	1	-	-	-	-	T-piece	T-nippel		3	
15	3273014-5	1	-	-	-	-	Hose	Slang		3	
16	943480-4	2	-	-	-	-	Hose clamp	Slangklamma			
17	960137-8	1	-	-	-	-	Washer	Bricka			
18	955130-0	1	-	-	-	-	Screw	Skruv	(31067143)		
19	3121025-5	1	-	-	-	-	Nut	Mutter	(32860280)	3	
20	945652-6	X	-	-	-	-	Hose clamp	Slangklamma			
21	3298366-0	1	-	-	-	-	Valve	Spjäll		3	
22	3298395-9	1	-	-	-	-	Filler pipe	Påfyllningsrör		4	
	3210240-2	1	-	-	-	-	Filler pipe	Påfyllningsrör	OXICAT	4	
23	3273253-9	1	-	-	-	-	• Anchorage	• Lockhållare		3	
24	3285113-1	1	-	-	-	-	Filler cap	Påfyllningslock		1	
		-	-	-	-	-	non lockable	ej låsbart			
	3207263-9	1	-	-	-	-	Filler cap	Påfyllningslock		2	
		-	-	-	-	-	black	svart			
		-	-	-	-	-	Lockable	Låsbart			
	3207265-4	1	-	-	-	-	Filler cap	Påfyllningslock		2	
		-	-	-	-	-	primer	grundfärg			
		-	-	-	-	-	lockable	låsbart			
	3210568-6	1	-	-	-	-	Filler cap	Påfyllningslock		2	
		-	-	-	-	-	Unleaded fuel	Unleaded fuel			
25	3287946-2	1	-	-	-	-	Lock cylinder	Låscylinder		2	
		-	-	-	-	-	Two keys	Två nycklar		2	
26	3298367-8	1	-	-	-	-	Expansion tank	Expansionstank		2	
27	3273922-9	2	-	-	-	-	Bushing	Bussning		2	
28	3273923-7	2	-	-	-	-	Bushing	Bussning		2	
29	3102808-7	X	-	-	-	-	Hose	Slang		6	
30	3120368-0	1	-	-	-	-	Clamp	Klämma		2	
31	3283842-7	1	-	-	-	-	Plate	Platta		4	
32	946234-2	X	-	-	-	-	Hose	Slang			
	3284899-6	X	-	-	-	-	Hose	Slang	B172 OXICAT	3	
33	946234-2	X	-	-	-	-	Hose	Slang			
34	3284126-4	X	-	-	-	-	Hose	Slang		2	
35	3272726-5	1	-	-	-	-	Rubber bushing	Gummibussning		2	
36	948211-8	1	-	-	-	-	Clamping band	Klämband	(32723058)		
37	3120488-6	1	-	-	-	-	Clamp	Klämma	B172	4	
38	3282863-4	1	-	-	-	-	Pipe bend	Rörböj	B172	4	
39	3200212-3	1	-	-	-	-	Clip	Clips		2	
40	3211822-6	1	-	-	-	-	Non-return valve	Backventil	B172	2	
41	3140677-0	1	-	-	-	-	Rubber bushing	Gummibussning		3	
42	3209521-8	X	-	-	-	-	Hose	Slang	B172 OXICAT	6	
43	3275339-4	X	-	-	-	-	Hose	Slang		3	
44	944219-5	1	-	-	-	-	Gasket	Packning			
45	3298396-7	1	-	-	-	-	Gasket	Packning		2	

 1) CH -120999
 2) CH 121000-