



VOLVO PARTS  
 1023 17948

A		B200K					FUEL TANK		BRÄNSLETANK		Group
B		B200E					WITH FITTING PARTS		OCH ANSLUTNINGSDETALJER		Grupp
C											23
D											Page
E											Sida
											177
Fig Pos	Part no. Artikel nr.	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	3287671-6	1	-	-	-	-		Fuel tank .....	Bränsletank .....		4
	3288243-3	-	1	-	-	-		Fuel tank .....	Bränsletank .....		4
2	3205816-6	1	-	-	-	-		• Fuel gauge sender .....	• Bränslenivågivare .....		2
3	3342318-7	1	-	-	-	-		•• Filter .....	•• Filter .....		2
4	3205884-4	-	1	-	-	-		• Fuel gauge sender .....	• Bränslenivågivare .....		2
5	944219-5	1	1	-	-	-		• Gasket .....	• Packning .....		
6	3279585-8	X	X	-	-	-		Hose .....	Slang .....		3
7	3283121-6	2	2	-	-	-		Hose clamp .....	Slangklamma .....		2
8	3107781-1	X	X	-	-	-		Strip .....	Profil .....		3
9	3270448-8	2	2	-	-	-		Clamp .....	Klämma .....		3
10	3560342-2	1	1	-	-	-		Protecting plate .....	Skyddsplåt .....		4
11	3279248-3	2	2	-	-	-		Bracket .....	Konsol .....		4
12	3560344-8	2	2	-	-	-		Felt band .....	Filtremsa .....	(32792632)	4
13	3270243-3	2	2	-	-	-		Screw .....	Skruv .....		2
14	946036-1	2	2	-	-	-		Lock nut .....	Låsmutter .....		
15	955894-1	2	2	-	-	-		Washer .....	Bricka .....		
16	3279453-9	2	2	-	-	-		Screw .....	Skruv .....		2
17	3560341-4	1	-	-	-	-		Protecting plate .....	Skyddsplåt .....		4
	3205746-5	-	1	-	-	-		Protecting plate .....	Skyddsplåt .....		2
18	941906-0	2	2	-	-	-		Resilient washer .....	Fjädrande bricka .....		
19	955781-0	2	2	-	-	-		Nut .....	Mutter .....		
20	945970-2	5	5	-	-	-		Screw .....	Skruv .....		
21	3279455-4	5	5	-	-	-		Nut .....	Mutter .....		2
22	3279292-1	12	12	-	-	-		Spacer .....	Mellanlägg .....		3