



VOLVO PARTS  
1021 17406

A			BELT TRANSMISSION		REMTRANSMISSION		Group Grupp				
							<b>21</b>				
							Page Sida				
					B200		<b>115</b>				
Fig Pos	Part no. Artikel nr.	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	1336761-0	1	-	-	-	-		Sealing flange.....	Tätningsslans.....		4
2	1306333-4	1	-	-	-	-		Seal.....	Tätning.....		2
3	1276424-7	1	-	-	-	-		Sealing ring.....	Tätningssring.....		2
4	1378493-9	1	-	-	-	-		Gasket.....	Packning.....	(1276817)	2
5	946544-4	6	-	-	-	-		Screw.....	Skruv.....		
6	953035-3	2	-	-	-	-		Stud.....	Pinnskruv.....		
7		1	-	-	-	-		Stud.....	Pinnskruv.....	SEE 21 . 91	
8	463386-3	1	-	-	-	-		Spring guide.....	Fjäderstyrning.....		
9	463389-7	1	-	-	-	-		Spring.....	Fjäder.....		
10	463633-8	1	-	-	-	-		Tension pulley.....	Spännrulle.....		
11	463580-1	1	-	-	-	-		Washer.....	Bricka.....		
★ 12	971071-6	1	-	-	-	-		Nut.....	Mutter.....		
13	463377-2	1	-	-	-	-		Tooth belt.....	Kuggrem.....		
14		1	-	-	-	-		Pulley.....	Remskiva.....	SEE 21 . 105	
15		1	-	-	-	-		Pulley.....	Remskiva.....	SEE 21 . 81	
16		1	-	-	-	-		Pulley.....	Remskiva.....	SEE 21 . 91	
17	1336756-0	1	-	-	-	-		Belt protector.....	Remskydd.....		4
18	945407-5	1	-	-	-	-		Nut.....	Mutter.....		
19	1336757-8	1	-	-	-	-		Belt protector.....	Remskydd.....		4
20	965213-2	1	-	-	-	-		Screw.....	Skruv.....	M6X45	
	948356-1	1	-	-	-	-		Screw.....	Skruv.....	M6X30	
	965216-5	1	-	-	-	-		Screw.....	Skruv.....	M8X55	
21	948356-1	1	-	-	-	-		Screw.....	Skruv.....		
22	946671-5	1	-	-	-	-		Screw.....	Skruv.....		
23	1336759-4	1	-	-	-	-		Belt protector.....	Remskydd.....		4