



VOLVO PARTS  
1064 17813

A							STEERING BOX		STYRVÄXEL		Group Grupp <b>64</b>	
B											Page Sida	
C											545	
D												
E									EXC P.S			
Fig Pos	Part no. Artikel nr.	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R	
		A	B	C	D	E						
1	3247496-7	1	-	-	-	-		Steering gear.....	Styrapparat.....	(32958324)	5	
	3295833-2	-	-	1	-	-		Steering gear.....	Styrapparat.....	CH -279625 (32898199)	5	
	3247497-5	-	-	1	-	-		Steering gear.....	Styrapparat.....	CH 279626-	5	
	3295834-0	-	1	-	-	-		Steering gear.....	Styrapparat.....	CH -251114	5	
	3247498-3	-	1	-	-	-		Steering gear.....	Styrapparat.....	CH 251115-	5	
2	3211955-4	2	2	2	-	-		• Ball joint.....	• Kullad.....		1	
3	955804-0	2	2	2	-	-		• Nut.....	• Mutter.....			
4	3293736-9	2	2	2	-	-		• Drag link.....	• Dragjärn.....		2	
5	3298989-9	2	2	2	-	-		• Bump stop.....	• Bomningsanslag.....		4	
6	3292862-4	1	-	-	-	-		• Rack.....	• Bock.....	CH -246952	4	
	3210922-5	1	-	-	-	-		• Rack.....	• Bock.....	CH 246953-	4	
	3292863-2	-	1	1	-	-		• Rack.....	• Bock.....	360, 340 CH -251114	4	
	3210923-3	-	1	-	-	-		• Rack.....	• Bock.....	CH 251115-	4	
7	3293203-0	1	-	-	-	-		• Shaft.....	• Axel.....	CH -246952	4	
	3211214-6	1	-	-	-	-		• Shaft.....	• Axel.....	CH 246953-	4	
	3296029-6	-	1	-	-	-		• Shaft.....	• Axel.....	CH -251114	4	
	3211215-3	-	1	-	-	-		• Shaft.....	• Axel.....	CH 251115-	4	
	3293205-5	-	-	1	-	-		• Shaft.....	• Axel.....	CH -279625	4	
	3211216-1	-	-	1	-	-		• Shaft.....	• Axel.....	CH 279626-	4	
8	3411271-4	1	1	1	-	-		• Sealing ring.....	• Tätningsring.....	(32007643)	4	
9	3294039-7	1	1	1	-	-		• Needle bearing.....	• Nållager.....		4	
10	3289821-5	1	-	-	-	-		• Steering gear housing.....	• Styrväxelhus.....		6	
	3289822-3	-	1	1	-	-		• Steering gear housing.....	• Styrväxelhus.....		6	
11	947065-9	2	2	2	-	-		• Clamp.....	• Klämma.....			
12	3411022-1	1	1	1	-	-		• Bellows.....	• Bålg.....		2	
13	943476-2	1	1	1	-	-		• Hose clamp.....	• Slangklämma.....			
14	943478-8	1	1	1	-	-		• Clamp.....	• Klämma.....			
15	3268834-3	1	1	1	-	-		• Bellows.....	• Bålg.....		2	
16	3411028-8	1	1	1	-	-		• Cover.....	• Kåpa.....	LHD CH 50022-246952 RHD CH 50022-251114	4	
	3200132-3	1	1	1	-	-		• Cover.....	• Kåpa.....	CH-50022	4	
	3211385-4	1	1	-	-	-		• Cover.....	• Kåpa.....	LHD CH 246953-	4	
17	3297589-8	1	1	1	-	-		• Bushing.....	• Bussning.....		4	
18	3298950-1	1	1	1	-	-		• Supporting washer.....	• Stödbricka.....		4	
19	3296534-5	1	1	1	-	-		• Adjusting piston.....	• Justerkoiv.....		4	
20	3298158-1	1	1	1	-	-		• Spring.....	• Fjäder.....		3	
21	3212296-2	1	1	1	-	-		• Gasket.....	• Packning.....	NON ASBESTOS (32935827)	4	
22	3292845-9	1	1	1	-	-		• Cover.....	• Kåpa.....		4	
23	941907-8	2	2	2	-	-		• Resilient washer.....	• Fjädrande bricka.....			
24	955295-1	2	2	2	-	-		• Screw.....	• Skruv.....			
25	3298728-1	1	1	1	-	-		• Screw.....	• Skruv.....		4	
26	3293627-0	1	1	1	-	-		• Nut.....	• Mutter.....		4	
27	3293505-8	1	1	1	-	-		• Cover.....	• Kåpa.....		4	
28	3292961-4	1	1	1	-	-		• Ball bearing.....	• Kullager.....		3	
29	960148-5	1	1	1	-	-		• Washer.....	• Bricka.....	(9611617)		
30	3270174-0	1	1	1	-	-		• Nut.....	• Mutter.....		4	
31	3285699-9	1	1	1	-	-		• Washer.....	• Bricka.....	CH 50022-	4	
32	963119-3	2	2	2	-	-		• Lock nut.....	• Låsmutter.....			