



VOLVO PARTS
 1064 17872

A		340 LHD					P S	Description	Benämning	Notes Anmärkning	S R
B		340 RHD									
C		360 LHD									
D		360 RHD									
E											
Fig Pos	Part no. Artikel nr.	Quantity / Antal					S				
		A	B	C	D	E					
1	3290968-1	1	1	1	1	-	Nut.....	Mutter.....			3
2	945494-3	2	2	2	2	-	Circlip.....	Låsring.....			3
3	3290068-0	2	2	2	2	-	Spring.....	Fjäder.....			3
4	3266719-8	2	2	2	2	-	Washer.....	Bricka.....			3
5	3266718-0	2	2	2	2	-	Ball bearing.....	Kullager.....			3
6	3286292-2	1	1	1	1	-	Housing.....	Hus.....			3
7	3288612-9	1	-	1	-	-	Steering column.....	Styrkolonn.....			4
	3288613-7	-	1	-	1	-	Steering column.....	Styrkolonn.....			4
8	955294-4	1	1	1	1	-	Screw.....	Skruv.....			4
9	946036-1	7	7	7	7	-	Lock nut.....	Låsmutter.....			
10	955271-2	4	4	4	4	-	Screw.....	Skruv.....			
11	941906-0	4	4	4	4	-	Resilient washer.....	Fjädrande bricka.....			
12	955892-5	4	4	4	4	-	Washer.....	Bricka.....			
13	963105-2	4	4	4	4	-	Nut.....	Mutter.....			
14		-	-	-	-	-	Column lock and.....	Rattlås med.....	SEE 36 • 369		
		-	-	-	-	-	Ignition switch.....	Startlås.....			
15	3271061-8	1	1	1	1	-	Bracket.....	Konsol.....			4
16	3212936-3	1	1	1	1	-	Bracket.....	Konsol.....	(32940751)		4
17	3285869-8	1	-	1	-	-	Connection pipe.....	Anslutningsrör.....			3
	3285870-6	-	1	-	1	-	Connection pipe.....	Anslutningsrör.....			3
18	3120254-2	1	1	1	1	-	Skrivet.....	Nit.....			3
19	959222-1	2	2	2	2	-	Screw.....	Skruv.....			
20	3297198-8	1	-	1	-	-	Steering shaft.....	Rattaxel.....			4
	3297199-6	-	1	-	1	-	Steering shaft.....	Rattaxel.....			4
21	3294074-4	1	1	1	1	-	Bracket.....	Konsol.....	1)		4
	3212935-5	1	1	1	1	-	Bracket.....	Konsol.....	2)		4
22	948645-7	4	4	4	4	-	Nut.....	Mutter.....			
23	3210490-3	1	-	1	-	-	Steering shaft.....	Rattaxel.....			4
	3212035-4	-	1	-	-	-	Steering shaft.....	Rattaxel.....			4
	3211967-9	-	-	-	1	-	Steering shaft.....	Rattaxel.....			4
24	963119-3	2	2	2	2	-	Lock nut.....	Låsmutter.....			
25	3266720-6	1	1	1	1	-	Universal joint.....	Universalknut.....			4
26	947818-1	2	2	2	2	-	Screw.....	Skruv.....	(9401324)		
27		-	-	-	-	-	Steering gear.....	Styrapparat.....	SEE 64 • 545		
28	3297189-7	1	1	1	-	-	Steering shaft.....	Rattaxel.....			4
	3294111-4	-	-	-	1	-	Steering shaft.....	Rattaxel.....			4
29	3270125-2	2	2	2	2	-	Screw.....	Skruv.....			3
30	955138-3	5	5	5	5	-	Screw.....	Skruv.....			
31	3290157-1	1	1	1	1	-	Washer.....	Bricka.....			3
32	3290156-3	1	1	1	1	-	Dust cover.....	Dammskydd.....			3
33	3205960-2	1	1	1	1	-	Bushing.....	Bussning.....	(32915209)		3
34	3294095-9	1	1	1	-	-	Cover.....	Kåpa.....			4
35	3283363-4	1	-	1	-	-	Support.....	Stöd.....			3
	3284931-7	-	1	-	1	-	Support.....	Stöd.....			3
36	955294-4	5	5	5	5	-	Screw.....	Skruv.....			
37	3270132-8	5	5	5	5	-	Spring washer.....	Fjäderbricka.....			2
38	3290053-2	2	2	2	2	-	Screw.....	Skruv.....			2
39	3208578-9	1	1	1	1	-	Coupling.....	Koppling.....	(32972234)		3
40	955894-1	2	2	2	2	-	Washer.....	Bricka.....			
41	3270034-6	1	1	1	1	-	Screw.....	Skruv.....			3
42	3290060-7	1	1	1	1	-	Companion flange.....	Medbringare.....			3
43	941761-9	2	2	2	2	-	Screw.....	Skruv.....			

 1) CH -357099
 2) CH 357100-