



VOLVO PARTS
 1080 17102



Sida Page	Grupp Group	Framstolar CH -347999	Front seats CH -347999	Illustration 17102 1983-03	1100
80	8				

Pos. Fig.	Antal/Quantity				Artikel nr Part No	Benämning	Description	Sats Kit	B P S R	Anmärkning Notes	
1	1	-	-	-	3276393-0	Sitsram, V	Seat frame, L	5			0020
	1	-	-	-	3276394-8	Sitsram, H	Seat frame, R	5			0040
2	4	-	-	-	3105475-2	Fjäder, V	Spring, L	5			0060
	4	-	-	-	3262473-6	Fjäder, H	Spring, R	4			0080
3	2	-	-	-	3105476-0	Gummiplatta	Rubber plate	5			0100
4	2	-	-	-	3269516-5	Glidskena, V	Adjuster rail, L	5			0120
	2	-	-	-	3269517-3	Glidskena, H	Adjuster rail, R	5			0140
5	8	-	-	-	3270096-5	Skruv	Screw	4	L20		0160
6	8	-	-	-	955919-6	Fjäderbricka	Spring washer	2			0180
7	8	-	-	-	3102946-5	Bricka	Washer	2			0200
8	2	-	-	-	3269518-1	Spärrbygel	Catch clamp	5			0240
9	8	-	-	-	955275-3	Skruv	Screw	2	L 30		0260
	8	-	-	-	3270102-1	Skruv	Screw	4	L 25		0280
10	8	-	-	-	3102946-5	Bricka	Washer	2			0300
11	2	-	-	-	3261937-1	Stoppning	Upholstery	5			0320
12	-	-	-	-		Klädsel	Cover			SE SIDA 64, 2-C17	
13	58	-	-	-	3105479-4	Clips	Clip	4			
14	1	-	-	-	3105454-7	Ryggram, V	Squab frame, L	5			0340
	1	-	-	-	3105455-4	Ryggram, H	Squab frame, R	5			0380
15	2	-	-	-	3105477-8	Fjäder	Spring	4			0400
16	6	-	-	-	3105478-6	Fjäder	Spring	4			0420
17	2	-	-	-	3268072-0	Täckplatta	Cover plate	5			0440
18	4	-	-	-	955154-0	Skruv	Screw	2			0460
19	2	-	-	-	3268071-2	Knopp	Button	4			0480
20	2	-	-	-	3269579-3	Wire	Control cable	5			0500
21	2	-	-	-	3265163-0	Stång	Bar	5			0520
22	2	-	-	-	3265164-8	Stång	Bar	5			0540
23	1	-	-	-	3261933-0	Stoppning, V	Upholstery, L	5			0560
	1	-	-	-	3261934-8	Stoppning, H	Upholstery, R	5			0580
24	-	-	-	-		Klädsel	Cover			SE SIDA 64, 2-C17	0600
25	14	-	-	-	3265934-4	Clips	Clip	5			0620
26	2	-	-	-	3105201-2	Skruv	Screw	2			0640
27	2	-	-	-	942605-7	Fjäderbricka	Spring washer	2			0660
28	2	-	-	-	3105103-0	Bussning	Bushing	2			0680
29	1	-	-	-	3269768-2	Beslag, V	Fitting, L	5			0700
	1	-	-	-	3269769-0	Beslag, H	Fitting, R	5			0720
30	2	-	-	-	940199-3	Skruv	Screw	2			0740
31	2	-	-	-	955894-1	Bricka	Washer	2			0760
32	2	-	-	-	955782-8	Mutter	Nut	2			0780
33	1	-	-	-	3269772-4	Kuliss, V	Coulisse, L	4			0800
	1	-	-	-	3269773-2	Kuliss, H	Coulisse, R	4			0820
34	1	-	-	-	3269774-0	Kuliss, V	Coulisse, L	4			0840
	1	-	-	-	3269775-7	Kuliss, H	Coulisse, R	4			0860
35	4	-	-	-	3269776-5	Skruv	Screw	3			0880
36	2	-	-	-	3269770-8	Ratt	Knob	4			0900
37	2	-	-	-	3269771-6	Lock	Cover	4			0920
38	1	-	-	-		Strömställare	Switch			SE GRUPP 3	0940