



VOLVO PARTS
 1083 - 19738

A	B	C	D	E	FRONT DOOR LOCKING SYSTEM		FRAMDÖRR LÄSSYSTEM		Group Grupp		
									83		
									Page Sida		
									733		
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1		-	-	-	-		Lock kit	Låssats	SEE 83-749		
2	3344256-7	2	-	-	-		Microswitch	Mikrobrytare	-1991	3	
	3344947-1	1	-	-	-		Microswitch	Mikrobrytare	1992-	3	
3	3121661-7	2	-	-	-		Screw	Skruv	(3120538)	2	
4	3417112-4	1	-	-	-		Link, l.h.	Länk, v		2	
	3417113-2	1	-	-	-		Link, r.h.	Länk, h		2	
5	3417114-0	1	-	-	-		Link, l.h.	Länk, v		2	
	3445822-4	1	-	-	-		Link, r.h.	Länk, h		2	
6	3417115-7	1	-	-	-		Link, l.h.	Länk, v		2	
	3417116-5	1	-	-	-		Link, r.h.	Länk, h		2	
7	3417117-3	1	-	-	-		Link, l.h.	Länk, v		2	
	3417118-1	1	-	-	-		Link, r.h.	Länk, h		2	
8	3269812-8	2	-	-	-		Clip	Clips		2	
9	3417057-1	2	-	-	-		Handle black	Handgrepp svart		3	
	3450469-6	2	-	-	-		Handle grey	Handgrepp grå	-1991	3	
	3463337-0	2	-	-	-		Handle grey	Handgrepp grå	CH 250200-419042	3	
	3472650-5	2	-	-	-		Handle	Handgrepp	CH 419043-	3	
	3450363-1	2	-	-	-		Handle	Handgrepp		3	
10	3417058-9	2	-	-	-		Cover black	Kåpa svart	440	3	
	3450470-4	2	-	-	-		Cover grey	Kåpa grå	440. -1991	3	
	3463339-6	2	-	-	-		Cover grey	Kåpa grå	1992-	3	
	3455250-5	2	-	-	-		Cover grey	Kåpa grå	460. -1991	3	
	3463338-8	2	-	-	-		Cover grey	Kåpa grå	1992-	3	
	3450364-9	2	-	-	-		Cover beige	Kåpa beige	440	3	
	3455251-3	2	-	-	-		Cover beige	Kåpa beige	460	3	
11	955127-6	1	-	-	-		Screw	Skruv		2	
12	3345058-6	1	-	-	-		Door lock, l.h. not illuminated	Dörrlås, v inte belyst	(3417119)	3	
									L.H.D. CH -318877		
	3345060-2	1	-	-	-		Door lock, r.h. not illuminated	Dörrlås, h inte belyst	(3430120)	3	
									L.H.D. CH -318877		
	3430121-8	1	-	-	-		Door lock, l.h. not illuminated	Dörrlås, v inte belyst	R.H.D. CH -318877	3	
	3417120-7	1	-	-	-		Door lock, r.h. not illuminated	Dörrlås, h inte belyst	R.H.D. CH -318877	3	
	(3450453)	1	-	-	-	SP	Door lock, l.h. illuminated	Dörrlås, v belyst	L.H.D. CH -318877	3	
									REPL 1 PCS 3345058-6		
	3345060-2	1	-	-	-		Door lock, r.h. illuminated	Dörrlås, h belyst	(3450454)	3	
									R.H.D. CH -318877		
	3345058-6	1	-	-	-		Door lock, l.h.	Dörrlås, v	CH 318878-	3	
	3345060-2	1	-	-	-		Door lock, r.h.	Dörrlås, h	CH 318878-	3	
13	3122530-3	3	-	-	-		Screw	Skruv		2	
14	3122448-8	4	-	-	-		Clip	Clips		2	
15	3461839-7	2	-	-	-		Lock cath	Lässpårr	(3417037)	3	
16	3120101-5	2	-	-	-		Screw	Skruv		2	
17	3445208-6	2	-	-	-		Seal	Tätning		2	
18	3445209-4	2	-	-	-		Seal	Tätning		2	
19	3456734-7	2	-	-	-		Brace	Bygel	(3345210)	3	
20	3445211-0	2	-	-	-		Clip	Clips		2	
21	3121577-5	2	-	-	-		Plug	Propp		2	
22	3417123-1	1	-	-	-		Contact unit driver's side	Kontaktenhet förarsida	-1991	3	
	3345056-0	1	-	-	-		Contact unit driver's side	Kontaktenhet förarsida	(3463402) CH -318877	3	
	3345056-0	1	-	-	-		Contact unit driver's side	Kontaktenhet förarsida	CH 318878-600055	3	
☆	3474173-6	1	-	-	-		Contact unit driver's side	Kontaktenhet förarsida	CH 600056-	3	
☆	3474174-4	1	-	-	-		Contact unit driver's side	Kontaktenhet förarsida	CH 600056-	3	
							rem controlled centr lock	fjärrstyrt centrallås			
	(3445975)	1	-	-	-	SP	Motor unit passenger's side	Motorenhet passagerarsida	-1991	3	
									REPL 1 PCS 3345059-4,		
									1 PCS 3345063-6.		
	3345059-4	1	-	-	-		Contact unit passenger's side	Kontaktenhet passagerarsida	(3464582) CH -318877	3	
	3345059-4	1	-	-	-		Contact unit passenger's side	Kontaktenhet passagerarsida	CH 318878-	3	
23	3417052-2	2	-	-	-		Spacer	Mellanlägg		3	
24	945407-5	2	-	-	-		Flange nut	Flänsmutter		2	
25	3445804-2	1	-	-	-		Link driver's side	Länk förarsida	-1991	2	
	3445805-9	1	-	-	-		Link passenger's side	Länk passagerarsida	-1991	2	

