



		SWITCHES DOOR					STRÖMSTÄLLARE DÖRR		Group Grupp		
									36		
									Page Sida		
							1994-		401		
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1		-	-	-	-	-	NS	Switch power windows .....	Strömställare elektrisk fönsterhiss .....		
2	1363684-0	1	-	-	-	-		• Socket .....	• Sockel .....		4
3	1324263-1	2	-	-	-	-		• Clip .....	• Clips .....		2
4	1347063-8	1	-	-	-	-		• Switch .....	• Strömställare .....		2
5	1363720-2	1	-	-	-	-		• Frame .....	• Ram .....		4
6		-	-	-	-	-	NS	• Switch elec. door mirror .....	• Strömställare elbackspegel ...		
7	1363682-4	1	-	-	-	-		• Socket .....	• Sockel .....	L.H.D	4
	1363683-2	1	-	-	-	-		• Socket .....	• Sockel .....	R.H.D	4
8	1324263-1	2	-	-	-	-		• Clip .....	• Clips .....		2
9	3345134-5	2	-	-	-	-		• Switch .....	• Strömställare .....		2
10	9130426-1	1	-	-	-	-		• Frame .....	• Ram .....	(1363719)	4
11		-	-	-	-	-	NS	Switch .....	Strömställare .....	P.W	
12	1363682-4	1	-	-	-	-		• Socket .....	• Sockel .....	L.H.D	4
	1363683-2	1	-	-	-	-		• Socket .....	• Sockel .....	R.H.D	4
13	1324263-1	2	-	-	-	-		• Clip .....	• Clips .....		2
14	3523826-0	1	-	-	-	-		• Frame .....	• Ram .....		4
15	3545022-0	2	-	-	-	-		• Switch .....	• Strömställare .....		2
16		-	-	-	-	-	NS	Switch elec. door mirror .....	Strömställare elbackspegel ....		
								power windows	elektrisk fönsterhiss		
								front	främre		
17	1363682-4	1	-	-	-	-		• Socket .....	• Sockel .....	L.H.D	4
	1363683-2	1	-	-	-	-		• Socket .....	• Sockel .....	R.H.D	4
18	1324263-1	2	-	-	-	-		• Clip .....	• Clips .....		2
19	3345134-5	2	-	-	-	-		• Switch .....	• Strömställare .....		2
20	3545022-0	2	-	-	-	-		• Switch .....	• Strömställare .....		2
21	3523825-2	1	-	-	-	-		• Frame .....	• Ram .....		4
22		-	-	-	-	-	NS	Switch elec. door mirror .....	Strömställare elbackspegel ....		
								power windows	elektrisk fönsterhiss		
								rear	bakre		
23	1324263-1	2	-	-	-	-		• Clip .....	• Clips .....		2
24	1363682-4	1	-	-	-	-		• Socket .....	• Sockel .....	L.H.D	4
	1363683-2	1	-	-	-	-		• Socket .....	• Sockel .....	R.H.D	4
25	3345135-2	1	-	-	-	-		• Frame .....	• Ram .....		2
26	3345134-5	2	-	-	-	-		• Switch .....	• Strömställare .....		2
27	3545022-0	2	-	-	-	-		• Switch .....	• Strömställare .....		2
28	1347064-6	1	-	-	-	-		• Switch .....	• Strömställare .....		2
29	1362546-2	2	-	-	-	-		• Switch .....	• Strömställare .....		2
30	3462342-1	2	-	-	-	-		Switch .....	Strömställare .....		2
31	3207321-5	X	-	-	-	-		Cover .....	Kåpa .....		3
32	3207322-3	X	-	-	-	-		Cover .....	Kåpa .....		3
33	3471929-4	4	-	-	-	-		Clip .....	Clips .....		3