



		IGNITION SYSTEM					TÄNDSYSTEM		Group Grupp		
									28		
									Page Sida		
									305		
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	3344523-0	1	-	-	-	-	Distributor .....	Fördelare .....		3	
2	3342862-4	1	-	-	-	-	•Distributor cap .....	• Fördelarlock .....		1	
3	3449620-8	1	-	-	-	-	•Rotor .....	• Rotor .....	(3342863)	1	
4	3342864-0	1	-	-	-	-	•Seal .....	• Tätning .....		2	
5	3342162-9	1	-	-	-	-	•Carbon brush .....	• Elborste .....		2	
6	955274-6	3	-	-	-	-	Screw .....	Skruv .....		2	
7	955892-5	3	-	-	-	-	Washer .....	Bricka .....		2	
8	3418154-5	1	-	-	-	-	High voltage cable .....	Högspänningsledning .....	EXC B18FT,FTM	1	
	3433362-5	1	-	-	-	-	High voltage cable .....	Högspänningsledning .....	B18FT,FTM	1	
9	3342846-7	1	-	-	-	-	Ignition cable kit .....	Tändledningsats .....		3	
10	3344473-8	1	-	-	-	-	Spark plug kit .....	Tändstiftsats .....	B18K,KD,KP,KPD,EP,FP, B16F,B18F,U.	1	
	3344899-4	1	-	-	-	-	Spark plug kit .....	Tändstiftsats .....	B18E,ED,TURBO,B20F.	1	
11	3342547-1	2	-	-	-	-	Clip .....	Clips .....		2	
12	3342548-9	3	-	-	-	-	Clip .....	Clips .....		2	
13	3342549-7	1	-	-	-	-	Bracket .....	Konsol .....	EXC B18FT,FTM	2	
	3343057-0	1	-	-	-	-	Bracket .....	Konsol .....	B18FT,FTM	2	
14	3449925-1	1	-	-	-	-	Dust cap .....	Dammkåpa .....	(3432575)	3	
15		-	-	-	-	-	Ignition coil .....	Tändspole .....	SEE 28-309		
16		1	-	-	-	-	Bracket .....	Konsol .....			
17		-	-	-	-	-	Control unit .....	Styrenhet .....			
							B18E,F,K,KD,KP	B18E,F,K,KD,KP	SEE 28-307		
							B18EP,FP	B18EP,FP	SEE 28-313		
18	3435307-8	1	-	-	-	-	Earth cable .....	Stomledning .....	(3470633)	3	
19	3342142-1	1	-	-	-	-	Retainer .....	Hållare .....	B18K,KP,KPD	2	
20	3456050-8	1	-	-	-	-	Bracket .....	Konsol .....	EXC B18K,KP,KPD	2	
21	3121943-9	1	-	-	-	-	Clip .....	Clips .....	R.H.D	3	
22	3416235-4	1	-	-	-	-	Clamp .....	Klämma .....	B18FT	2	
23	3344851-5	1	-	-	-	-	Clamp .....	Klämma .....	B18U	5	
24	3473213-1	1	-	-	-	-	Clip .....	Clips .....		2	