



VOLVO PARTS
1064 - 19002

A		L.H.D					STEERING GEAR		STYRVÄXEL		Group
B		R.H.D									Grupp
C											64
D											Page
E									P.S		Sida
Fig	Part No. Artikel nr	Quantity / Antal					P	Description	Benämning	Notes Anmärkning	S
		A	B	C	D	E	S				R
1	(3436667)	1	-	-	-	-	SP	Steering gear	Styrapparat	CH -70629 REPL 1 PCS 9031601-9, 2 PCS 963119-3.	5
	(9031189)	1	-	-	-	-	SP	Steering gear	Styrapparat	REPL 1 PCS 9031601-9.	6
	(3344583)	1	-	-	-	-	SP	Steering gear	Styrapparat	CH 70630-349876 REPL 1 PCS 9031601-9	5
	(9031189)	1	-	-	-	-	SP	Steering gear	Styrapparat	REPL 1 PCS 9031601-9	6
	(3470365)	1	-	-	-	-	SP	Steering gear	Styrapparat	REPL 1 PCS 9031601-9. CH 349877-460829 REPL 1 PCS 9031601-9.	4
	9031601-9	1	-	-	-	-	EU	Steering gear	Styrväxel		4
	3465183-6	1	-	-	-	-		Steering gear	Styrapparat	CH 460830-	4
	9031603-5	1	-	-	-	-	EU	Steering gear	Styrapparat		4
	(3436668)	-	1	-	-	-	SP	Steering gear	Styrapparat	CH -72076 REPL 1 PCS 9031602-7, 2 PCS 963119-3.	5
	(9031190)	-	1	-	-	-	SP	Steering gear	Styrapparat	REPL 1 PCS 9031602-7.	6
	(3344584)	-	1	-	-	-	SP	Steering gear	Styrväxel	CH 72077-349876 REPL 1 PCS 9031602-7.	5
	(9031190)	-	1	-	-	-	SP	Steering gear	Styrapparat	REPL 1 PCS 9031602-7.	6
	3470366-0	-	1	-	-	-		Steering gear	Styrapparat	CH 349877-460829 REPL 1 PCS 9031602-7.	4
	9031602-7	-	1	-	-	-	EU	Steering gear	Styrapparat		4
	3465184-4	-	1	-	-	-		Steering gear	Styrapparat	CH 460830-	4
	9031604-3	-	1	-	-	-	EU	Steering gear	Styrapparat		4
2		-	-	-	-	-	KN	• Seal	• Tätning		
3		-	-	-	-	-	KN	• Bushing	• Bussning		
4		-	-	-	-	-	KN	• O-ring	• O-ring		
5		-	-	-	-	-	KN	• Oil deflector ring	• Oljeavkastarring		
6	3342810-3	1	-	-	-	-		• Rack	• Kuggstång		4
	3342897-0	-	1	-	-	-		• Rack	• Kuggstång		4
7		-	-	-	-	-	KN	•• Rack	•• Bock		
8		-	-	-	-	-	KN	•• Seal	•• Tätning		
9		-	-	-	-	-	KN	•• O-ring	•• O-ring		
10		-	-	-	-	-	KN	•• Washer	•• Bricka		
11		-	-	-	-	-	KN	•• Retaining ring	•• Spärring		
12		-	-	-	-	-	KN	•• Seal	•• Tätning		
13		-	-	-	-	-	KN	•• Bearing	•• Lager		
14	3345066-9	1	-	-	-	-		• Shaft	• Axel	(3342891) CH -349876	4
	3345066-9	1	-	-	-	-		• Shaft	• Axel	CH 349877-	4
	3345068-5	-	1	-	-	-		• Shaft	• Axel	(3342898) CH -349876	4
	3345068-5	-	1	-	-	-		• Shaft	• Axel	CH 349877-	4
15	3342820-2	1	1	-	-	-		• Seal	• Tätning		4
16	3342818-6	2	2	-	-	-		• Nut	• Mutter		4
17	3342819-4	2	2	-	-	-		• Seal	• Tätning		4
18	3342797-2	1	1	-	-	-		• Nut	• Mutter		2
19		-	-	-	-	-	NS	• Housing	• Hus		
20	3345065-1	1	-	-	-	-		• Pipe	• Rör	(3342805)	4
	3345067-7	-	1	-	-	-		• Pipe	• Rör	(3342896)	4
21	3342804-6	1	-	-	-	-		• Pipe	• Rör		4
	3342895-4	-	1	-	-	-		• Pipe	• Rör		4
22		-	-	-	-	-	KN	• Bearing	• Lager		
25	3342798-0	1	1	-	-	-	IK	• Sealing plug	• Tätningsplugg		4
26		-	-	-	-	-	KN	• Adjusting piston	• Justerkolv		
27		-	-	-	-	-	KN	• Spring	• Fjäder		
28		-	-	-	-	-	KN	• Cover	• Käpa		
29	3342824-4	2	2	-	-	-		• Drag link	• Dragjärn		2
30		-	-	-	-	-	KN	• Clamp	• Klamma		
31		-	-	-	-	-	KN	• Bellows	• Bälga		
32	967919-2	2	2	-	-	-	IK	• Hose clamp	• Slangklamma	(966825)	2
33	955802-4	2	2	-	-	-	IK	• Nut	• Mutter	(3342795)	2
34	3480012-8	2	2	-	-	-		• Ball joint	• Kulled		2
35	3436666	1	1	-	-	-	OP	• Cap	• Överfall		3

A	L.H.D	STEERING GEAR				STYRVÄXEL				Group Grupp	64	
	B											R.H.D
	C											
	D											
	E										P.S	
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R	
		A	B	C	D	E						
36		-	-	-	-	-	KN	• Bushing	• Bussning			
37		-	-	-	-	-	KN	• Seal	• Tätning			