



VOLVO PARTS  
1086 18691

A	B	C	D	E	COVER PLATES MUDFLAPS		TÄCKPLÅTAR STÄNKSKYDD		Group Grupp		
									86		
										Page Sida	
										613	
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	3120349-0	4	-	-	-	-	Nut .....	Mutter .....		2	
2	3270393-6	4	-	-	-	-	Screw .....	Skruv .....		2	
3	3432482-2	1	-	-	-	-	Protecting plate, l.h. ....	Skyddsplatta, v .....		2	
	3432483-0	1	-	-	-	-	Protecting plate, r.h. ....	Skyddsplatta, h .....		2	
4	3415134-0	1	-	-	-	-	Mudflap, l.h. ....	Stänkskydd, v .....	(3447436)	1	
	3415135-7	1	-	-	-	-	Mudflap, r.h. ....	Stänkskydd, h .....	(3447437)	1	
5	3270409-0	12	-	-	-	-	Screw .....	Skruv .....		5	
6	3122453-8	18	-	-	-	-	Rivet .....	Nit .....		2	
7	3122456-1	4	-	-	-	-	Nut .....	Mutter .....		1	
8	3415136-5	1	-	-	-	-	Mudflap, l.h. ....	Stänkskydd, v .....		1	
	3415137-3	1	-	-	-	-	Mudflap, r.h. ....	Stänkskydd, h .....		1	
9	3416174-5	1	-	-	-	-	Cover plate, l.h. ....	Täckplatta, v .....		3	
	3416175-2	1	-	-	-	-	Cover plate, r.h. ....	Täckplatta, h .....		3	
10	948571-5	8	-	-	-	-	Spring nut .....	Fjädermutter .....		2	
11	3410692-2	1	-	-	-	-	Cover .....	Huv .....	1)	2	
	3460743-2	1	-	-	-	-	Cover .....	Huv .....	2)	2	
☆ 12	3470029-4	1	-	-	-	-	Cover plate .....	Täckskiva .....	(3435204)	3	
☆ 13	3435201-3	1	-	-	-	-	Cover plate .....	Täckskiva .....	1)	2	
	3470030-2	1	-	-	-	-	Cover plate .....	Täckskiva .....	2) (3457069)	3	
14	3104081-9	3	-	-	-	-	Nut .....	Mutter .....		2	
15	3122397-7	3	-	-	-	-	Screw .....	Skruv .....		2	
16	945358-0	5	-	-	-	-	Flange screw .....	Flänsskruv .....		2	
17	3120476-1	2	-	-	-	-	Nut .....	Mutter .....		2	
18	3120288-0	4	-	-	-	-	Screw .....	Skruv .....		2	
19	3413050-0	1	-	-	-	-	Cover plate, l.h. ....	Täckplatta, v .....		3	
	3413051-8	1	-	-	-	-	Cover plate, r.h. ....	Täckplatta, h .....		3	
20	3453072-5	1	-	-	-	-	Protecting cap .....	Skyddshuv .....		3	
21	3433562-0	1	-	-	-	-	Protecting plate, l.h. ....	Skyddsplatta, v .....		2	
	3433563-8	1	-	-	-	-	Protecting plate, r.h. ....	Skyddsplatta, h .....		2	
22	3293328-5	4	-	-	-	-	Nut .....	Mutter .....		2	
23	3433114-0	1	-	-	-	-	Protector plate .....	Grovskydd .....		2	
24	3269355-8	6	-	-	-	-	Nut plate .....	Mutterplåt .....		6	
25	945970-2	4	-	-	-	-	Screw .....	Skruv .....		2	
	3120288-0	4	-	-	-	-	Screw .....	Skruv .....		2	
26	956090-5	2	-	-	-	-	Screw .....	Skruv .....		2	
27	3457669-4	2	-	-	-	-	Mudflap .....	Stänkskydd .....	1992-	1	
28	3120336-7	4	-	-	-	-	Screw .....	Skruv .....	1992-	2	

1) 48 L. tank / 48 L. tank  
 2) 60 l. tank / 60 L. tank