



850 18817

A	B	C	D	E	FRONT SEAT		FRAMSTOL		Group		
									85		
										Page	
										Sida	
										597	
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1		-	-	-	-		Head restraint	Nackskydd	SEE 88 • 659		
2	3438156-6	2	-	-	-		Backrest frame	Ryggram	-1993	5	
☆ 3	3467537-1	1	-	-	-		Backrest frame	Ryggram	(3467538) 1994-	5	
4	3416867-4	2	-	-	-		Padding	Stoppning		5	
5	(3417907)	2	-	-	-	SP	Cover	Kåpa	SEE 85 • 583		
							Wire matting	Resärmatta	CH -542508	5	
	(3452368)	2	-	-	-	SP	Wire matting	Resärmatta	REPL 1 PCS 3453772-0, 1 PCS 3453771-2, CH 542509-552955	5	
							Wire matting	Resärmatta	REPL 1 PCS 3453771-2, 1 PCS 3453772-0, CH 552956-	5	
6	3453771-2	8	-	-	-		Wire matting	Resärmatta		5	
7	3416863-3	2	-	-	-		Hinge support	Gångjärnsstöd		5	
	(3418202)	2	-	-	-	SP	Cover	Huv	CH -578947	4	
									REPL 1 PCS 3465971-4, 1 PCS 3465972-2, 1 PCS 3465973-0, CH 578948-	4	
8	3465972-2	2	-	-	-		Cover	Kåpa		4	
9	3120502-4	4	-	-	-		Screw	Skruv		3	
	(3413012)	2	-	-	-	SP	Knob	Knopp	CH -578947	4	
									REPL 1 PCS 3465971-4, 1 PCS 3465972-2, 1 PCS 3465973-0, CH 578948-	4	
☆ 10	3465971-4	2	-	-	-		Knob	Knopp	CH 578947	4	
	(3435731)	2	-	-	-	SP	Cable	Ledning	CH -578947	5	
									REPL 1 PCS 3465971-4, 1 PCS 3465972-2, 1 PCS 3465973-0, CH 578948-	5	
☆ 11	3465973-0	2	-	-	-		Cable	Ledning	CH 578948-	5	
						NS	• Lever	• Hävarm			
12	3410145-1	2	-	-	-		Cap retainer	Lockhållare	CH -544094	5	
	3448827-0	2	-	-	-		Cap retainer	Lockhållare	CH 544095-	5	
13	3448853-6	2	-	-	-		Strap	Stropp	(3415020)	5	
14	3401230-2	2	-	-	-		Yoke	Ok		5	
15	3410146-9	2	-	-	-		Housing	Hus		5	
16	3410143-6	2	-	-	-		Knob	Knopp		5	
17	3452401-7	2	-	-	-		Heater	Värmare	(3200530)	3	
18	3416868-2	2	-	-	-		Spring	Fjäder		3	
19	3122497-5	2	-	-	-		Clip	Clips		4	
20	3417412-8	1	-	-	-		Torsion spring, l.h.	Torsionsfjäder, v		5	
	3417413-6	1	-	-	-		Torsion spring, r.h.	Torsionsfjäder, h		5	
21	3401555-2	4	-	-	-		Spring clip	Fjäderklammer		3	
22	3401554-5	4	-	-	-		Pin	Stift		3	
23	3105479-4	X	-	-	-		Clamp	Klämma		4	
24	3432373-3	1	-	-	-		Switch relay, seat belt	Strömställare relä bilbälte		3	
25	3453772-0	8	-	-	-		Spring	Fjäder		5	
26	3416876-5	2	-	-	-		Padding	Stoppning		5	
27	3452402-5	2	-	-	-		Heater	Värmare	(3200531)	3	
28	3521725-6	2	-	-	-		• Thermostat	• Termostat	(1204871)	3	
29	3401272-4	2	-	-	-		Wire matting	Resärmatta		5	
30	3401275-7	10	-	-	-		Spring	Fjäder		4	
31	3122409-0	2	-	-	-		Profile	Profil		4	
32	3412118-6	1	-	-	-		Cover, l.h.	Kåpa, v	L.H.D	3	
	3430328-9	1	-	-	-		Cover, l.h.	Kåpa, v	R.H.D	3	
	3412119-4	1	-	-	-		Cover, r.h.	Kåpa, h	L.H.D	3	
	3430330-5	1	-	-	-		Cover, r.h.	Kåpa, h	R.H.D	3	
33	3430959-1	1	-	-	-		Lever	Hävarm		4	
☆ 34	3468508-1	2	-	-	-		Knob	Knopp	(3414950)	4	
35	3414952-6	2	-	-	-		Plug	Propp	(3414952)	4	
36	3342349-2	2	-	-	-		Clip	Clips		5	
37	3269776-5	2	-	-	-		Screw	Skruv		3	
38	(3342335)	1	-	-	-	SP	Seat frame cpl, l.h.	Sitsram kmpl, v	REPL 1 PCS 3432561-3.	5	

A							P S	Description	Benämning	Notes Anmärkning	S R			
	B													
		C												
			D											
E														
							FRONT SEAT		FRAMSTOL		Group Grupp			
											85			
											Page Sida			
											599			
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R			
		A	B	C	D	E								
	(3342335)	1	-	-	-	-	SP	Seat frame cpl, l.h.	Sitsram kmpl, v	REPL 1 PCS 3432112-5.	5			
	(3342334)	1	-	-	-	-	SP	Seat frame cpl, r.h.	Sitsram kmpl, h	REPL 1 PCS 3432561-3.	5			
	(3342334)	1	-	-	-	-	SP	Seat frame cpl, r.h.	Sitsram kmpl, h	REPL 1 PCS 3432213-3.	5			
	3432561-3	1	-	-	-	-		Seat frame, l.h.	Sitsram, v	1)	3			
	3432112-5	1	-	-	-	-		Seat frame, l.h.	Sitsram, v	2) (3342952)	3			
	3432113-3	1	-	-	-	-		Seat frame, r.h.	Sitsram, h	2)	3			
39	3417946-5	2	-	-	-	-		Handle	Handgrepp		5			
40	3342337-7	1	-	-	-	-		Adjusting lever	Justerhävarm	2)	5			
41	3342340-1	1	-	-	-	-		Connecting pipe	Anslutningsrör	2)	5			
42	3342338-5	1	-	-	-	-		Slide rail cpl, r.h.	Glidskena kmpl, h	2)	5			
	3344509-9	1	-	-	-	-		Slide rail, r.h.	Glidskena, h	1) (3342343)	5			
	3342339-3	1	-	-	-	-		Slide rail cpl, l.h.	Glidskena kmpl, v	2)	5			
	3344510-7	1	-	-	-	-		Slide rail, l.h.	Glidskena, v	1) (3344510)	5			
43	3401234-4	2	-	-	-	-		Cover ring	Täckring		5			
44	955275-3	4	-	-	-	-		Screw	Skruv	1)	2			
45	963105-2	4	-	-	-	-		Lock nut	Låsmutter	1)	2			
46	955892-5	4	-	-	-	-		Washer	Bricka	1)	2			
47	3343632-0	1	-	-	-	-		Adjuster kit	Justeringsats	2)	5			
48	955276-1	2	-	-	-	-		• Screw	• Skruv		2			
49	955892-5	4	-	-	-	-		• Washer	• Bricka		2			
50		-	-	-	-	-	NS	• Bushing	• Bussning					
51		-	-	-	-	-	NS	• Spacer	• Mellanlägg					
52	3344281-5	2	-	-	-	-		• Bushing	• Bussning		1			
53		-	-	-	-	-	NS	• Linkage	• Länkage					
54	963105-2	4	-	-	-	-		• Lock nut	• Låsmutter		2			
55	3343097-6	1	-	-	-	-		Spring	Fjäder		5			
56	955276-1	4	-	-	-	-		Screw	Skruv		2			
57	963105-2	4	-	-	-	-		Lock nut	Låsmutter		2			
58	955892-5	4	-	-	-	-		Washer	Bricka		2			
59	3342351-8	1	-	-	-	-		Spring, l.h.	Fjäder, v	2)	5			
	3342350-0	1	-	-	-	-		Spring, r.h.	Fjäder, h	2)	5			
60	3342352-6	2	-	-	-	-		Plug	Propp	2)	5			
61	3342353-4	2	-	-	-	-		Slide block	Glidklots	2)	5			
62	3923179-0	8	-	-	-	-		Bolt	Bult	(3120809)	3			
63	3343629-6	2	-	-	-	-		Bushing	Bussning		5			
64	947246-5	4	-	-	-	-		Screw	Skruv		2			
65	3416133-1	2	-	-	-	-		Plug	Propp		4			
66	3448829-6	2	-	-	-	-		Hook	Krok		5			
67	3448828-8	2	-	-	-	-		Spring	Fjäder		5			

1) Not height-adjustable seat / Ej höj- och sänkbart säte

2) Height-adjustable seat / Höj- och sänkbart säte