



VOLVO PARTS
1064 - 18195

A	L.H.D					P	S	Description	Benämning	Notes Anmärkning	S	R	
	B	C	D	E									
B	R.H.D												
C						STEERING GEAR							
D						STYRVÄXEL							
E													
Fig	Part No. Artikel nr	Quantity / Antal											
		A	B	C	D	E							
1	(3436667)	1	-	-	-	-	SP	Steering gear	Styrapparat	CH -551442		5	
	(3344583)	1	-	-	-	-	SP	Steering gear	Styrapparat	REPL 1 PCS 9031601-9, 2 PCS 963119-3.		5	
☆	(3470365)	1	-	-	-	-	SP	Steering gear	Styrapparat	CH 551443-582095		4	
☆	3465183-6	1	-	-	-	-		Steering gear	Styrapparat	REPL 1 PCS 9031601-9.		4	
	(9031189)	1	-	-	-	-	SP	Steering gear	Styrapparat	CH 582096-587960		6	
☆	9031601-9	1	-	-	-	-	EU	Steering gear	Styrväxel	REPL 1 PCS 9031601-9.		4	
	9031603-5	1	-	-	-	-	EU	Steering gear	Styrapparat	CH 587961-		4	
	(3436668)	-	1	-	-	-	SP	Steering gear	Styrapparat	CH -582095		5	
	(3344584)	-	1	-	-	-	SP	Steering gear	Styrväxel	REPL 1 PCS 9031602-7, 2 PCS 963119-3.		5	
	3470366-0	-	1	-	-	-		Steering gear	Styrapparat	CH 551443-582095		4	
☆	3465184-4	-	1	-	-	-		Steering gear	Styrapparat	REPL 1 PCS 9031602-7.		4	
	(9031190)	-	1	-	-	-	SP	Steering gear	Styrapparat	CH 582096-587960		6	
☆	9031602-7	-	1	-	-	-	EU	Steering gear	Styrapparat	CH 587961-		4	
☆	9031604-3	-	1	-	-	-	EU	Steering gear	Styrapparat	CH -582095		4	
2		-	-	-	-	-	KN	• Seal	• Tätning	REPL 1 PCS 9031602-7, 2 PCS 963119-3.			
3		-	-	-	-	-	KN	• Bushing	• Bussning	CH 551443-582095			
4		-	-	-	-	-	KN	• O-ring	• O-ring	REPL 1 PCS 9031602-7.			
5		-	-	-	-	-	KN	• Ring	• Ring	CH 582096-587960			
6	3342810-3	1	-	-	-	-		• Rack	• Kuggstång	CH 587961-		4	
	3342897-0	-	1	-	-	-		• Rack	• Kuggstång	CH -582095		4	
7		-	-	-	-	-	KN	• • Rack	• • Kuggstång	REPL 1 PCS 9031602-7.			
8		-	-	-	-	-	KN	• • Seal	• • Tätning	CH 582096-587960			
9		-	-	-	-	-	KN	• • O-ring	• • O-ring	CH 587961-			
10		-	-	-	-	-	KN	• Washer	• Bricka	REPL 1 PCS 9031602-7.			
11		-	-	-	-	-	KN	• Retaining ring	• Spårring	CH -582095			
12		-	-	-	-	-	KN	• Seal	• Tätning	REPL 1 PCS 9031602-7.			
13		-	-	-	-	-	KN	• Bearing	• Lager	CH 582096-			
14	3345066-9	1	-	-	-	-		• Shaft	• Axel	(3342891)		4	
	3345068-5	-	1	-	-	-		• Shaft	• Axel	(3342898)		4	
15	3342820-2	1	1	-	-	-		• Seal	• Tätning			4	
16	3342818-6	2	2	-	-	-		• Nut	• Mutter			4	
17	3342819-4	2	2	-	-	-		• Seal	• Tätning			4	
18	3342797-2	1	1	-	-	-		• Nut	• Mutter			2	
19		-	-	-	-	-	NS	• Housing	• Hus				
20	3345065-1	1	-	-	-	-		• Pipe	• Rör	(3342805)		4	
	3345067-7	-	1	-	-	-		• Pipe	• Rör	(3342896)		4	
21	3342804-6	1	-	-	-	-		• Pipe	• Rör			4	
	3342895-4	-	1	-	-	-		• Pipe	• Rör			4	
22		-	-	-	-	-	KN	• Bearing	• Lager				
23		-	-	-	-	-	KN	• Retaining ring	• Spårring				
24		-	-	-	-	-	KN	• Nut	• Mutter				
25	3342798-0	1	1	-	-	-	IK	• Sealing plug	• Tätningsplugg			4	
26		-	-	-	-	-	KN	• Adjusting piston	• Justerkolv				
27		-	-	-	-	-	KN	• Spring	• Fjäder				
28		-	-	-	-	-	KN	• Cover	• Käpa				
29	3342824-4	2	2	-	-	-		• Drag link	• Dragjärn			2	
30		-	-	-	-	-	KN	• Clamp	• Klamma				
31		-	-	-	-	-	KN	• Bellows	• Bälg				
32	967919-2	2	2	-	-	-	IK	• Hose clamp	• Slangklamma	(966825)		2	
☆	955802-4	2	2	-	-	-	IK	• Nut	• Mutter	(3342795)		2	
34	3480012-8	2	2	-	-	-		• Ball joint	• Kulled	(3410364)		2	
35	3436666	1	1	-	-	-	OP	• Cap	• Överfall			3	
36		-	-	-	-	-	KN	• Bushing	• Bussning				

A	L.H.D					STEERING GEAR	STYRVÄXEL	Group Grupp	64			
	B	R.H.D										
		C										
			D									
				E								
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R	
		A	B	C	D	E						
37		-	-	-	-	-	KN	• Seal	• Tätning			