






© **VOLVO**
Genuine Parts
PV 435 61331

A		1208506					AUTOMATVÄXELLÅDA		AUTOMATISCHES GETRIEBE		Grupp Seite	
B		1208505									43	
C		1208397									Sida	
D		1208517									Seite	
E		1208507							ZF22		1011	
Pos	Artikel nr Artikelnr.	Antal / Anzahl					P S	Benämning	Bezeichnung	Anmärkning Anmerkung	S R	
		A	B	C	D	E						
1	(1208506)	1	-	-	-	-	SP	Automatväxellåda	Automatisches getriebe	REPL 1 PCS 1208664-1.	5	
	(1208505)	-	1	-	-	-	SP	Automatväxellåda	Automatisches getriebe	REPL 1 PCS 1208594-0.	5	
	(1208397)	-	-	1	-	-	SP	Automatväxellåda	Automatisches getriebe	REPL 1 PCS 1208663-3.	5	
	1208517-1	-	-	-	1	-		Automatväxellåda	Automatisches getriebe		5	
	(1208507)	-	-	-	-	1	SP	Automatväxellåda	Automatisches getriebe	REPL 1 PCS 1208665-8.	5	
2	1339504-1	1	-	1	-	1		• Momentomvandlare	• Drehmomentwandler		4	
	1339818-5	-	1	-	-	-		• Momentomvandlare	• Drehmomentwandler		4	
	1385022-7	-	-	-	1	-		• Momentomvandlare	• Drehmomentwandler	(1339654)	4	
3	1339501-7	1	1	1	-	1		• Momentomvandlarkåpa	• Wandlerglocke		5	
	1339500-9	-	-	-	1	-		• Momentomvandlarkåpa	• Wandlerglocke		5	
4	1339507-4	1	1	1	1	1		• Skyddsgaller	• Schutzgitter		3	
5	973246-2	12	12	12	12	12		• Skruv	• Schraube	(949366)	2	
6	970948-6	6	6	6	6	6		• Skruv	• Schraube	(955318)	2	
7	941908-6	18	18	18	18	18		• Fjäderbricka	• Federscheibe		2	
8		1	1	1	1	1	NS	• Växellådshus	• Getriebegehäuse			
		-	-	-	-	-		• • Pumphaus- kopplingshus	• • Pumpengehäuse- Kuppl.-Gehäuse	SEE 43 • 1015		
		-	-	-	-	-		• • Kopplingshus-, planetväxel-, utgående axel	• • Kupplungsgehäuse-, Planetengetriebe Abtriebwelle .	SEE 43 • 1019		
		-	-	-	-	-		• • Överväxel, frihjul- koppling- broms	• • Overdrive, Freilauf- Kupplung- Bremse	SEE 43 • 1025		
8a	1339717-9	1	1	1	1	1		• Gummiring	• Gummiring		3	
9	1339516-5	1	1	1	1	1		• Packning	• Dichtung		3	
10	1339502-5	1	1	1	1	1		• Hus, bakre	• Gehäuse, h		4	
11	950543-9	2	2	2	2	2		• Styrpinne	• Führungsstift		2	
12	1339696-5	1	1	1	1	1		• Bult	• Bolzen		4	
13	1339698-1	1	1	1	1	1		• Fjäder	• Feder		3	
14	1339697-3	1	1	1	1	1		• Spärrhake	• Sperrhaken		4	
15	1339703-9	1	1	1	1	1		• Styrplatta	• Führungsplatte		4	
16	1339704-7	1	1	1	1	1		• Styrplåt	• Führungsblech		4	
17	1339705-4	1	1	1	1	1		• Skruv	• Schraube		3	
18	1339699-9	1	1	1	1	1		• Tryckstång	• Druckstange		3	
19		1	1	1	1	1	NS	• Plugg	• Stopfen			
20	1339706-2	1	1	1	1	1		• Axel	• Welle		4	
21	1339716-1	1	1	1	1	1		• Rörpinne	• Spannstift		2	
22	1339707-0	1	1	1	1	1		• Tättningsring	• Dichtring		3	
23	1339708-8	1	1	1	1	1		• Växelväljarkam	• Umsteuernocken		3	
24	(1339712)	1	1	1	1	1	SP	• Kam	• Nocken		4	
25	1339715-3	1	1	1	1	1		• Fjäder	• Feder		4	
26	1339671-8	1	1	1	1	1		• Packning	• Dichtung		3	
27	1339676-7	1	1	1	1	1		• Tättningsring	• Dichtring		3	
28	1339677-5	1	1	1	1	1		• Skruv	• Schraube		2	
29	1339672-6	1	1	1	1	1		• Luftnippel	• Luftnippel		3	
30	1339674-2	1	1	1	1	1		• O-ring	• O-ring		3	
31	1339675-9	1	1	1	1	1		• Låsbricka	• Sicherungsscheibe		3	
32	1339673-4	1	1	1	1	1		• Lock	• Deckel		4	
33	1339976-1	1	-	-	-	-		• Kontrollsystem	• Kontrollsystem	SEE 43 • 1065	4	
	1339975-3	-	1	-	-	-		• Kontrollsystem	• Kontrollsystem	SEE 43 • 1065	4	
	1339979-5	-	-	1	-	-		• Kontrollsystem	• Kontrollsystem	SEE 43 • 1047	4	
	1385009-4	-	-	-	1	-		• Kontrollsystem	• Kontrollsystem	SEE 43 • 1041	4	
	1339977-9	-	-	-	-	1		• Kontrollsystem	• Kontrollsystem	SEE 43 • 1035	4	
34	1339721-1	3	3	3	3	3		• Skruv	• Schraube		2	
35	1339725-2	1	1	1	1	1		• Oljesil	• Ölsieb		3	
36	1339724-5	1	1	1	1	1		• O-ring	• O-ring		2	
37	1339750-0	5	5	5	5	5		• Skruv	• Schraube		2	
38	1339723-7	8	8	8	8	8		• Skruv	• Schraube		2	
39	1339667-6	8	8	8	8	8		• Tättningsring	• Dichtring		3	
40	1339665-0	4	4	4	4	4		• Fjäder	• Feder		3	
41	1339666-8	5	5	5	5	5		• Fjäder	• Feder		3	
41a	1339997-7	1	1	1	1	1		• Tättningshylsa	• Dichthulse		3	
42	1339668-4	9	9	9	9	9		• Spärring	• Nutring		3	
43	1385020-1	1	1	1	1	1		• Packning	• Dichtung	(1339793)	3	

A		1208506					AUTOMATVÄXELLÅDA		AUTOMATISCHES GETRIEBE		Grupp	
B		1208505									Gruppe	
C		1208397									43	
D		1208517									Sida	
E		1208507					ZF22		Seite		1013	
Pos	Artikel nr Artikelnr.	Antal / Anzahl					P S	Benämning	Bezeichnung	Anmärkning Anmerkung	S R	
		A	B	C	D	E						
44	1339726-0	1	1	1	1	1	SP	•Oljesump	•Ölwanne	REPL 1PCS 1385040-9, 1PCS 1385042-5.	4	
45	(1339728)	4	4	4	4	4		•Bygel	•Bugel		2	
		-	-	-	-	-						
	1385040-9	4	4	4	4	4	SP	•Bygel	•Bugel	REPL 1PCS 1385041-7, 1PCS 1385042-5.	2	
46	(1339729)	2	2	2	2	2		•Bygel	•Bugel		2	
	1385041-7	2	2	2	2	2	NS	•Bygel	•Bugel	(1339730)	2	
47	1385042-5	6	6	6	6	6		•Skruv	•Schraube		2	
48	1339733-6	1	1	1	1	1		•Packning	•Dichtung		2	
49	965768-5	1	1	1	1	1		•Plugg	•Stopfen		2	
50		1	1	1	1	1		•Överfallsmutter	•Kappenmutter			
51	1339719-5	1	1	1	-	1		•Reglagewire	•Regelzug		3	
	1385041-7	2	2	2	2	2		•Bygel	•Bugel		2	
	1339992-8	-	-	-	1	-		•Reglagewire	•Regelzug		3	
52	1339745-0	1	1	1	1	1		•• O-ring	•• O-ring		3	
53	271696-7	1	1	1	1	1		Reparationssats	Reparatursatz		3	
							Oljesil	Ölsieb				
54	1339725-2	1	1	1	1	1	•Oljesil	•Ölsieb	3			
55	1339724-5	1	1	1	1	1	•O-ring	•O-ring	2			
56	1385020-1	1	1	1	1	1	•Packning	•Dichtung	3			
57		1	1	1	1	1	Reparationssats	Reparatursatz	SEE 43-1089			